Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit MX-T40,MX-T50,MX-T70,MX-ST40B

ZdalaMit MX-T Series Replacement Remote Control User Manual

For Samsung Speaker Models: MX-T40, MX-T50, MX-T70, MX-ST40B

Introduction

This manual provides instructions for the ZdalaMit MX-T series replacement remote control. This remote is designed to be compatible with various Samsung Speaker models, including MX-T40, MX-T50, MX-T70, MX-T40/ZA, MX-T50/ZA, MX-T70/ZA, and MX-ST40B. It offers a direct replacement solution without requiring complex programming.

Setup

1. Battery Installation

The remote control requires two (2) AAA size alkaline batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back view of the ZdalaMit MX-T series remote control, illustrating the location of the battery compartment. The compartment cover is typically located on the lower half of the back panel.

2. Initial Use

No programming is required for this replacement remote control. Once the batteries are correctly installed, the remote is ready for immediate use with your compatible Samsung Speaker system.

Operating Instructions

This section details the functions of the buttons on your ZdalaMit MX-T series remote control.





Image: Front view of the ZdalaMit MX-T series remote control, displaying all control buttons. The buttons are arranged logically for easy

access to various speaker functions.

Button Functions Overview:

- **POWER ( )**: Turns the speaker system on or off.
- **LIGHT**: Controls the speaker's lighting effects.
- **BLUETOOTH / PAIRING**: Activates Bluetooth mode and initiates pairing with a device.
- **USB**: Selects USB input source.
- **AUX**: Selects Auxiliary input source.
- **TEMPO (+/-)**: Adjusts the tempo of the audio playback.
- **SOUND MODE**: Cycles through various preset sound modes.
- **EFFECT / EFFECT+**: Applies or adjusts sound effects.
- **DJ**: Activates DJ mode or related functions.
- **DOWN / UP (Arrows)**: Navigates menus or tracks.
- **VOLUME (+/-)**: Increases or decreases the speaker volume.
- **MUTE**: Silences the audio output.
- **PLAY/PAUSE (►)**: Plays or pauses audio playback.
- **SKIP FORWARD ( ) / SKIP BACKWARD ( )**: Skips to the next or previous track.
- **BASS**: Enhances or adjusts bass levels.
- **REPEAT/SHUFFLE (↺)**: Controls playback repeat or shuffle functions.

Note: Specific button functionalities may vary slightly depending on your Samsung Speaker model. Refer to your speaker's original manual for detailed function descriptions.

MAINTENANCE

Cleaning the Remote Control

- Use a soft, dry cloth to wipe the surface of the remote control.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Ensure no liquid enters the remote's interior.
- Avoid using harsh chemicals, solvents, or abrasive cleaning materials, as these can damage the remote's finish or internal components.

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops functioning. Always replace both batteries simultaneously with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

TROUBLESHOOTING

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Remote control is not working.	• Batteries are dead or incorrectly installed. • Obstruction between remote and speaker. • Remote control is too far from the speaker.	• Replace batteries with new AAA alkaline batteries, ensuring correct polarity. • Remove any objects blocking the line of sight between the remote and the speaker's sensor. • Move closer to the speaker system.
Some buttons do not respond.	• Batteries are low. • Button is stuck or dirty. • Function not supported by your specific speaker model.	• Replace batteries. • Clean the remote control, paying attention to the unresponsive button. • Consult your Samsung Speaker's original manual to confirm supported functions.

Specifications

- **Brand**: ZdalaMit
- **Model Compatibility**: Samsung Speaker MX-T40, MX-T50, MX-T70, MX-T40/ZA, MX-T50/ZA, MX-T70/ZA, MX-ST40B
- **Power Source**: 2 x AAA Alkaline Batteries (not included)
- **Dimensions (L x W x H)**: Approximately 6 x 2 x 0.5 inches
- **Weight**: Approximately 2 ounces (without batteries)
- **Color**: Black
- **Special Feature**: Ergonomic design
- **Max Number of Supported Devices**: 1
- **Compatible Devices**: Home Theater (Samsung Speaker Systems)

Support

For any questions or assistance regarding your ZdalaMit MX-T series replacement remote control, please contact the seller or manufacturer directly. Refer to your purchase documentation for contact information.

Note: This remote control is a replacement unit and does not require programming. If issues persist after following troubleshooting steps, ensure your Samsung Speaker system is functioning correctly with its original remote (if available) or contact Samsung support for speaker-specific issues.

© 2023 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B8VJDNPH

More documents and user manuals: **https://manuals.plus/**