Pigeon 15045

Pigeon Healthifry Digital Air Fryer User Manual

Model: Pigeon Healthifry Digital Air Fryer - 4.2L (Model No. 15045)

1. Introduction

Welcome to the user manual for your new Pigeon Healthifry Digital Air Fryer. This appliance is designed to provide a healthier way to cook your favorite foods, utilizing 360° high-speed air circulation technology to achieve crispy results with significantly less oil. Please read this manual thoroughly before first use to ensure safe and optimal operation.



Figure 1.1: The Pigeon Healthifry Digital Air Fryer, showcasing its sleek green design and digital interface.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.

- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is not dishwasher safe. Refer to the cleaning section for proper maintenance.

3. Product Components

Familiarize yourself with the main parts of your Pigeon Healthifry Digital Air Fryer.

1. Main Unit with Digital Touch Control Panel
2. Removable Basket (4.2L capacity)
3. Food Safe Oil Separator (Coated Stainless Steel)
4. Handle
5. Air Outlet Vent
6. Power Cord



Figure 3.1: View of the durable, long-lasting construction, including the coated stainless steel oil separator and the easy food release basket.

4. Setup and First Use

1. **Unpacking:** Carefully remove the air fryer and all packaging materials. Keep packaging for future storage or disposal.
2. **Cleaning:** Before first use, clean the basket and oil separator with warm soapy water. Wipe the main unit with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Placement:** Place the air fryer on a stable, heat-resistant, and level surface. Ensure there is adequate space (at least 10 cm) around the appliance for proper air circulation. Do not place it near walls or other appliances that are sensitive to heat.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet (220V).
5. **Initial Run (Optional but Recommended):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 180°C (356°F) to eliminate any manufacturing odors. A slight odor may be present, which is normal

and will dissipate.

5. Operating Instructions

5.1 Digital Touch Control Panel

The Pigeon Healthifry Digital Air Fryer features an intuitive digital touch control panel for easy operation.



Figure 5.1: The digital touch control panel, showing temperature and time display, and various function icons.

5.2 Basic Operation

1. **Prepare Food:** Place your ingredients in the air fryer basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the basket firmly back into the main unit.
3. **Power On:** Touch the power icon on the digital display to turn on the appliance.
4. **Set Temperature and Time:** Use the temperature and time control icons to adjust to your desired settings. The air

fryer supports temperatures from 80°C to 200°C.

5. **Start Cooking:** Press the start/pause icon to begin the cooking process.
6. **Shaking/Flipping (Optional):** For some foods, shaking or flipping halfway through the cooking time can ensure more even browning. Carefully pull out the basket, shake/flip, and reinsert. The air fryer will resume cooking automatically.
7. **Completion:** The air fryer will beep when the set time has elapsed. Carefully remove the basket and transfer food to a serving dish.

5.3 Preset Menus

The air fryer comes with 8 convenient preset menus for common dishes, taking the guesswork out of cooking.



Figure 5.2: The 8 pre-set menus available on the digital air fryer for quick and easy cooking.

- French Fries
- Paneer Tikka

- Samosa
- Vegetable Roast
- Pizza
- Cutlets/Nuggets
- Cakes
- Chips

5.4 Special Functions

- **Delay Start Function:** Plan your meals ahead by setting a delayed start time. Refer to the digital display for setting options.
- **Defrost Function:** Quickly and safely thaw frozen foods before cooking. Select the defrost icon on the control panel.



Figure 5.3: Illustration of the 360° high-speed air circulation technology, ensuring perfectly crispy and evenly cooked snacks.

The advanced 360° high-speed air circulation technology ensures perfectly crispy and evenly cooked delicious snacks,

using up to 95% less oil compared to traditional frying methods.

6. Maintenance and Cleaning

Regular cleaning will extend the life of your air fryer and ensure optimal performance.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Basket and Oil Separator:** The non-stick basket and oil separator are easy to clean. Wash them with warm water, a mild dish soap, and a non-abrasive sponge. For stubborn residue, soak them in warm soapy water for 10-15 minutes before cleaning. Rinse thoroughly and dry completely.
3. **Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scourers. Never immerse the main unit in water or any other liquid.
4. **Interior:** If necessary, wipe the interior of the air fryer with a damp cloth.
5. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

Important: The air fryer is *not* dishwasher safe. Hand washing is required for all removable parts.

7. Troubleshooting

If you encounter any issues with your air fryer, please refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet issue; appliance malfunction.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. If still not working, contact customer support.
Food is not cooked evenly.	Basket is overfilled; food not shaken/flipped.	Do not overfill the basket. Shake or flip ingredients halfway through cooking for best results.
White smoke coming from the appliance.	Grease residue from previous use; fatty ingredients.	Clean the basket and oil separator thoroughly after each use. For fatty foods, a small amount of white smoke is normal.
Food is not crispy.	Insufficient cooking time/temperature; too much moisture.	Increase cooking time or temperature. Pat dry ingredients before air frying. Ensure proper air circulation by not overcrowding the basket.
Unusual noise during operation.	Basket not inserted correctly; foreign object inside.	Ensure the basket is fully and correctly inserted. Unplug and check for any foreign objects. If noise persists, contact customer support.

8. Specifications

Feature	Detail
Model Name	Pigeon Healthifry Digital Air Fryer - 4.2L
Model Number	15045
Capacity	4.2 Litres

Feature	Detail
Wattage	1200 Watts
Voltage	220V
Control Method	Touch Control (Digital Display)
Temperature Range	80°C - 200°C
Dimensions (D x W x H)	30D x 22.9W x 29H Centimeters
Item Weight	3.5 Kilograms
Material	Stainless Steel, Plastic, Aluminium
Non-stick Coating	Yes
Dishwasher Safe	No (Basket and Oil Separator are hand-wash only)
Country of Origin	India
Included Components	Air Fryer



Figure 8.1: Product dimensions of the Pigeon Healthifry Digital Air Fryer.

9. Warranty and Support

Pigeon products are built with quality and durability in mind. For any warranty claims or technical assistance, please contact Pigeon customer support.

- **Manufacturer:** Stove Kraft Limited, Pigeon
- **Service Network:** Pigeon has over 500 service centers and a highly trained customer support team ready to assist you.
- For detailed warranty information and to locate a service center, please visit the official Pigeon website or refer to the warranty card included with your product.



Figure 9.1: The Pigeon Healthifry Digital Air Fryer is ISI Certified, ensuring quality and safety standards.

© 2025 Pigeon. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I reset the Pigeon Healthifry Digital Air Fryer (Model 15045)?

The user manual for the Pigeon Healthifry Digital Air Fryer (Model 15045) does not specify a dedicated "factory reset" button or software reset procedure. However, for most digital air fryers of this type, you...

Read full answer