Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ezebaby B0B9MWQHJF

Ezebaby Adjustable Wooden High Chair Instruction Manual

Model: B0B9MWQHJF

Brand: Ezebaby

1. Introduction

Thank you for choosing the Ezebaby Adjustable Wooden High Chair. This chair is designed to grow with your child, offering adjustable seating and footrest positions suitable for toddlers through to teens. Crafted from solid beech wood, it provides a stable and comfortable seating solution for various activities, including dining and studying.

2. Safety Information

- Always supervise children when they are using the chair.
- Ensure all screws and fasteners are securely tightened before each use. Regularly check for loose parts.
- Do not allow children to stand on the footrest or seat without supervision.
- Keep the chair away from heat sources, open flames, and direct sunlight to prevent damage to the wood.
- Do not use the chair if any part is broken, torn, or missing. Contact customer support for replacement parts.
- The maximum weight recommendation for this chair is 100 kilograms.

3. Package Contents

Please verify that all components are present before beginning assembly:

- Wooden Chair Frame (Beech Wood components)
- Seat Cushion (Removable)
- Backrest Cushion (Removable)
- Hardware Kit (Screws, nuts, Allen wrench)
- Instruction Manual

4. Assembly Instructions

Assembly of the Ezebaby Adjustable Wooden High Chair is designed to be straightforward. Follow the detailed steps provided in the included instruction manual. Ensure all parts are correctly oriented and securely fastened. The chair features concealed screw designs for safety and a smooth finish.



Figure 1: Fully assembled Ezebaby Adjustable Wooden High Chair with cushions.



Figure 2: The chair features concealed screw designs for enhanced safety and a smooth, polished surface.

5. Setup and Adjustments

The Ezebaby high chair offers multiple adjustment options to accommodate your child's growth and various needs.

5.1. Seat and Footrest Height Adjustment

The seat and footrest are adjustable to match different table heights and ensure proper ergonomic support for your child. Locate the adjustment holes on the side frames of the chair. To adjust, remove the screws, reposition the seat/footrest to the desired height, and re-secure with the screws. Ensure both sides are at the same height level.



Figure 3: Illustration of the multiple height adjustable options for the seat and footrest.

5.2. Back Support Adjustment

The arch back support has 3 positions to customize the suitable angle for your child's comfort and posture.



Figure 4: The back support offers three adjustable positions for optimal comfort.

5.3. Proper Ergonomic Posture

When adjusted correctly, the high chair allows for an ideal elbow angle for writing and comfortable foot support, helping to correct sitting posture and build good habits.



Figure 5: Proper sitting posture achieved with the adjustable Ezebaby high chair, compared to a standard chair.

6. Operating Instructions

The Ezebaby high chair is multifunctional and can be used in various settings:

- **Dining Chair:** Adjust the seat and footrest to align with your dining table, allowing your child to comfortably join family meals.
- **Study Chair:** Optimize the chair's height for a desk or learning table to support good posture during study or creative activities.
- **General Seating:** The widened seat allows teenagers and even adults to use it in various rooms like the kitchen, living room, bedroom, or study.



Figure 6: A child using the Ezebaby high chair as a study chair at a desk.

Figure 7: The chair provides stable and comfortable seating for various activities.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the Ezebaby Adjustable Wooden High Chair's features and usage in various settings.

7. Maintenance

7.1. Cleaning the Chair Frame

The wooden frame can be wiped clean with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals that may damage the wood finish. Dry thoroughly after cleaning.

7.2. Cleaning the Removable Cushions

The seat and backrest cushions are removable and washable for easy cleaning.



Figure 8: The removable seat and backrest cushions allow for easy cleaning.

To remove the cushions, detach the straps or Velcro fasteners. Follow the care instructions on the cushion labels for washing. Typically, they can be machine washed on a gentle cycle with cold water and air-dried to maintain their shape and integrity. Ensure cushions are completely dry before reattaching.

8. Troubleshooting

- **Chair feels wobbly:** Check all assembly screws and bolts to ensure they are tightened securely. Ensure the chair is on a flat, even surface.
- **Difficulty adjusting seat/footrest:** Loosen the screws completely before attempting to reposition the components. Ensure the components slide smoothly into the desired holes before re-tightening.
- **Cushions slipping:** Ensure the attachment straps or Velcro are properly secured. If the cushions are worn, consider replacing them.

9. Specifications

Feature	Detail
Product Dimensions	18.9 x 17.1 x 29.9 inches (48 x 43.4 x 75.9 cm)
Maximum Weight Recommendation	100 Kilograms (220 lbs)
Material Type	Beech Wood
Style	Classic
Is Portable	Yes
Item Weight	17.76 pounds (8.06 kg)
Color	Natural Color
Age Range (Description)	Toddler to Teen



Figure 9: Detailed product dimensions.

10. Warranty and Support

For warranty information, product support, or to purchase replacement parts, please contact Ezebaby customer service through the retailer where the product was purchased or visit the official Ezebaby website.

© 2025 Ezebaby. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B9MWQHJF

More documents and user manuals: **https://manuals.plus/**