Nokia

Nokia 2660 Flip User Manual

Model: NOKIA 2660 TA-1480 DS IN BLACK

1. Introduction

Welcome to the user manual for your Nokia 2660 Flip phone. This guide provides essential information on setting up, operating, maintaining, and troubleshooting your device. The Nokia 2660 Flip is a 4G VoLTE keypad phone designed for ease of use, featuring a dual SIM, dual screen, and an inbuilt MP3 player and wireless FM radio.
Its classic flip design allows for simple call management, while large buttons and a clear display enhance usability for all users.

2. What's in the Box

Upon opening your Nokia 2660 Flip package, you should find the following items:

- Nokia 2660 Flip Phone
- Battery
- Charger
- User Guide (UG)



Image: The Nokia 2660 Flip phone in its open position, displaying the main screen and the large, easy-to-use keypad.

3. Setup

3.1. Installing the SIM Card and Battery

1. Carefully remove the back cover of the phone.
2. Insert your SIM card(s) into the designated slot(s). The Nokia 2660 Flip supports dual SIM cards.
3. Insert the battery into its compartment, ensuring the contacts align correctly.
4. Replace the back cover until it clicks securely into place.

3.2. Charging the Battery

Before first use, fully charge the phone's battery. Connect the charger to the phone's charging port and plug it into a power outlet. The battery indicator on the screen will show the charging status. A full charge can provide weeks of

standby time.

4. Basic Operations

4.1. Power On/Off

- To power on: Press and hold the Power key until the phone vibrates and the screen lights up.
- To power off: Press and hold the Power key, then select 'Power off' from the options.

4.2. Making and Receiving Calls

- To make a call: Dial the number using the keypad and press the Call key.
- To receive a call: Open the flip to answer, or press the Call key.
- To end a call: Close the flip or press the End Call key.

4.3. Using the Keypad and Display

The phone features large, tactile buttons for easy dialing and navigation. The 2.8-inch primary display provides a clear view of menus and content, complemented by a Zoom UI for enhanced readability.



Image: The Nokia 2660 Flip phone, showcasing its main internal display and the smaller external display when the phone is open.

5. Features Overview

- **Large Buttons and Loud Sound:** Designed for ease of use, the phone features big buttons and clear, loud audio for calls and notifications.
- **Dual Screen:** The phone includes a large 2.8-inch primary display and a secondary external screen for quick access to time, date, and notifications without opening the flip.
- **4G VoLTE Connectivity:** Enjoy clear call quality and reliable network performance with 4G VoLTE support.
- **Zoom UI:** The user interface is optimized with a zoom feature for improved visibility and navigation.
- **Extended Battery Life:** The battery is designed to last for weeks on a single charge, providing long-lasting connectivity.
- **Flip Functionality:** Answer or end calls with a simple flip of the phone.
- **Emergency Button:** A dedicated emergency button allows you to quickly contact up to 5 pre-selected contacts in urgent situations.

- **Inbuilt MP3 Player & Wireless FM Radio:** Enjoy your favorite music and radio stations on the go.



Image: The Nokia 2660 Flip phone in its closed state, highlighting the external display showing the current time and date.

6. Media Integration

6.1. Product Overview Video

Your browser does not support the video tag.

Video: A comprehensive overview of the Nokia 2660 Flip phone, detailing its key features, design, and functionality.

6.2. Additional Product Video

Your browser does not support the video tag.

Video: A detailed product overview video showcasing the Nokia 2660 Flip phone's design and user experience.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the phone's surfaces. Avoid using harsh chemicals or abrasive materials.
- **Battery Care:** To prolong battery life, avoid exposing the phone to extreme temperatures. Do not leave the phone charging for extended periods after it is fully charged.
- **Storage:** Store the phone in a cool, dry place when not in use.

8. Troubleshooting

8.1. Phone Does Not Power On

- Ensure the battery is properly inserted and charged.
- Try charging the phone for at least 30 minutes before attempting to power it on again.

8.2. No Network Signal

- Check if the SIM card is correctly inserted.
- Move to an area with better network coverage.
- Restart the phone.

8.3. Call Quality Issues

- Ensure the speaker and microphone are not obstructed.
- Adjust the call volume during a conversation.
- If using a headset, ensure it is properly connected.

9. Specifications

Feature	Detail
OS	S30+
RAM	0.05 GB
Product Dimensions	20.5 x 5.5 x 1.1 cm
Weight	124 g
Batteries	1 Lithium Ion battery (included)
Item Model Number	NOKIA 2660 TA-1480 DS IN BLACK
Wireless Communication	Cellular
Connectivity Technologies	Bluetooth, USB
Special Features	MP3, Dual_Sim, Radio

Device Interface	Buttons
Resolution	720p
Audio Jack	Wired
Form Factor	Foldable Screen
Colour	Black
Battery Power Rating	1450 mAh
Phone Talk Time	6.3 Hours
Phone Standby Time	300 Hours
Manufacturer	Foxconn
Country of Origin	India

10. Warranty and Support

This product comes with a standard brand warranty. For detailed information regarding warranty terms, replacement policies, and further support, please refer to the product detail page where you purchased the device or contact Nokia customer support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Can I access the internet on the Nokia 2660 Flip 4G phone?

The Nokia 2660 Flip is a 4G VoLTE keypad phone that runs on the S30+ operating system. While it supports 4G connectivity for high-quality voice calls and reliable network performance, its internet capabilities are...

Read full answer

What features does the inbuilt MP3 player on the Nokia 2660 Flip have, and can you shuffle songs, create playlists, or organize by artist?

The Nokia 2660 Flip features an inbuilt MP3 player and a 3.5mm audio jack for listening to music. Based on the S30+ operating system used by this device, the MP3 player typically offers basic...

Read full answer