SYSKA EB0568

SYSKA EARGROOVE EB0568 Wireless Earbuds User Manual

Model: EB0568 | Brand: SYSKA

Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your SYSKA EARGROOVE EB0568 Wireless Earbuds. Please read this manual thoroughly before using the product to ensure proper function and longevity.

What's in the Box

Upon opening your SYSKA EARGROOVE EB0568 package, you should find the following items:

- SYSKA EARGROOVE EB0568 Wireless Earbuds
- Charging Case
- Charging Cable
- Ear Cushions (various sizes)
- User Manual (this document)



Image: SYSKA EARGROOVE EB0568 Wireless Earbuds inside their charging case.

Setup

1. Charging the Earbuds and Case

Before first use, ensure both the earbuds and the charging case are fully charged.

1. Place the earbuds into their respective slots in the charging case.
2. Connect the charging cable to the charging port on the case and to a USB power source.
3. The indicator lights on the case will show the charging status. A full charge for the case can provide up to 4 full charges for the earbuds.
4. Charging time for the case is approximately 15 hours. Earbuds provide up to 4 hours of play time on a single charge.



Image: Open charging case displaying the earbuds ready for charging or use.

2. Initial Pairing with a Device

Follow these steps to pair your earbuds with your smartphone, laptop, or other compatible device.

1. Ensure the earbuds are charged and inside the charging case.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device, go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices and select "SYSKA EARGROOVE EB0568" from the list.
5. Once connected, you will hear an audio prompt, and the indicator lights on the earbuds will change.



Image: Earbuds removed from the case, ready for pairing and use.

Operating Instructions

Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on and connect to the last paired device.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging.

Touch Controls

The SYSKA EARGROOVE EB0568 features a Cognizant Active Touch Sensor for intuitive control:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Long press on either earbud during an incoming call.
- **Activate Voice Assistant (Google Assistant):** Triple tap on either earbud.

Mono/Stereo Mode

The earbuds support both mono and stereo modes for flexible listening:

- **Stereo Mode:** Use both earbuds together for an immersive audio experience.
- **Mono Mode:** Use a single earbud while the other is in the case. This is useful for calls or when you need to be aware of your surroundings.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Ear Cushions:** Remove and clean the ear cushions periodically. Ensure they are completely dry before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Water:** The earbuds are not waterproof. Avoid exposure to water or excessive moisture.

Troubleshooting

If you encounter issues with your SYSKA EARGROOVE EB0568, refer to the following common solutions:

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on your device's Bluetooth. Place earbuds back in case, close, then reopen to re-enter pairing mode.
No sound from one earbud	Check battery level of both earbuds. Try re-pairing the earbuds. Ensure both earbuds are properly seated in the charging case to reset.
Charging case not charging	Verify the charging cable is securely connected to both the case and the power source. Try a different USB port or power adapter.
Touch controls unresponsive	Ensure your fingers are clean and dry. Restart the earbuds by placing them in the case and taking them out again.

Specifications

Below are the technical specifications for the SYSKA EARGROOVE EB0568 Wireless Earbuds:

Feature	Detail
Model Name	EB0568
Connectivity Technology	Wireless
Wireless Communication Technology	Wireless
Battery Life (Earbuds)	Up to 4 hours (single charge)
Total Playtime (with case)	Up to 15 hours
Charging Time (Case)	15 Hours
Control Type	Voice Control, Touch
Special Feature	Fast Charging
Compatible Devices	Cellphones, Laptops, Desktops, Tablets, Smart Speaker
Material	Plastic
Color	Black

Feature	Detail
Item Weight	120 g
Product Dimensions (LxWxH)	5.5 x 2 x 4 Centimeters

Product Overview Video

Your browser does not support the video tag.

Video: An overview of the SYSKA EARGROOVE Wireless Earbuds, highlighting key features, battery life, design, device compatibility, and what's included in the box. This video provides a visual summary of the product's main attributes and components.

Warranty and Support

For warranty information, technical support, or service inquiries regarding your SYSKA EARGROOVE EB0568 Wireless Earbuds, please refer to the warranty card included in your product packaging or visit the official SYSKA website. You can also contact customer support through the details provided on the product's retail page or the manufacturer's website.
For further information, you may visit theproduct detail page on Amazon.in.

© 2023 SYSKA. All rights reserved.