Disney B0B9YNVDFW

Disney Store - Mickey Mouse Halloween Pumpkin Plush Instruction Manual

Model: B0B9YNVDFW

Product Overview

This instruction manual provides important information for the proper care and handling of your Disney Store Mickey Mouse Halloween Pumpkin Plush. This plush toy features Mickey Mouse dressed in a pumpkin outfit, designed for decorative display and gentle play.



Figure 1: Front view of the Mickey Mouse Halloween Pumpkin Plush. Mickey is wearing an orange pumpkin costume with a matching hat, featuring embroidered details and a soft surface.

Key Features:

- Mickey Mouse wearing a pumpkin costume
- Embroidered details for durability and aesthetic appeal
- Soft surface material for comfortable handling
- Official Disney Store product
- Dimensions: Approximately 40 cm (height) x 33 cm (width) x 20 cm (depth)

Setup

The Disney Store Mickey Mouse Halloween Pumpkin Plush requires no assembly. It is ready for use directly out of its packaging.

1. **Unboxing:** Carefully remove the plush toy from its packaging. Ensure all packaging materials are discarded responsibly.
2. **Initial Inspection:** Inspect the plush toy for any signs of damage or loose parts. If any issues are found, refer to the "Troubleshooting" section or contact customer support.
3. **Placement:** Place the plush toy in a desired location, such as a shelf, bed, or play area.

Operating

This plush toy is designed for gentle interaction and display. It does not contain electronic components or require batteries.

- **Gentle Play:** The plush is suitable for cuddling and imaginative play. Avoid rough handling to preserve its condition.
- **Display:** The plush can be used as a decorative item, especially during the Halloween season, adding a festive touch to any room.



Figure 2: The plush toy can be easily positioned in a sitting posture, ideal for display on shelves or beds.

Maintenance

Proper maintenance will help extend the life and appearance of your plush toy.

Cleaning Instructions:

- **Spot Cleaning:** For minor dirt or stains, wipe the surface gently with a clean, damp cloth. Use mild soap if necessary, but avoid harsh chemicals.
- **Drying:** Allow the plush to air dry completely. Do not machine wash or tumble dry, as this may damage the material and internal structure.
- **Storage:** When not in use, store the plush in a clean, dry place away from direct sunlight to prevent fading.





Figure 3: Side profile of the plush, showing its soft texture and detailed stitching, which should be handled with care during cleaning.

Troubleshooting

This section addresses common concerns regarding the plush toy.

Problem	Possible Cause	Solution
Plush appears flattened or misshapen.	Prolonged compression or improper storage.	Gently fluff the plush by hand. Store in a space where it can retain its shape.
Surface is dirty.	Exposure to dust or spills.	Refer to the "Cleaning Instructions" in the Maintenance section.
Stitching or fabric appears damaged.	Rough handling or manufacturing defect.	Discontinue use if damage is significant. Contact Disney Store customer support for assistance.

Specifications

Detailed specifications for the Disney Store Mickey Mouse Halloween Pumpkin Plush.

Attribute	Detail
Product Dimensions	Approximately 33 x 20 x 40 cm (Width x Depth x Height)
Item Weight	270 grams
Number of Pieces	1
Assembly Required	No
Batteries Required	No
Material Type	Plush
Color	Orange
ASIN (Model Number)	B0B9YNVDFW
First Available Date	August 17, 2022





Figure 4: Visual representation of the plush toy's dimensions: approximately 40cm height, 33cm width, and 20cm depth.

Warranty and Support

This product is manufactured by Disney Store. For specific warranty information, please refer to the terms and conditions provided at the point of purchase or visit the official Disney Store website.
For customer support, inquiries, or to report any issues with your product, please contact Disney Store customer service directly. Contact information can typically be found on the product's original packaging or on the official Disney Store website.
Online Support: Visit the Disney Store on Amazon

© 2023 Disney. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question