PERFASCIN RAV28 WJ40970EU

PERFASCIN RAV28 WJ40970EU Replacement Remote Control User Manual

For Yamaha AV Receivers

1. Introduction

This manual provides comprehensive instructions for the PERFASCIN RAV28 WJ40970EU replacement remote control. This remote is designed to function as a direct replacement for various Yamaha AV Receiver models, offering seamless control without the need for complex programming.

Compatible Yamaha AV Receiver Models:

- RAV34
- RAV250
- RX-V361
- RX-V365
- HTR-6030
- HTIB-680
- RAV34 WN46680EU
- RX-V463
- YHT-797

2. Setup

The PERFASCIN RAV28 WJ40970EU remote control requires two 1.5V AAA alkaline batteries (not included) for operation. No programming or pairing is necessary.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

4. Slide the battery cover back into place until it clicks securely.



Figure 1: Battery compartment with batteries inserted. Ensure correct polarity.

3. Operating Instructions

Once batteries are correctly installed, the remote control is ready for immediate use with your compatible Yamaha AV receiver. No additional setup is required.

3.1 Basic Operation

- **Power:** Press the **POWER** button to turn your AV receiver on or off.
- **Volume:** Use the **VOLUME +** and **VOLUME -** buttons to adjust the sound level.
- **Mute:** Press the **MUTE** button to temporarily silence the audio. Press again to restore sound.
- **Input Selection:** Use the dedicated input buttons (e.g.,**CD**, **DVD**, **TUNER**, **MULTI CH IN**) to select your desired audio/video source.
- **Scene:** The **SCENE** buttons (1-4) allow you to recall preset scene settings on your receiver.
- **Navigation:** Use the arrow buttons and **ENTER** button for menu navigation on your receiver's display.


RAV28 WJ40970 EU
STANDBY
POWER
SCENE
1
2
3
4
CD
MD/CD-R
TUNER
MULTI CH IN
DVD
DTV/CBL
DVR
V-AUX
VOLUME
MUTE
A/B/C/D/E
PRESET
SLEEP
LEVEL
MENU
AUDIO SEL
NIGHT
ENTER
RETURN
DISPLAY
SUR. DECODE
STRAIGHT
PROG
ENHANCER
FREQ/TEXT
EON
MODE–PTY
SEEK–START

Figure 2: Front view of the remote control with button layout.

3.2 Important Considerations

- Ensure a clear line of sight between the remote control and the infrared sensor on your Yamaha AV receiver.
- The maximum effective range for the remote control is approximately 10 meters (33 feet).

4. Maintenance

4.1 Battery Replacement

Replace the batteries when the remote control's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new AAA alkaline batteries.

4.2 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.

5. Troubleshooting

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the proper polarity.
  - Replace the batteries with fresh AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the AV receiver's infrared sensor.
  - Confirm that the remote is pointed directly at the AV receiver.
- **Certain functions not working:**
  - Verify that your specific Yamaha AV receiver model is listed as compatible in Section 1.
  - Some advanced functions may be specific to the original remote control and might not be fully supported by a replacement remote.

If the problem persists after trying these steps, please contact customer support for further assistance.

6. Specifications

Brand	PERFASCIN
Model Name	ANG-RAV28-WJ40970EU-US
Connectivity Technology	Infrared (IR)
Compatible Devices	Yamaha AV Receivers (Home Theater)
Battery Type	2 x AAA Alkaline Batteries (not included)
Maximum Range	10 Meters (33 feet)

Controller Type	Button Control
Button Quantity	20
Color	Black
Item Weight	2.3 Ounces

7. Warranty and Support

For any questions, concerns, or technical assistance regarding your PERFASCIN RAV28 WJ40970EU replacement remote control, please contact PERFASCIN customer service. Refer to your product packaging or retailer's website for specific contact details.

© 2024 PERFASCIN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question