SABA SB32100

Saba SB32100 32-inch HD Ready LED TV User Manual

Model: SB32100

1. Important Safety Instructions

Please read these safety instructions carefully before operating your television and retain them for future reference. Incorrect use may result in electric shock, fire, or damage to the appliance.

- **Power Source:** Connect the TV only to an AC 220-240V, 50Hz power supply.
- **Ventilation:** Ensure adequate ventilation. Do not block ventilation openings. Maintain a minimum distance of 10 cm around the TV for proper airflow.
- **Water and Moisture:** Do not expose the TV to rain or moisture. Do not place objects filled with liquids, such as vases, on the TV.
- **Heat Sources:** Keep the TV away from heat sources like radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Unplug the TV from the wall outlet before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **Wall Mounting:** If wall mounting, ensure the wall mount is securely installed and capable of supporting the TV's weight.

2. Package Contents

Verify that all items listed below are included in your package:

- Saba SB32100 32-inch HD Ready LED TV
- Remote Control
- Power Cable
- TV Stand (2 pieces) and Screws
- User Manual (this document)

3. Product Overview

The Saba SB32100 is a 32-inch (81 cm) HD Ready LED television designed for home entertainment. It features an integrated satellite receiver, multiple connectivity options, and built-in speakers.

Front View



This image shows the front of the Saba SB32100 television, highlighting its slim bezel and the 32-inch screen. The screen displays a vibrant, colorful abstract image, and icons for HD TV, DVB-T2/C/S2, HDMI, and Media Player are visible at the bottom left.

Side View and Connectivity



The side view illustrates the television's profile and the arrangement of its input/output ports on the rear panel, including USB and HDMI connections.

4. Setup

4.1 Attaching the TV Stand

1. Carefully place the TV screen-down on a soft, flat surface (e.g., a blanket or soft cloth) to prevent scratches.
2. Align the stand pieces with the corresponding slots on the bottom of the TV.
3. Secure the stand pieces using the provided screws. Ensure they are tightened firmly.

4.2 Wall Mounting (Optional)

The TV supports VESA standard wall mounts. The VESA mounting dimensions are 200 x 100 mm. Use M4 screws of appropriate length (not included). Consult a professional for wall mounting to ensure safety.

4.3 Connecting External Devices

Connect your external devices (e.g., DVD player, game console, satellite receiver) to the TV's input ports.

- **HDMI:** For high-definition audio and video. The TV has 3 HDMI ports.
- **USB:** For connecting USB storage devices (e.g., flash drives) for media playback. The TV has 2 USB ports.
- **VGA-AV-YPbPr:** For connecting older devices.
- **Antenna/Satellite Input:** Connect your terrestrial antenna or satellite dish cable.

4.4 Power Connection

After all connections are made, plug the power cable into the TV's power input and then into a wall outlet.

5. Operating the TV

5.1 Remote Control

The included remote control allows you to operate all functions of your TV. Insert two AAA batteries (not included) into the

remote control, observing the correct polarity.



This image displays the product information sheet, which includes a visual representation of the remote control layout and its various buttons for channel selection, volume control, menu navigation, and input switching.

5.2 First Time Setup

When you turn on the TV for the first time, a setup wizard will guide you through initial settings such as language, country, and channel scanning. Follow the on-screen instructions to complete the setup.

5.3 Channel Scanning

The TV supports DVB-T2/C (terrestrial/cable) and DVB-S2 (satellite) broadcasting standards. During the first-time setup or via the 'Channel' menu, you can perform an automatic or manual scan to find available channels.

5.4 Input Selection

Press the 'SOURCE' or 'INPUT' button on your remote control to cycle through available input sources (e.g., TV, HDMI1, HDMI2, USB, VGA-AV-YPbPr).

5.5 Media Playback via USB

Insert a USB storage device into one of the TV's USB ports. The TV's media player will typically launch automatically, allowing you to browse and play compatible video, audio, and image files.

6. Maintenance

6.1 Cleaning the Screen

Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner (ensure it's suitable for LED screens) and wipe carefully. Do not spray liquid directly onto the screen.

6.2 Cleaning the TV Body

Use a soft, dry cloth to wipe the TV's casing. Avoid using abrasive cleaners, waxes, or solvents as they can damage the finish.

6.3 Storage

If storing the TV for an extended period, unplug it from the power outlet and cover it to protect against dust. Store in a cool, dry place.

7. Troubleshooting

Before contacting support, try the following solutions for common issues:

- **No Power:**
  - Check if the power cable is securely plugged into both the TV and the wall outlet.

- Ensure the wall outlet is functioning by testing it with another device.
- Press the power button on the TV or remote control.

- **No Picture, but Sound is Present:**
  - Check the input source. Ensure it matches the device you are trying to view.
  - Try connecting a different device to the same input or the same device to a different input.
- **No Sound, but Picture is Present:**
  - Check the volume level and ensure the TV is not muted.
  - Verify audio cables are correctly connected for external devices.
- **Remote Control Not Working:**
  - Replace the batteries with new ones, ensuring correct polarity.
  - Ensure there are no obstructions between the remote control and the TV's IR sensor.
- **Poor Picture Quality/Signal:**
  - Check antenna/satellite cable connections.
  - Perform a channel rescan.
  - Adjust antenna position if using a terrestrial antenna.

8. Specifications

Detailed technical specifications for the Saba SB32100 TV:

Screen Size	32 inches (81 cm)
Resolution	1366 x 768 (HD Ready)
Display Technology	LED
Refresh Rate	200 Hz
Tuner Type	Integrated Satellite Receiver (DVB-S2), DVB-T2/C
Connectivity	3 x HDMI, 2 x USB, VGA-AV-YPbPr, Headphone Output, Optical Audio Output
Audio Output	2 x 8W Built-in Speakers
Product Dimensions (D x W x H)	5D x 85W x 80H cm (without stand: 730 x 85.38 x 431 mm)
VESA Wall Mount	200 x 100 mm
Energy Class	F
Power Consumption	32 kWh/1000h

Energy Label



The energy label provides information on the TV's energy efficiency class (F) and its power consumption (32 kWh per 1000 hours).

9. Warranty and Support

Your Saba SB32100 TV comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.
For technical support, service, or warranty claims, please contact the authorized service center or the distributor. You can find more information on the distributor's website: Mehmet Atmaca Elektronik.

© 2023 Saba. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question