Ontel HTBS-MC12/4

Ontel Handy Heater Freedom Instruction Manual

Model: HTBS-MC12/4 | Brand: Ontel

Introduction

The Ontel Handy Heater Freedom is a portable, rechargeable neck heater designed to provide instant warmth in various environments. Its compact, lightweight, and cordless design allows for hands-free heating, making it ideal for both indoor and outdoor use. This device features Comfort-Heat Technology with four adjustable heat settings and offers up to 6 hours of battery life per charge, ensuring comfort throughout the day.



Figure 1: Ontel Handy Heater Freedom product packaging, highlighting its wearable design and key features.

Key Features

- **Unique Portable Neck Heater:** Designed to be worn around the neck, radiating warmth to the neck, shoulders, and throughout the body.
- **Customized Heating:** Features Comfort-Heat Technology with 4 distinct heat settings for personalized comfort.
- **Battery Operated:** Powered by a rechargeable battery, offering up to 6 hours of use per charge (runtime varies by heat setting).
- **Hands-Free Design:** Cordless and wearable, allowing for unrestricted movement. Features a flexible neckband and soft-touch coating for a snug fit.
- **Versatile Use:** Suitable for various activities and environments, including relaxing at home, walking, sporting events, office work, and commuting.



Figure 2: The Handy Heater Freedom emitting a warm glow, illustrating its heating capability.



Figure 3: Heat radiating from the device, providing warmth to the neck and upper body.

What's Included

Your Ontel Handy Heater Freedom package includes the following items:

- Handy Heater Freedom Personal Heater
- USB Charging Cable
- Easy Instruction Guide

Setup

1. **Initial Charge:** Before first use, fully charge your Handy Heater Freedom using the provided USB charging cable. Connect the cable to the USB charging port on the device and a compatible USB power source. The charging indicator lights will provide status.
2. **Wearing the Device:** Gently slip the Handy Heater Freedom around your neck. The flexible neckband is designed to conform for a custom and comfortable fit. Ensure the heating elements are positioned against the back of your neck.

Operating Instructions

1. **Powering On/Off:** Locate the power button on the device. Press and hold the power button for a few seconds to turn the heater on. Repeat the action to turn it off.
2. **Adjusting Heat Settings:** Once powered on, short press the power button to cycle through the four available heat settings. The indicator lights will change to reflect the selected heat level. Choose the setting that provides your desired level of warmth.
3. **Battery Life:** The Handy Heater Freedom provides up to 6 hours of continuous heating on a full charge. Actual battery life may vary depending on the selected heat setting and environmental conditions.
4. **Recharging:** When the battery is low, connect the device to a USB power source using the included USB charging cable. The charging indicator lights will show the charging progress.



Figure 4: Enjoying warmth at outdoor events with the hands-free design.



Figure 5: Ideal for maintaining comfort while working or relaxing indoors.



Figure 6: Providing warmth during outdoor activities like walking in cold weather.



Figure 7: Keeping warm during physically demanding outdoor tasks.

Maintenance

- **Cleaning:** To clean the device, gently wipe the surfaces with a soft, damp cloth. Do not submerge the unit in water or use harsh chemicals.
- **Storage:** When not in use, store the Handy Heater Freedom in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery longevity, avoid fully depleting the battery frequently. Charge the device regularly, even if not in constant use.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the provided USB cable.
Device is not heating.	Incorrect heat setting selected or device is off.	Ensure the device is powered on and cycle through heat settings to activate heating.
Short battery life.	High heat setting selected or battery not fully charged.	Use a lower heat setting for extended battery life. Ensure the device is fully charged before use.

Specifications

Brand	Ontel
Model Number	HTBS-MC12/4
Product Dimensions	9.5 x 7.5 x 2.5 inches
Item Weight	1.09 pounds
Material	Plastic
Heating Method	Electric
Power Source	1 Lithium Ion battery (included)
Battery Life	Up to 6 hours per charge
Special Feature	Portable, Wearable, Rechargeable

Warranty & Support

The Ontel Handy Heater Freedom comes with a manufacturer's warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the Easy Instruction Guide included with your product or contact Ontel customer support directly.

For technical assistance, troubleshooting, or any product-related inquiries, please reach out to Ontel customer support through their official channels. Contact information can typically be found in the product packaging or on the manufacturer's website.

© 2023 Ontel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question