Whirlpool 8058331857369

Whirlpool Start/Pause Button Instruction Manual

For Washing Machines

Brand: Whirlpool | Model: 8058331857369

Introduction

This instruction manual provides essential information for the Whirlpool Start/Pause Button, a replacement part designed for various washing machine models. It covers compatibility, installation guidance, basic operation, maintenance tips, and troubleshooting advice to ensure proper use and longevity of the component.

Compatibility

This start/pause button is compatible with washing machines from the following brands and models:

- **Brands:** LADEN, BAUKNECHT, IGNIS, WHIRLPOOL, PROLINE, POLAR, CYLINDA
- **Whirlpool Models:** Awv8526 (858485240060), Awv9526 (858495240060)
- **Other Compatible Models:** Ev1045 (858410429050, 858410429052, 858410429054), Ev1046 (858410429060, 858410429062, 858410429064), Ev1047 (858410429090, 858410429092, 858410429094, 858410429095), Ev1048 (858410429010)

Please verify your washing machine's model number to ensure compatibility before installation.

Installation Instructions

This start/pause button is a replacement part. Installation typically involves disassembling the washing machine's control panel to access the faulty button and replace it with the new one. Due to the electrical components and potential complexity, **professional installation by a qualified technician is highly recommended**to ensure safety and proper functionality.

Important Safety Precautions:

- Always disconnect the washing machine from the power supply before attempting any installation or repair.
- Refer to your specific washing machine's service manual for detailed disassembly and reassembly instructions.
- Use appropriate tools and wear protective gear.



Image 1: Front view of the Whirlpool Start/Pause Button. This image displays the white plastic button with its internal mechanism, ready for installation into a washing machine control panel.



Image 2: Angled view of the Whirlpool Start/Pause Button. This image provides a different perspective of the button, highlighting its shape and connection points for proper alignment during installation.

Operation

Once correctly installed, the start/pause button functions as the primary control for initiating and temporarily stopping washing machine cycles. Pressing the button typically starts the selected wash program. Pressing it again during a cycle will pause the operation, allowing you to add or remove items, or make adjustments if your machine supports these features. A subsequent press will resume the cycle.

Maintenance

The start/pause button itself requires minimal maintenance. To ensure its longevity and proper function:

- Keep the control panel clean and free from dirt, dust, and detergent residue. Use a soft, damp cloth for cleaning.
- Avoid pressing the button with excessive force, which can damage the internal mechanism.
- Ensure no liquids spill directly onto the control panel, as this can lead to electrical issues or button malfunction.

Troubleshooting

If you experience issues with your start/pause button after installation, consider the following:

- **Button Not Responding:**
  - Check if the washing machine is properly plugged in and receiving power.
  - Ensure the control panel is securely reassembled and all connections are firm.
  - Verify that the button is correctly seated and not obstructed.
- **Button Feels Stuck or Loose:**
  - This may indicate incorrect installation or damage during assembly. Re-examine the button's seating.
- **Machine Does Not Start/Pause:**
  - If the button physically responds but the machine does not, the issue might be with the washing machine's internal electronics or programming, not the button itself. Consult your washing machine's user manual or a qualified technician.

If troubleshooting steps do not resolve the issue, contact a qualified appliance repair technician.

Specifications

Brand	Whirlpool
Model Number	8058331857369
Manufacturer Model	481241029517
Item Weight	250 g
ASIN	B0BBN377PL
Date First Available	July 12, 2019

Warranty and Support

This product benefits from the legal warranty of conformity and the warranty against hidden defects, as per applicable regulations. For specific warranty details or technical support, please refer to the documentation provided with your original washing machine or contact the seller or manufacturer directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question