Timex TW4B27500JT

Timex UFC Men's Core Shock 45mm Watch Instruction Manual

Model: TW4B27500JT

1. Introduction

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your Timex UFC Men's Core Shock 45mm Watch. Designed for durability and functionality, this watch features a 45mm round case, a comfortable 8-inch strap, an acrylic lens, and is water-resistant up to 100 meters (328 feet). It is an official Timex X UFC collaboration timepiece.


SHOCK
UFC
SET
START/SPLIT
WE 10 14
10:09 36
MODE
STOP/RESET
TIMEX
INDIGLO

Image 1.1: Front view of the Timex UFC Men's Core Shock 45mm Watch.

2. Setup

2.1. Initial Power-Up and Battery

Your watch comes with a Lithium Metal battery pre-installed. The watch should be operational upon arrival. If the display is blank or dim, the battery may need to be activated or replaced. Refer to the 'Maintenance' section for battery replacement guidelines.

2.2. Setting Time and Date

The Timex UFC Core Shock watch features a digital display. Specific button functions for setting time and date are typically located on the side of the watch case. Consult the diagrams below for button identification.

1. Locate the 'MODE' or 'SET' button (usually on the left side). Press and hold this button until the time display begins to flash.
2. Use the 'ADJUST' or 'START/STOP' buttons (usually on the right side) to change the flashing digits (hours, minutes, seconds).
3. Press the 'MODE' button again to cycle through different settings such as 12/24-hour format, year, month, and day.
4. Once all settings are correct, press the 'MODE' or 'SET' button one last time to exit the setting mode.



Image 2.1: Side view of the watch, highlighting the control buttons.

2.3. Strap Adjustment

The watch features a two-piece resin strap with a buckle clasp. Adjust the strap by selecting the appropriate hole for a comfortable and secure fit on your wrist. The strap length is 8 inches.

3. Operating Instructions

3.1. Basic Time Display

The watch displays time digitally. Pressing the 'MODE' button typically cycles through different display modes such as time, date, alarm, and chronograph.

3.2. Chronograph Function

This watch includes a chronograph feature for timing events. To use the chronograph:

1. Enter chronograph mode by pressing the 'MODE' button until 'CHR' or 'STOPWATCH' appears on the display.
2. Press the 'START/STOP' button to begin timing.
3. Press 'START/STOP' again to pause or stop the timer.
4. Press the 'RESET' button to clear the chronograph to zero.



Image 3.1: Watch face displaying chronograph function.

3.3. Water Resistance

The watch is water-resistant to 100 meters (328 feet). This means it can withstand splashes, rain, and brief immersion in water. It is suitable for swimming and snorkeling but **not** for scuba diving or high-impact water sports. Do not operate buttons underwater.

3.4. Shock Resistance

The Timex UFC Core Shock watch is designed with shock resistance to withstand impacts from daily activities and sports. While durable, extreme impacts should still be avoided to preserve the watch's integrity.



Image 3.2: Watch design emphasizing shock resistance.

4. Maintenance

4.1. Cleaning

Clean your watch regularly with a soft, damp cloth. For resin straps, mild soap and water can be used. Avoid harsh chemicals or abrasive materials that could damage the watch case or strap.

4.2. Battery Replacement

The watch uses one Lithium Metal battery. When the display dims or stops functioning, the battery may need replacement. It is recommended to have battery replacement performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

4.3. Acrylic Lens Care

The watch features an acrylic lens. Acrylic is prone to scratching. Avoid contact with sharp objects and abrasive surfaces. Minor scratches can sometimes be buffed out with specialized acrylic polish.

4.4. Water Resistance Preservation

To maintain water resistance, ensure the watch crown and buttons are fully pushed in. Avoid exposing the watch to extreme temperature changes, which can affect the seals. Do not open the watch case yourself, as this will compromise its water resistance.



Image 4.1: Back view of the watch, showing the strap attachment.



Image 4.2: Close-up of the watch case back, detailing specifications like water resistance.

5. Troubleshooting

5.1. Watch Not Functioning

- **Check Battery:** If the display is blank or dim, the battery may be depleted. Refer to Section 4.2 for battery replacement.
- **Reset:** Some digital watches have a small reset button (often recessed) that can be pressed with a pointed object (e.g., a paperclip) to restart the watch. Consult the full manual if available for exact location.

5.2. Incorrect Time/Date

- **Re-set Time:** Follow the instructions in Section 2.2 to re-set the time and date.
- **Time Zone:** Ensure the correct time zone is selected if your watch has this feature.

5.3. Water Inside Watch

If moisture appears inside the watch, immediately take it to a qualified watch repair center. Do not attempt to dry it yourself, as this can cause further damage.

6. Specifications

Feature	Detail
Model Number	TW4B27500JT
Brand	Timex
Case Diameter	45 Millimeters
Case Thickness	10 Millimeters
Case Material	Resin
Band Material	Resin
Band Length	8 Inches
Band Width	0.87 Inches
Clasp Type	Buckle
Crystal Type	Acrylic
Display Type	Digital
Movement Type	Quartz
Water Resistance Depth	100 Meters (328 Feet)
Power Source	Battery Powered (1 Lithium Metal battery included)
Additional Features	Chronograph, Shock Resistant
Item Weight	250 Grams (8.82 ounces)

7. Warranty and Support

7.1. Limited Warranty

Your Timex UFC Men's Core Shock watch is covered by a limited warranty. Details regarding the duration and terms of this warranty are typically included with your purchase documentation or can be found on the official Timex website. This warranty generally covers manufacturing defects but does not cover damage resulting from improper use, accidents, or unauthorized repairs.

7.2. Customer Support

For further assistance, technical support, or warranty claims, please contact Timex customer service. You can find contact information and additional resources on the official Timex website: www.timex.com.



Image 7.1: Timex UFC Official Watch Partner branding.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question