## BrilliantHouse N28

# BrilliantHouse 16GB Digital Voice Recorder User Manual

Model: N28

## Introduction

This manual provides comprehensive instructions for the operation and maintenance of your BrilliantHouse 16GB Digital Voice Recorder. This device is designed for high-quality audio capture in various environments, offering features such as voice-activated recording, password protection, and versatile file management.

The BrilliantHouse digital voice recorder is UPDATED with 1536KBPS quality and a User-Friendly System. Features include a portable design, one-click recording, A-B repeat, password protection, voice-activated recording, USB transmission, and MP3 function.




Image: Front and side view of the BrilliantHouse 16GB Digital Voice Recorder, showcasing its compact design and control buttons.

## What's in the Box

Your BrilliantHouse Digital Voice Recorder package includes the following items:

- 1 x voice recorder
- 1 x earphone
- 1 x usb cable
- 1 x microphone
- 1 x telephone adapter




Image: The digital voice recorder along with its included accessories: earphones, microphone, telephone adapter, and USB cable.

## Setup

1. **Charging the Device:** Connect the voice recorder to a computer or a USB power adapter using the provided USB cable. The device will indicate charging status on its screen.
2. **Power On/Off:** Locate the power switch on the side of the device. Slide it to the "ON" position to power on. Slide to "OFF" to power off.
3. **Initial Setup:** Upon first power-on, you may be prompted to set the language and time. Navigate using the control buttons and confirm your selections.
4. **Connecting Accessories:**
    - Insert the earphones into the 3.5mm headphone jack for private playback.

- Connect the external microphone to the microphone input jack for enhanced audio capture.
- Use the telephone adapter for recording phone conversations (requires specific setup, refer to advanced features).




Image: The voice recorder connected to a laptop via its USB cable, illustrating the charging and data transmission capability.

## Operating Instructions

### Basic Recording

1. **One-Click Recording:** To start recording, slide the REC button upwards. The recording indicator light will illuminate.
2. **Saving a Recording:** To save the current recording, slide the SAVE button downwards. The device will confirm "Saved!".

3. **Pausing/Resuming Recording:** During recording, press the PLAY/PAUSE button to pause. Press it again to resume.




Image: A visual guide highlighting the REC button for recording, the SAVE button for saving, and the power switch for turning the device on.

## Voice Activated Recording (VAR)

In VAR mode, the recorder automatically starts recording when sound is detected and pauses when there is silence, optimizing storage space and recording time.

1. **Activating VAR:** Navigate to the "Record Settings" in the system menu and select "AVR mode" (Automatic Voice Recording).
2. **Adjusting Sensitivity:** You can set the voice decibel level at 5 different levels to suit various environments, ensuring optimal voice detection.




Image: The voice recorder's screen displaying recording information, with an illustration of a microphone and sound waves, indicating the voice-activated recording function.

## Playback

1. **Playing Recordings:** From the main menu, select "Record" to view your saved files. Use the navigation buttons to select a file and press PLAY/PAUSE to begin playback.
2. **A-B Repeat:** During playback, press the A-B repeat button to mark the start point (A). Press it again to mark the end point (B). The device will loop playback between points A and B.
3. **Fast Forward/Rewind:** Use the fast forward and rewind buttons during playback to quickly navigate through the audio.

## Password Protection

To protect your recordings, you can set a password for the device.

1. **Setting Password:** Access the system settings menu and locate the "Password Protection" option. Follow the on-screen prompts to set your desired password.
2. **Disabling Password:** You can disable the password protection through the same menu if no longer required.




Image: The voice recorder's screen showing the password protection feature, with two lock icons indicating security.

## Features Overview

- **High-Quality Recording:** Captures premium 1536KBPS audio quality with a dynamic noise-canceling microphone.
- **Long Battery Life:** Records continuously for over 30 hours and plays for 12 to 20 hours on a full battery.
- **MP3 Functionality:** Supports recording in MP3 or WAV format, and can also function as an MP3 player for music playback.
- **USB Connectivity:** Easily link to a computer for data transfer and editing while simultaneously charging the device.
- **Compact and Portable:** Tiny and fits into almost any pocket, making it ideal for on-the-go use.
- **Telephone Recording:** Includes a function for recording telephone conversations with the provided adapter.

## Maintenance

To ensure the longevity and optimal performance of your BrilliantHouse Digital Voice Recorder, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Handling:** Handle the device with care to prevent drops or impacts, which can damage internal components or the screen.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Device does not power on. | Low battery; Power switch in OFF position. | Charge the device fully; Ensure power switch is in ON position. |
| Cannot record. | Memory full; Incorrect recording mode; Device locked. | Delete old files to free space; Check recording settings; Unlock device if password protected. |
| Poor audio quality during playback. | Low recording bitrate; External interference; Speaker/earphone issue. | Adjust recording quality settings (e.g., to 1536KBPS); Record in a quieter environment; Test with different earphones or use built-in speaker. |
| Device not recognized by computer. | Faulty USB cable; Driver issue; Incorrect connection. | Try a different USB cable; Restart computer and device; Ensure proper connection. |

## Specifications

- **Brand:** BrilliantHouse
- **Model:** N28
- **Memory Storage Capacity:** 16 GB
- **Recording Quality:** Up to 1536KBPS
- **Recording Formats:** MP3, WAV
- **Battery Life (Recording):** Up to 30 hours continuous recording
- **Battery Life (Playback):** 12 to 20 hours
- **Product Dimensions:** 3.3 x 1.4 x 0.55 inches (0.6"D x 1.3"W x 3.3"H)
- **Item Weight:** 1.16 ounces (33 Grams)

- **Hardware Interface:** USB
- **Microphone Form Factor:** Built-In
- **Headphones Jack:** 3.5 millimeters
- **Compatible Devices:** Laptop, Earphone, Personal Computer, Tablet

## Warranty and Support

BrilliantHouse is committed to providing excellent customer support. While specific warranty periods may vary by region or retailer, we offer dedicated assistance for any issues you may encounter with your device.

- **Customer Support:** For technical assistance or inquiries, please contact our support team via email. We offer 24/7 online email support.
- **Trouble Resolution:** In cases of device malfunction, BrilliantHouse may offer a "Get your money without return" policy, ensuring a hassle-free resolution.
- **Online Resources:** Refer to the online instructional video mentioned in the product accessories for additional guidance and troubleshooting tips.

© 2025 BrilliantHouse. All rights reserved.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

## Answered questions about this manual

**Why is my BrilliantHouse 16GB Digital Voice Recorder (Model N28) not being recognized by any computer even though it shows it is charging?**

If your BrilliantHouse N28 recorder is charging but not appearing as a drive on your computer, please try the following troubleshooting steps based on the manual and common device behavior:Check the Power Switch: Ensure...

**Read full answer**