Macook CA-Mini RC

Macook Mini Rice Cooker User Manual

Model: CA-Mini RC

Introduction

Thank you for choosing the Macook Mini Rice Cooker. This compact and versatile appliance is designed to simplify your meal preparation, perfect for individuals, students, campers, or small families. It features one-touch operation, an automatic keep-warm function, and a non-stick inner pot for easy cleaning. Beyond rice, it can also prepare soups, oatmeal, pasta, vegetables, and stews.



The Macook Mini Rice Cooker in white, a compact and efficient kitchen appliance.

Included Components

- Rice Cooker Unit
- Removable Nonstick Inner Pot

- Rice Spatula
- Measuring Cup
- Power Cord
- User Manual (this document)

Specifications

Feature	Detail
Brand	Macook
Model Name	mini rice cooker, small rice cooker
Capacity	1-1.5 Cups Uncooked (3 Cups Cooked) / 0.3L
Product Dimensions	6"D x 6"W x 7"H
Power Source	Corded Electric
Product Care Instructions	Dishwasher Safe (inner pot)
Color	White and Grey
Special Features	Portable, One-Touch Operation, Removable Bowl, Non-Stick
Material	Aluminum (inner pot)
Wattage	200 watts
Voltage	120 Volts



The compact dimensions of the rice cooker make it ideal for small spaces.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the removable inner pot, lid, and accessories (spatula, measuring cup) with warm, soapy water. Rinse thoroughly and dry. The inner pot is dishwasher safe.
3. **Placement:** Place the rice cooker on a stable, flat, heat-resistant surface, away from direct sunlight or heat sources. Ensure adequate ventilation around the unit.
4. **Connect Power:** Insert the power cord into the rice cooker's power inlet, then plug the other end into a standard 120V electrical outlet.

Operating Instructions

Cooking Rice

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of uncooked rice. The cooker can handle 1 to 1.5 cups of uncooked rice.
2. **Rinse Rice (Optional but Recommended):** Rinse the rice under cold water until the water runs clear. This helps remove excess starch and can improve rice texture.
3. **Add Rice to Inner Pot:** Place the rinsed rice into the removable non-stick inner pot.
4. **Add Water:** Add water according to the markings inside the inner pot. For 1 cup of uncooked rice, fill water up to the "1 CUP" line. For 1.5 cups, fill up to the "1.5 CUP" line. Adjust water quantity based on desired rice texture (less water for firmer rice, more for softer).
5. **Place Inner Pot:** Carefully place the inner pot into the main rice cooker unit. Ensure it sits properly.

6. **Close Lid:** Close the lid securely.
7. **Start Cooking:** Press the "COOK" switch down. The "COOK" indicator light (red) will illuminate, indicating that cooking has started.



The simple one-touch switch for Cook and Warm functions.

8. **Automatic Keep Warm:** Once the rice is cooked, the cooker will automatically switch to the "WARM" mode, and the "WARM" indicator light (yellow) will illuminate. This prevents overcooking and keeps the rice warm until serving.
9. **Resting Period:** For best results, allow the rice to rest in the "WARM" mode for 10-15 minutes after cooking is complete. This allows the steam to distribute evenly, resulting in fluffier rice.
10. **Serve:** Open the lid carefully, avoiding steam. Use the provided spatula to fluff the rice and serve.

Other Uses

The Macook Mini Rice Cooker is versatile and can be used for more than just rice:

- **Oatmeal:** Prepare single servings of oatmeal for a quick breakfast.
- **Soups/Broths:** Ideal for heating or preparing small portions of soup or broth.
- **Pasta/Noodles:** Cook small amounts of pasta or instant noodles.
- **Steamed Vegetables:** Use the inner pot to steam vegetables (ensure adequate water for steaming).



The rice cooker's multi-functionality allows for various dishes beyond just rice.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your rice cooker.

1. **Unplug:** Always unplug the rice cooker from the power outlet and allow it to cool completely before cleaning.
2. **Remove Inner Pot and Lid:** Take out the removable inner pot and the detachable inner lid.
3. **Wash Inner Pot:** The aluminum inner pot with non-stick coating can be washed by hand with warm, soapy water and a soft sponge, or placed in the dishwasher for convenience. Avoid abrasive cleaners or scouring pads that could damage the non-stick surface.



The non-stick inner pot is easy to clean by hand.

4. **Clean Outer Body:** Wipe the exterior of the rice cooker with a damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Clean Lid:** Wash the detachable inner lid and the main lid with warm, soapy water. Ensure all food particles are removed from the steam vent.



The detachable inner lid simplifies the cleaning process.

6. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling and storing.

Troubleshooting

Problem	Possible Cause	Solution
Rice is too hard/undercooked	Not enough water; lid not properly sealed; rice not rested after cooking.	Add slightly more water next time; ensure lid is secure; allow 10-15 minutes resting time in "WARM" mode.
Rice is too soft/mushy	Too much water; rice not rinsed (excess starch).	Reduce water slightly next time; rinse rice thoroughly before cooking.
Rice sticking to the bottom	Not enough water; inner pot not properly cleaned; non-stick coating wear.	Ensure correct water ratio; clean inner pot thoroughly; if coating is worn, consider replacement.

Cooker does not turn on	Not plugged in; power outlet issue; switch not engaged.	Check power cord connection; test outlet with another appliance; ensure "COOK" switch is fully pressed down.

Warranty and Support

The Macook Mini Rice Cooker comes with a **1-Year Warranty** from the date of purchase, covering manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.
For service, technical assistance, or any questions regarding your product, please contact our expert technicians:
Email: mgservices@hgcooker.com



Contact information for service and support, highlighting the 1-year warranty.

© 2025 Macook. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

I need a replacement inner pot for my Macook CA-Mini RC rice cooker; who sells it?

To obtain a replacement inner pot for your Macook CA-Mini RC, you should contact the manufacturer's support team directly. The manual provides the following contact information for service, technical assistance, and parts:Email: mgservices@hgcooker.comAdditionally, since...

Read full answer