Ingersoll I12701

Ingersoll The Swing Men's Automatic Watch I12701 Instruction Manual

Model: I12701

1. Introduction

Thank you for choosing the Ingersoll The Swing Men's Automatic Watch I12701. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

2. Product Overview

The Ingersoll The Swing I12701 is an automatic mechanical watch featuring an open heart dial, day and date subdials, and a genuine leather strap. It is designed for daily wear and offers a blend of classic aesthetics with modern watchmaking.





Figure 2.1: Front view of the Ingersoll The Swing Automatic Watch I12701, showcasing the rose gold case, brown dial, and leather strap.

2.1 Key Components

- **Case:** Rose gold-tone stainless steel, 45mm diameter.
- **Dial:** Brown with an open heart window at 6 o'clock, revealing the balance wheel.
- **Crown:** Located on the right side of the case, used for winding and setting.
- **Strap:** Brown genuine leather with a tang buckle.
- **Movement:** Automatic self-winding mechanical movement.
- **Subdials:** Day indicator (left) and Date indicator (right).



Figure 2.2: Close-up view of the watch dial, highlighting the open heart mechanism, day subdial, and date subdial.

3. Setup

3.1 Unboxing

Your Ingersoll watch comes packaged in a watch box, which also contains this instruction manual. Carefully remove the watch from its packaging.

3.2 Initial Winding

As an automatic watch, the movement is powered by the motion of your wrist. However, for initial use or after a period of inactivity, manual winding is recommended to build up a power reserve.

1. Ensure the crown is in its fully pushed-in position (Position 0).
2. Rotate the crown clockwise approximately 20-30 times. This will provide sufficient power to start the watch.
3. The watch will then continue to wind itself through your natural wrist movements.



Figure 3.1: Side view of the watch, illustrating the crown for winding and setting functions.

3.3 Setting Time and Date

To set the time and date on your watch:

1. **Setting the Time:** Pull the crown out to Position 2 (farthest out). Rotate the crown to move the hands clockwise until the desired time is set. Push the crown back to Position 0 to start the watch.
2. **Setting the Date:** Pull the crown out to Position 1 (middle position). Rotate the crown clockwise to adjust the date subdial.
3. **Setting the Day:** While the crown is in Position 1, rotate the crown counter-clockwise to adjust the day subdial.
4. **Important:** Avoid setting the date or day between 9:00 PM and 3:00 AM, as this is when the watch's internal mechanisms are engaged in changing the date, and manual adjustment can cause damage. If you need to set the date/day during this period, first set the time outside this window (e.g., to 6:00 AM), adjust the date/day, then reset the time to the correct current time.

3.4 Adjusting the Strap

The genuine leather strap is equipped with a tang buckle. To adjust, simply insert the tang into the desired hole on the strap for a comfortable and secure fit. Ensure the watch is snug but not overly tight on your wrist.



Figure 3.2: View of the brown genuine leather strap and tang buckle mechanism.

4. Operating Your Watch

4.1 Automatic Movement

Your Ingersoll The Swing watch is powered by an automatic mechanical movement. This means it does not require a battery. The watch is wound by the natural motion of your arm. When worn daily, the watch should maintain its power reserve. If the watch is not worn for an extended period (typically 36-40 hours), it will stop and require manual winding as described in Section 3.2.


112701
RF
STAINLESS STEEL 316L
5ATM WATER RESISTANT
Ingersoll
29 JEWELS
AUTOMATIC



Figure 4.1: View of the transparent case back, revealing the intricate automatic mechanical movement.

4.2 Water Resistance

This watch has a water resistance rating of 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming. It is **not** suitable for diving, snorkeling, or high-impact water sports. Always ensure the crown is fully pushed in before any contact with water. Avoid operating the crown while the watch is wet or submerged.

5. Maintenance

5.1 Cleaning

To maintain the appearance of your watch:

- Wipe the case and crystal with a soft, dry, lint-free cloth.
- For the leather strap, avoid excessive moisture. If it gets wet, allow it to air dry naturally, away from direct heat.
- Do not use chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish or strap.

5.2 Storage

When not wearing your watch, store it in its original box or a watch winder to keep the movement running and maintain its power reserve. Keep it away from extreme temperatures, strong magnetic fields, and direct sunlight.

5.3 Water Resistance Care

The water resistance of your watch is not a permanent feature and may decrease over time due to wear and tear on gaskets. It is recommended to have the water resistance checked periodically by an authorized service center, especially if the watch has been exposed to water frequently or if the case has been opened.

6. Troubleshooting

- **Watch has stopped or is running slow:** This is common for automatic watches that have not been worn or manually wound. Manually wind the watch 20-30 times (Section 3.2) and wear it regularly. If the issue persists, it may require servicing.
- **Date/Day not changing correctly:** Ensure you are not attempting to set the date/day between 9:00 PM and 3:00 AM. If the issue continues, consult the warranty information for service options.
- **Condensation under the crystal:** This indicates a breach in the watch's water resistance. Immediately take the watch to an authorized service center to prevent further damage to the movement.

7. Specifications

Model Number	I12701
Movement Type	Automatic
Case Material	Stainless Steel
Case Diameter	45 Millimeters
Case Thickness	15.4 Millimeters

Band Material	Leather
Band Width	22 Millimeters
Water Resistance Depth	50 Meters (5 ATM)
Crystal Type	Mineral Glass
Additional Features	Open Dial, Day/Date Subdials
Item Weight	100 Grams

8. Warranty and Support

8.1 Warranty Information

Your Ingersoll The Swing Automatic Watch I12701 comes with a **Lifetime Warranty**. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear of the strap or crystal.

8.2 Customer Support

For warranty claims, service, or any questions regarding your Ingersoll watch, please contact Ingersoll customer support through their official website or the retailer where the watch was purchased. Please have your model number (I12701) and proof of purchase available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question