KreizyGo 81534281-eadd-4c91-9162-0ac3dc36ba19

KreizyGo Flapping Wings Sparrow Interactive Catnip Toy User Manual

Model: 81534281-eadd-4c91-9162-0ac3dc36ba19

Introduction

This manual provides comprehensive instructions for the safe and effective use of your KreizyGo Flapping Wings Sparrow Interactive Catnip Toy. Please read this guide thoroughly before initial use and retain it for future reference.

Safety Information

- Always supervise your pets during play to prevent accidental ingestion of toy parts.
- Keep the internal motor unit dry. Do not immerse the toy in water or expose it to excessive moisture.
- Ensure the toy is fully charged before its first use to ensure optimal performance.
- Discontinue use immediately if the toy becomes damaged or shows signs of wear that could pose a risk to your pet.
- This toy is designed for cats and small dogs.

Package Contents

- 1x KreizyGo Flapping Wings Sparrow Toy
- 1x USB Charging Cable
- 2x Catnip Pouches
- 1x Elastic Rope with Hook (for hanging play)

Setup

1. **Charging the Toy:**
   Locate the zipper or Velcro opening on the toy to access the internal mechanism.



Image Description: A close-up view of the toy's internal white plastic module, showing a micro-USB port and a red indicator light. A USB cable is plugged in, indicating the toy is charging.

Connect the provided USB charging cable to the toy's charging port.

Plug the other end of the USB cable into a compatible USB power source (e.g., computer, wall adapter).

The indicator light will be red during charging. It will turn green when fully charged. A full charge supports up to 260 vibrations and chirps.

2. **Inserting Catnip:**

   Open the Velcro pouch on the toy's underside.

   Insert one of the provided catnip pouches into the pouch.

   Close the Velcro securely.

3. **Activating the Toy:**

   Locate the ON/OFF switch on the internal mechanism.



Image Description: A detailed view of the toy's internal white plastic module, highlighting the ON/OFF switch and the micro-USB charging port.

Slide the switch to the "ON" position.

Your browser does not support the video tag.

Video Description: This video demonstrates the setup process, including opening the Velcro, turning on the switch, and

activating the toy by patting it. It also shows the charging process.

Operating Instructions

1. **Touch Activation:**

   Once turned on, the toy is touch-activated. When your pet touches or bats the toy, the built-in motion sensor will activate.

   The sparrow toy will flap its wings and emit realistic chirping sounds.

   If the toy stops, a gentle tap will reactivate it.

2. **Flapping Modes:**

   The toy features multiple flapping modes (e.g., Rapid, Intermittent, Normal) to maintain your pet's engagement. These modes typically cycle automatically or can be changed by repeated interaction.

   Your browser does not support the video tag.

   Video Description: This video illustrates the different flapping modes of the toy, including rapid, intermittent, and normal speeds, as a cat interacts with it.

3. **Using the Elastic Rope (Optional):**

   Attach the provided elastic rope to the loop on the top of the toy.

   Hang the toy from a suitable location, such as a cat tree or door frame, to encourage jumping, swatting, and extended play sessions.

   Your browser does not support the video tag.

   Video Description: A black cat on a cat tree actively playing with the flapping bird toy, which is suspended by an elastic rope, demonstrating interactive aerial play.

Maintenance

- **Cleaning:** The soft plush cover of the toy is washable. However, it is crucial to remove the internal motor unit before washing. The motor is not waterproof and will be damaged if exposed to water.



   Image Description: The toy is depicted partially submerged in water, illustrating that the cover is washable. A text overlay explicitly warns that the motor is not waterproof and must be removed prior to cleaning.

- **Charging:** Recharge the toy when the flapping and chirping actions become weak or cease entirely.

Troubleshooting

Issue	Solution
Toy not activating	Ensure the ON/OFF switch is in the "ON" position. Check the battery charge level and recharge if necessary.
Weak flapping/chirping	The battery may be low. Recharge the toy fully.
Toy not charging	Ensure the USB cable is securely connected to both the toy and the power source. Try a different USB port or cable.

Specifications

- **Brand:** KreizyGo
- **Model:** 81534281-eadd-4c91-9162-0ac3dc36ba19
- **Product Dimensions:** 14 x 9 x 12 cm
- **Weight:** 141.75 g
- **Battery:** 1 Lithium Ion battery (included)
- **Material:** Fur (Plush)
- **Power Source:** USB Rechargeable

Warranty and Support

For warranty information or customer support regarding your KreizyGo Flapping Wings Sparrow Interactive Catnip Toy, please contact KreizyGo customer service directly through your original purchase platform. Please have your order details and model number available for faster assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question