Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Parkside IAN 305729

Parkside LIDL IAN 305729 High-Pressure Detergent Tank with Foam Nozzle User Manual

1. Product Overview

The Parkside LIDL IAN 305729 High-Pressure Detergent Tank with Foam Nozzle is an accessory designed for use with compatible high-pressure washers, specifically the Parkside PHD 150 G4 model. This tank allows for the efficient application of cleaning detergents, car shampoos, and pre-wash foams, making it ideal for vehicle washing, terrace cleaning, and other outdoor cleaning tasks.

Its integrated foam nozzle ensures even distribution of cleaning agents, enhancing cleaning effectiveness.

2. Safety Instructions

Always observe general safety precautions when operating high-pressure cleaning equipment. This detergent tank is an accessory and should be used in conjunction with the safety guidelines provided with your high-pressure washer.

- **Read all instructions:** Before using the detergent tank, read and understand all instructions in this manual and your pressure washer's manual.
- **Use appropriate detergents:** Only use detergents specifically designed for high-pressure washers and suitable for the surface being cleaned. Follow detergent manufacturer's instructions for dilution and application.
- **Wear protective gear:** Always wear appropriate personal protective equipment, including eye protection, gloves, and suitable clothing, to prevent contact with detergents and high-pressure spray.
- **Avoid contact with skin and eyes:** Detergents can be corrosive or irritating. In case of contact, rinse immediately with plenty of water and seek medical attention if irritation persists.
- **Keep out of reach of children:** Store detergents and the tank in a secure place away from children and pets.
- **Do not modify:** Never attempt to modify the detergent tank or foam nozzle. Use only original replacement parts.
- **Check for damage:** Before each use, inspect the tank and nozzle for any signs of damage. Do not use if damaged.

3. Package Contents

Verify that all items are present upon unpacking:

- 1 x Detergent Tank (1 Litre capacity)

- 1 x Foam Nozzle attachment



Image 1: Front view of the Parkside LIDL IAN 305729 Detergent Tank with Foam Nozzle. This image shows the complete unit, including the 1-liter tank and the attached foam nozzle, ready for use.

4. Setup and Assembly

1. **Prepare the Detergent Tank:**

   Unscrew the foam nozzle attachment from the detergent tank by turning it counter-clockwise.



Image 2: Close-up view of the foam nozzle mechanism on the Parkside LIDL IAN 305729. This image highlights the connection point and adjustment dial on the nozzle.

2. **Fill with Detergent:**

   Carefully fill the detergent tank with the desired cleaning solution. Ensure you follow the detergent manufacturer's instructions for dilution ratios. Do not overfill the tank.

3. **Attach Foam Nozzle:**

   Screw the foam nozzle attachment back onto the detergent tank by turning it clockwise until securely fastened. Do not overtighten.

4. **Connect to Pressure Washer:**

   Connect the assembled detergent tank and foam nozzle directly to the spray gun of your Parkside PHD 150 G4 high-pressure washer. Ensure a secure connection to prevent leaks during operation.



Image 3: Side view of the Parkside LIDL IAN 305729 Detergent Tank with Foam Nozzle. This image illustrates the overall profile of the accessory, showing how it connects to a pressure washer gun.

5. Operating Instructions

1. **Start Pressure Washer:**

   Turn on your high-pressure washer according to its operating instructions.

2. **Adjust Foam Output:**

   The foam nozzle typically features an adjustment dial or knob to control the foam concentration or spray pattern. Rotate this dial to achieve the desired foam thickness and coverage.

3. **Apply Detergent:**

   Direct the foam nozzle towards the surface to be cleaned and press the trigger on your pressure washer gun. Apply an even layer of foam over the entire surface.

4. **Allow Dwell Time:**

   Allow the detergent foam to dwell on the surface for the time recommended by the detergent manufacturer. Do not let the foam dry on the surface.

5. **Rinse:**

   After the recommended dwell time, remove the detergent tank and foam nozzle from the pressure washer gun. Reattach a standard spray lance or nozzle and rinse the surface thoroughly with clean water, working from top to bottom.

6. Maintenance

- **Empty and Rinse Tank:** After each use, empty any remaining detergent from the tank. Fill the tank with clean water and run it through the foam nozzle to flush out any detergent residue. This prevents clogging and extends the

life of the nozzle.

- **Clean Nozzle:** If the foam output becomes inconsistent or weak, the nozzle may be clogged. Disassemble the nozzle and clean any internal components with water. A small brush or needle can be used to clear stubborn blockages.
- **Inspect Seals:** Regularly check the O-rings and seals for wear or damage. Replace them if necessary to prevent leaks.
- **Storage:** Store the detergent tank and foam nozzle in a clean, dry, and frost-free environment. Ensure the tank is empty and clean before storage.

7. Troubleshooting

Problem	Possible Cause	Solution
No foam or weak foam output	• Detergent tank empty • Nozzle clogged • Detergent too diluted or too concentrated • Air leak in connection • Nozzle adjustment incorrect	• Refill detergent tank • Clean foam nozzle • Adjust detergent concentration according to manufacturer's instructions • Check all connections for tightness • Adjust the foam nozzle dial
Leaks from connections	• Loose connection • Damaged O-ring or seal	• Tighten connections securely • Inspect and replace damaged O-rings or seals

8. Specifications

Feature	Detail
Brand	Parkside
Model Number	IAN 305729
Compatibility	Parkside PHD 150 G4 High-Pressure Washer
Tank Volume	1 Litre
Certifications	CE, CSA
Package Contents	1 x Detergent Tank with Foam Nozzle

9. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your original Parkside PHD 150 G4 high-pressure washer or contact Parkside customer service directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BD4JX5CP

More documents and user manuals: **https://manuals.plus/**