SENSYNE AB Shutter3

Sensyne 60-inch Phone Tripod and Selfie Stick Instruction Manual

Introduction

Welcome to your new Sensyne 60-inch Phone Tripod and Selfie Stick. This versatile device combines the functionality of a tripod and a selfie stick, designed to enhance your mobile photography and videography experience. Please read this manual carefully to ensure proper setup and operation.

Key Features

- **All-in-One Design:** Integrates selfie stick and tripod functionality for versatile use. Collapses to 13.5 inches for portability.
- **60-inch Telescoping Pole:** Made from premium aluminum alloy with a high-end piano baking paint process. Extends up to 60 inches for eye-level shots and aerial views.
- **360° Rotating Phone Holder:** Allows for vertical or horizontal phone positioning. Compatible with smartphones 2.3" to 3.9" in width. Features non-slip silicone pads for phone protection.
- **Multifunctional Use:** Easily switches between selfie stick and tripod modes. Ideal for video recording, group photos, vlogging, live streaming, and online meetings.
- **Removable Wireless Remote Shutter:** Bluetooth remote for hands-free photo and video capture. Stores securely in the tripod leg to prevent loss. Compatible with iOS and Android.

Setup Guide

1. Unfolding the Tripod

To transform the compact unit into a tripod, gently pull the bottom section downwards. The three legs will automatically extend outwards, forming a stable base.



Image: The Sensyne tripod in its compact form and fully extended with legs deployed.

2. Extending the Telescoping Pole

Once the tripod legs are stable, grasp the top section and pull upwards to extend the telescoping pole to your desired height. The pole consists of multiple sections that lock into place.



Image: Illustrates the adjustable height and angle of the phone holder.

3. Attaching Your Smartphone

Locate the phone holder at the top of the pole. Gently pull the spring-loaded clamp open and insert your smartphone. Ensure the phone is securely held by the non-slip silicone pads. The holder can be rotated 360° to

switch between portrait and landscape orientations.

Operating Instructions

1. Using the Wireless Remote Shutter

The wireless remote shutter is integrated into the tripod leg. To remove it, gently slide it out. To pair with your smartphone:

1. Turn on the remote by pressing and holding the button until a green light flashes.
2. Enable Bluetooth on your smartphone and search for "Y60 selfie stick" (or similar).
3. Select the device to pair. The green light will stop flashing once connected.
4. Open your phone's camera app. Press the button on the remote to capture photos or start/stop video recording.



Image: Shows the detachable remote and its Bluetooth pairing process.

2. Switching Between Modes

The device can be used as a tripod or a handheld selfie stick:

- **Tripod Mode:** Deploy the legs and extend the pole as described in the Setup Guide. Ideal for stable shots, group photos, and video calls.
- **Selfie Stick Mode:** Keep the legs folded and use the extended pole as a handheld selfie stick.
- **Handheld Mode:** Keep the legs folded and the pole retracted for a compact handheld grip.



Image: Depicts the various modes of use: selfie stick, handheld, and tripod.

Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Collapse the tripod completely and store it in a dry, cool place away from direct sunlight.
- **Remote Battery:** The remote uses a CR2 battery. Replace it when the indicator light no longer flashes or the remote fails to connect.

Troubleshooting

Remote Not Connecting:

Ensure the remote is charged (if rechargeable) or has a fresh battery. Verify Bluetooth is enabled on your phone and the remote is in pairing mode. Try unpairing and re-pairing the device in your phone's Bluetooth settings.

Tripod Instability:

Ensure all three legs are fully deployed and locked into position. Avoid extending the pole to its maximum height on uneven surfaces or in windy conditions.

Phone Not Fitting Securely:

Check that your phone's width is within the supported range (2.3" - 3.9"). Ensure the spring-loaded clamp is fully extended and gripping the phone firmly.

Specifications

Feature	Detail

Model Name	AB Shutter3
Maximum Height	60 inches (152.4 cm)
Minimum Height	12 inches
Folded Size	13.5 inches
Item Weight	12.6 ounces (358.34 Grams)
Material	Aluminum
Compatible Devices	Smartphones (2.3" - 3.9" width)
Remote Battery	1 CR2 battery (included)

Warranty and Support

For warranty information and customer support, please refer to the product packaging or contact SENSYNE customer service directly. Keep your purchase receipt for warranty claims.

© 2025 SENSYNE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question