SYLVANIA PSP953

Proscan PSP953-BLACK Portable Bluetooth Speaker User Manual

Model: PSP953 | Brand: SYLVANIA

Introduction

Thank you for purchasing the Proscan PSP953-BLACK Portable Bluetooth Speaker. This manual provides essential information for the safe and efficient operation of your new speaker. Please read it thoroughly before use and retain it for future reference.

Important Safety Information

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.
Always follow basic safety precautions when using electrical appliances, especially when children are present.

Product Overview

The Proscan PSP953-BLACK is a 3-watt portable Bluetooth speaker designed for versatile audio playback. Its waterproof design and rubber finish make it suitable for various environments, including pool and beach use. It features both Bluetooth wireless connectivity and a 3.5mm AUX input for wired connections.

Key Features:

- 3-watt mono speaker output
- Frequency response: 120 Hz to 10 kHz
- Bluetooth for wireless pairing with compatible devices
- 3.5 mm standard AUX input for wired connections
- Waterproof design
- Rechargeable battery powered
- Durable rubber finish and cloth trim

What's in the Box

- Proscan PSP953-BLACK Portable Bluetooth Speaker
- Charging Cable
- User Manual (this document)

Product Diagram and Controls





Figure 1: Front view of the Proscan PSP953-BLACK speaker. Visible controls include power, volume up/next track, volume down/previous track, play/pause, and Bluetooth pairing buttons. The speaker has a black rubberized finish and a cloth grille.





Figure 2: Side view illustrating the compact dimensions of the speaker, approximately 7.87 inches (200mm) in height and 2.95 inches (75mm) in diameter.





Figure 3: Top view of the speaker, highlighting the sturdy orange carrying loop for portability.





Figure 4: Additional side view of the speaker, emphasizing the textured cloth trim and rubberized finish.

Control Button Functions:

- **Power Button (O):** Press and hold to turn the speaker On/Off.
- **Volume Up (+):** Short press to increase volume. Long press for next track.
- **Volume Down (-):** Short press to decrease volume. Long press for previous track.
- **Play/Pause Button (►▮▮):** Press to play or pause audio.
- **Bluetooth Button (ᛒ):** Press to enter Bluetooth pairing mode.

Setup

Charging the Speaker:

1. Locate the charging port on the speaker (usually protected by a rubber flap for waterproofing).
2. Connect the provided charging cable to the speaker and a suitable USB power source (e.g., computer USB port, USB wall adapter).
3. The charging indicator light will illuminate. Once fully charged, the light may change color or turn off.
4. Ensure the rubber flap is securely closed after charging to maintain waterproofing.

Operating Instructions

Power On/Off:

- To turn on, press and hold the Power button (O) until you hear an audible indication or see an indicator light.
- To turn off, press and hold the Power button (O) again until the speaker powers down.

Bluetooth Pairing:

1. Ensure the speaker is powered on.
2. Press the Bluetooth button (ᛒ) to enter pairing mode. The Bluetooth indicator light will flash, indicating it's ready to pair.
3. On your Bluetooth-enabled device (smartphone, tablet, computer), go to the Bluetooth settings.
4. Search for available devices. You should see "PSP953" or a similar name in the list.
5. Select "PSP953" to connect. Once paired, the speaker will provide an audible confirmation, and the Bluetooth indicator light will become solid.
6. You can now play audio from your device through the speaker.

Using the AUX Input:

1. Locate the 3.5mm AUX input port on the speaker (usually protected by a rubber flap).
2. Connect one end of a 3.5mm audio cable (not included) to the speaker's AUX input.
3. Connect the other end of the audio cable to the headphone jack or audio output of your device.
4. The speaker should automatically switch to AUX mode.
5. Adjust volume on both the speaker and your connected device.
6. Ensure the rubber flap is securely closed after use to maintain waterproofing.

Maintenance

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Waterproofing:** Always ensure all port covers are securely sealed when using the speaker near water to maintain its waterproof rating.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Recharge the speaker regularly, even if not in use for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is low or dead.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker is not in pairing mode; device Bluetooth is off; speaker is already connected to another device; too far from device.	Ensure speaker is in pairing mode (flashing light); turn on Bluetooth on your device; disconnect from other devices; move speaker closer to device (within 33 feet/10 meters).
No sound or low volume.	Volume too low on speaker or device; incorrect input mode; cable not fully inserted (AUX).	Increase volume on both speaker and device; ensure correct mode (Bluetooth/AUX); check cable connection.

Problem	Possible Cause	Solution
Sound distortion.	Volume too high; weak Bluetooth signal.	Lower volume; move speaker closer to the Bluetooth device.

Specifications

- **Model Name:** Proscan PSP953-BLACK 3-Watt Portable Bluetooth Waterproof Rechargeable Speaker with Rubber Finish and Cloth Trim (Black)
- **Brand:** SYLVANIA
- **Power Output:** 3 Watts
- **Speaker Type:** Mono speaker
- **Frequency Response:** 120 Hz to 10 kHz
- **Connectivity:** Bluetooth, 3.5mm AUX input
- **Wireless Communication Technology:** Bluetooth
- **Power Source:** Battery Powered (1 Lithium Ion battery included)
- **Waterproof:** Yes
- **Material:** Plastic, Rubber Finish, Cloth Trim
- **Color:** Black
- **Item Dimensions (LxWxH):** 2.75 x 8.25 x 4.05 inches
- **Item Package Dimensions (LxWxH):** 8.86 x 4.61 x 3.46 inches
- **Package Weight:** 0.62 Kilograms
- **Controller Type:** Button
- **Recommended Uses:** Music, Pool, Beach
- **Manufacturer:** CURTIS INTERNATIONAL LTD
- **UPC:** 058465824556

Warranty and Support

This product comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase or visit the SYLVANIA website for detailed warranty information and terms. For technical support or customer service, please contact CURTIS INTERNATIONAL LTD, the manufacturer.
Manufacturer: CURTIS INTERNATIONAL LTD
Brand Store: SYLVANIA Store on Amazon

© 2023 SYLVANIA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question