Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aresrora DW21

Aresrora DW21 Retro Bluetooth Speaker User Manual

Model: DW21

1. Introduction

Thank you for purchasing the Aresrora DW21 Retro Bluetooth Speaker. This manual provides detailed instructions for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

2. Product Overview

The Aresrora DW21 is a portable retro-designed Bluetooth speaker featuring advanced Bluetooth 5.0 technology for stable and efficient wireless connectivity. It supports multiple playback modes including TWS pairing for stereo sound, TF card, USB disk, and AUX input. Its compact size and durable construction make it ideal for various indoor and outdoor settings.

Key Features:

- **Bluetooth 5.0 Technology:** Ensures stable and fast connection with compatible devices.
- **TWS Pairing Support:** Connect two DW21 speakers for a true stereo audio experience.
- **Multiple Playback Modes:** Supports Bluetooth, TF Card, USB disk, and 3.5mm AUX input.
- **Crystal Clear Sound:** Delivers enhanced bass, clear mid-range, and high-frequency sound with minimal distortion.
- **Portable Design:** Lightweight and compact with a convenient handle for easy carrying.
- **Long Battery Life:** Built-in 500mAh rechargeable battery provides approximately 5 hours of playtime.

Product Dimensions and Weight:

- Dimensions: 2.5"D x 4.1"W x 3"H
- Item Weight: 8 Ounces
- Material: ABS + Silica Gel



Image: Front view of the Aresrora DW21 speaker with its dimensions clearly marked.

3. What's in the Box

- 1 x Aresrora DW21 Retro Bluetooth Speaker
- 1 x Type-C Charging Cable
- 1 x AUX Line
- 1 x Instruction Manual

4. Controls and Ports

Familiarize yourself with the speaker's controls and connection ports:



Image: Labeled diagram of the speaker's front controls and rear connection ports.

Front Controls:

- **Volume Dial:** Rotate to adjust the audio volume.
- **Power On/Off / Play/Pause Button:** Long press to power on/off. Short press to play or pause music.
- **Previous Song Button:** Short press to go to the previous song. Long press for TWS pairing.
- **Next Song Button:** Short press to go to the next song. Long press to switch between modes (Receiver Tone, Bluetooth, AUX).

Rear Ports:

- **Type-C Charging Interface:** For charging the speaker.
- **TF Card Slot:** Insert a TF card for direct music playback.
- **USB Interface:** Insert a USB disk for direct music playback.
- **AUX Interface:** Connect external audio devices using the provided 3.5mm AUX cable.

5. Setup and Initial Use

5.1 Charging the Speaker

1. Connect the provided Type-C charging cable to the Type-C port on the back of the speaker.
2. Connect the other end of the cable to a USB power adapter (DC 5V 1A, not included) or a computer's USB port.
3. The charging indicator light will illuminate during charging and turn off once fully charged.
4. A full charge takes approximately 1.5 hours and provides about 5 hours of playtime (varies by volume).



Image: Visual representation of the speaker's battery capacity and playtime.

5.2 Powering On/Off

- **To Power On:** Long press the Power On/Off / Play/Pause button until you hear a power-on prompt.
- **To Power Off:** Long press the Power On/Off / Play/Pause button until you hear a power-off prompt.

6. Operating Instructions

6.1 Bluetooth Pairing



Image: Representation of Bluetooth 5.0 technology.

1. Ensure the speaker is powered on and in Bluetooth mode (indicated by a voice prompt or LED). If not, long press the Next Song button to cycle modes until Bluetooth mode is activated.
2. Enable Bluetooth on your device (smartphone, tablet, laptop, etc.).
3. Search for "DW21" in your device's Bluetooth settings and select it to pair.
4. Once successfully paired, you will hear a confirmation sound.
5. The speaker has a maximum Bluetooth range of 33 feet (10 meters).



Image: The speaker demonstrating compatibility with various Bluetooth-enabled devices.

6.2 TWS (True Wireless Stereo) Pairing

To achieve a true stereo sound experience, you can pair two Aresrora DW21 speakers together:



Image: Two speakers paired using TWS technology for stereo audio.

1. Ensure both DW21 speakers are powered on and not connected to any other Bluetooth device.
2. Long press the "Previous Song" button on one of the speakers. It will enter TWS pairing mode.
3. The speakers will automatically search for and pair with each other. You will hear a confirmation tone once connected.
4. Once TWS is established, connect your device to one of the speakers via Bluetooth as described in section 6.1. Both speakers will then play audio in stereo.

6.3 TF Card / USB Disk Playback



Image: The speaker's rear ports for TF card, USB, and AUX connections.

1. Insert a TF card or USB disk containing audio files into the respective slot on the back of the speaker.
2. The speaker will automatically switch to TF Card or USB mode and begin playing music.
3. Use the Previous/Next Song buttons to navigate tracks and the Volume Dial to adjust volume.

6.4 AUX Input

1. Connect one end of the provided 3.5mm AUX cable to the AUX port on the back of the speaker.
2. Connect the other end to the audio output jack of your external device (e.g., desktop computer, MP3 player).
3. The speaker will automatically switch to AUX mode.
4. Control playback and volume from your connected device or use the speaker's volume dial.

6.5 Answering Calls

If your speaker is connected to a smartphone via Bluetooth and a call comes in:

- **Short press the Power On/Off / Play/Pause button** to answer the call.

- **Short press the Power On/Off / Play/Pause button again** to end the call.

7. Maintenance

- Keep the speaker away from water, moisture, and extreme temperatures. The speaker is not waterproof.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid dropping or subjecting the speaker to strong impacts.
- When not in use for extended periods, charge the speaker at least once every three months to maintain battery health.

8. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker for at least 1.5 hours.
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from device.	Ensure speaker is in Bluetooth mode. Turn device Bluetooth off/on. Move speaker closer to device (within 33 ft).
No sound or low volume.	Volume too low on speaker or device; incorrect mode selected.	Adjust volume dial on speaker and device. Ensure correct playback mode (Bluetooth, TF, USB, AUX) is selected.
TWS pairing fails.	Speakers already connected to another device; not in TWS pairing mode.	Ensure both speakers are disconnected from other devices. Long press the "Previous Song" button on one speaker to initiate TWS pairing.

9. Specifications

Feature	Detail
Model Name	DW21
Material	ABS + Silica Gel
Speaker Size	45 Millimeters
Speaker Impedance	4 Ohms
Speaker Maximum Output Power	3 Watts
Battery Type	1 Lithium Polymer (included)
Battery Capacity	500 Milliamp Hours
Charging Time	1.5 Hours
Playtime	Approx. 5 hours (varies by volume)
Input Voltage	DC 5V 1A

Feature	Detail
Connectivity Technology	Bluetooth 5.0, AUX, TF Card, USB
Wireless Communication Technology	Bluetooth
Maximum Range	33 Feet / 10 Meters
Signal-to-Noise Ratio	75 dB
Control Method	Touch (buttons) and Rotary (volume dial)
Is Waterproof	False (Not Water Resistant)

10. Official Product Video

Watch this official product video from Aresrora Direct for a detailed overview of the speaker's features and operation.

Your browser does not support the video tag.

Video: "What the product is really like" by Aresrora Direct, demonstrating the speaker's functionality.

11. Warranty and Support

This product is covered by a Seller Warranty. For any issues, questions, or support needs, please contact Aresrora Direct through your purchase platform. Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BF4T94K9

More documents and user manuals: **https://manuals.plus/**