Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

740919961695

Generic 1.8L Multifunctional Electric Hot Pot User Manual

Model: 740919961695

1. Introduction

Thank you for purchasing the Generic 1.8L Multifunctional Electric Hot Pot. This versatile appliance is designed to simplify your cooking experience, allowing you to fry, stir-fry, boil, steam, and prepare hot pot dishes with ease. With its compact design and user-friendly features, it is ideal for individuals or small families. Please read this manual thoroughly before first use to ensure safe operation and optimal performance.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance features **double temperature control protection**, including **overheating protection** and an **anti-drying function**. If the pot overheats or runs dry, it will automatically power off for safety.
- Ensure the power outlet voltage matches the appliance's requirements (110V).

3. Product Overview

Familiarize yourself with the components of your electric hot pot.

3.1 Package Contents



Image: Package Contents. This image displays the accessories included with your electric hot pot: a pair of chopsticks, a spoon, a cooking shovel, a small bowl, and a cleaning cloth.

- Electric Hot Pot with Handle
- Glass Lid
- Power Cord
- Stainless Steel Steamer
- Chopsticks
- Spoon
- Shovel
- Bowl
- Cleaning Cloth

3.2 Product Features and Components



Image: Product Dimensions. This image shows the overall dimensions of the electric hot pot, indicating a diameter of 17cm (6.69 inches), a height of 13.5cm (5.31 inches), a handle length of 10cm (3.93 inches), and a total capacity of 1.8 liters.

- **1.8L Capacity:** Suitable for 1-2 people.
- **Non-Stick Coating:** Food-grade Teflon non-stick interior for easy cooking and cleaning.
- **PP Outer Layer:** The exterior shell is made of PP material, providing heat insulation and anti-scalding protection.
- **Visible Glass Lid:** Allows you to monitor cooking progress without lifting the lid.
- **Anti-Scalding Handle:** Ergonomically designed for a comfortable and safe grip.
- **Ring-Shaped Heating Tube:** Ensures food is heated fully and evenly for efficient cooking.
- **Separate Power Cord:** Detachable power cord for convenience and easier cleaning.

3.3 Controls



Image: Power Control Switch. This image highlights the push-button control switch located on the handle, offering two power settings: 225W for low temperature and 450W for high temperature cooking.

The electric hot pot features a simple push-button control on the handle with two power settings:

- **I (225W):** Low temperature setting, suitable for simmering, keeping warm, or gentle cooking.
- **II (450W):** High temperature setting, ideal for rapid boiling, frying, or stir-frying.



Image: Non-Stick Coating. This image illustrates the Teflon non-stick coating inside the pot, emphasizing its easy-to-clean surface as water is shown being poured out.



Image: Design Details. This composite image highlights key design features: the acrylic anti-scalding knob on the lid, the transparent glass lid itself, the main anti-scalding handle of the pot, and the detachable power cord for convenience.



Image: Steamer and Pot Material. This image shows the stainless steel steamer insert, highlighting its durability, and a close-up of the pot's exterior, indicating it is made of PP material for heat insulation and anti-scalding properties.

4. Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wash the pot interior, glass lid, and steamer with warm soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the pot with a damp cloth. Do not immerse the main pot body in water.
3. **Placement:** Place the electric hot pot on a stable, flat, heat-resistant surface away from flammable materials. Ensure there is adequate ventilation around the appliance.
4. **Power Connection:** Insert the power cord into the appliance's power inlet, then plug the other end into a standard 110V electrical outlet.

5. Operating Instructions

Your multifunctional electric hot pot can be used for various cooking methods.

5.1 Basic Operation

1. Ensure the pot is clean and dry before adding ingredients.
2. Add desired ingredients (water, oil, food items) to the pot. Do not overfill; ensure contents are below the maximum fill line.
3. Plug the power cord into a wall outlet.
4. Select your desired power setting (I for 225W, II for 450W) using the switch on the handle. The indicator light will illuminate.
5. Once cooking is complete, switch the power to 'O' (off) and unplug the appliance from the wall outlet.

5.2 Cooking Modes



Image: Wide Range of Uses. This image demonstrates the versatility of the 1.8L electric hot pot, showcasing its ability to prepare hot pot, general cooking, stir-fries, stews, grilled items, and noodles.

- **Boiling/Hot Pot:** Add water or broth and desired ingredients. Use setting II for rapid boiling, then switch to setting I for

simmering.

- **Frying/Stir-Frying:** Add a small amount of oil. Use setting II for quick heating. Add ingredients and stir as needed. The non-stick coating helps prevent food from sticking.
- **Steaming:** Pour water into the main pot (do not exceed the steamer base). Place the stainless steel steamer with food inside. Cover with the glass lid. Use setting II to bring water to a boil, then adjust as needed.



Image: Steaming in Action. This image shows the stainless steel steamer being used to steam buns, illustrating the efficient design that allows for steaming on top while boiling or cooking can occur in the main pot below.

Tip: For optimal cooking, ensure the glass lid is properly seated to retain heat and moisture.

6. Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your electric hot pot.

1. **Always Unplug:** Before cleaning, ensure the appliance is turned off and unplugged from the power outlet. Allow it to cool down completely.

2. **Interior Cleaning:** Wash the non-stick interior with warm, soapy water using a soft sponge or the provided cleaning cloth. Do not use abrasive scrubbers or metal utensils, as they can damage the non-stick coating. Rinse thoroughly and dry.
3. **Exterior Cleaning:** Wipe the exterior of the pot with a damp cloth. Do not immerse the main pot body in water or any other liquid.
4. **Lid and Steamer:** The glass lid and stainless steel steamer can be washed with warm soapy water, rinsed, and dried.
5. **Storage:** Ensure all parts are completely dry before storing. Store the appliance in a cool, dry place.

7. Troubleshooting

If you encounter any issues, please refer to the following common problems and solutions.

- **Appliance does not turn on:**
  - Check if the power cord is securely plugged into both the appliance and the wall outlet.
  - Ensure the wall outlet is functioning (test with another appliance).
  - Verify the power switch on the handle is set to 'I' or 'II'.
- **Food sticks to the bottom:**
  - Ensure you are using a small amount of oil when frying or stir-frying.
  - Avoid using metal utensils that can scratch the non-stick coating.
  - Ensure the pot is clean and free of residue from previous cooking.
- **Appliance stops heating unexpectedly:**
  - The appliance has overheating protection and an anti-drying function. If the pot becomes too hot or runs out of liquid, it will automatically shut off. Unplug the unit, allow it to cool down completely, and then check for sufficient liquid before restarting.



Image: Safety Protection. This image visually explains the double temperature control protection, indicating that the pot will automatically power off in cases of high temperature or lack of water to prevent damage and ensure user safety.

8. Specifications

Feature	Specification
Brand	Generic
Model Number	740919961695
Capacity	1.8 Liters
Material	Stainless Steel (Steamer), PP (Outer Shell), Teflon (Inner Coating)
Color	Green
Product Dimensions (D x W x H)	6.69"D x 10.62"W x 5.31"H

Feature	Specification
Rated Power	225W / 450W (Dual Power)
Voltage	110 Volts
Control Method	Push Button
Item Weight	1.8 pounds

9. Warranty and Support

This product comes with a standard manufacturer's warranty. Please refer to the documentation provided at the time of purchase for specific warranty terms and conditions. For any product support, technical assistance, or warranty claims, please contact the seller or retailer from whom you purchased this product. Keep your proof of purchase for warranty validation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question