ALLIMITY QYSY-YKR-L-101E-102E-QYSY

ALLIMITY Air Conditioning Remote Control User Manual

Model: QYSY-YKR-L-101E-102E-QYSY
Brand: ALLIMITY

1. Introduction

This user manual provides comprehensive instructions for the ALLIMITY Air Conditioning Remote Control, Model QYSY-YKR-L-101E-102E-QYSY. This remote control is designed to be compatible with a wide range of air conditioning units, offering a direct replacement for many original remotes without requiring any programming. Simply insert the batteries, and the remote is ready for use.

2. Product Overview

The ALLIMITY Air Conditioning Remote Control features an intuitive layout with clearly labeled buttons and a digital display for easy operation. It is designed to replicate the full functionality of your original air conditioner remote.





Figure 2.1: Front view of the remote control, displaying the screen and primary function buttons.



Figure 2.2: Remote control with the battery compartment open, showing battery placement and secondary function buttons.

Button Functions:

- **ON/OFF:** Powers the air conditioner on or off.

- **MODE:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **SPEED:** Adjusts fan speed (e.g., Low, Medium, High, Auto).
- **Temperature Up/Down (▲/▼):** Increases or decreases the set temperature.
- **TURBO:** Activates rapid cooling or heating.
- **HEALTH:** Engages health-related functions (if available on AC unit).
- **SILENCE:** Reduces fan noise for quieter operation.
- **SLEEP:** Activates sleep mode for comfortable overnight operation.
- **TIMER:** Sets the timer for automatic on/off operations.
- **iFEEL:** Activates the 'I Feel' function, sensing temperature at the remote's location.
- **DISPLAY:** Toggles the display on the air conditioner unit.
- **ICLEAN:** Initiates the self-cleaning function (if available on AC unit).
- **Anti-Fungus:** Activates anti-fungus drying function (if available on AC unit).
- **ELE.H:** Electric Heating function.
- **ECO:** Activates energy-saving mode.
- **SPOT SWING:** Controls specific swing direction.
- **COOL:** Directly selects cooling mode.
- **HEAT:** Directly selects heating mode.
- **SWING ↑↓:** Controls vertical louver swing.
- **SWING ←→:** Controls horizontal louver swing.

3. Setup

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

The remote control is now ready for use. No programming is required.

4. Operating Instructions

To operate your air conditioner using this remote control, point the remote directly at the air conditioner's receiver. Ensure there are no obstructions between the remote and the unit.

Basic Operation:

- **Power On/Off:** Press the `ON/OFF` button once to turn the unit on, and again to turn it off.
- **Selecting Mode:** Press the `MODE` button repeatedly to cycle through available modes (e.g., Cool, Heat, Fan, Dry, Auto). The selected mode will typically be displayed on the remote's screen.
- **Adjusting Temperature:** Use the `▲` (Up) and `▼` (Down) buttons to set your desired temperature.
- **Fan Speed:** Press the `SPEED` button to adjust the fan speed.

Advanced Functions:

- **Timer Function:** Press the `TIMER` button to set a scheduled time for the air conditioner to turn on or off.

Follow the on-screen prompts to adjust the time.

- **Sleep Mode:** Activate `SLEEP` mode for optimized temperature and fan settings during sleep.
- **Swing Function:** Use the `SWING` buttons to control the direction of the air flow.

5. Maintenance

Cleaning the Remote:

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote's electronics or finish.

Battery Replacement:

Replace batteries when the remote's display becomes dim or the remote fails to operate the air conditioner consistently. Always replace both batteries at the same time with new alkaline batteries of the correct type (AAA). Do not mix old and new batteries, or different types of batteries.

Storage:

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

6. Troubleshooting

Common Issues and Solutions:

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with new ones.
  - Ensure there is a clear line of sight between the remote and the air conditioner's receiver.
- **Limited range:**
  - Replace batteries, as low battery power can reduce signal strength.
  - Ensure no strong light sources (like direct sunlight) are interfering with the infrared signal.
- **Specific functions not working:**
  - Some advanced functions may only be available if supported by your specific air conditioner model. Refer to your AC unit's manual.

7. Specifications

Model Number	QYSY-YKR-L-101E-102E-QYSY
Brand	ALLIMITY
Product Dimensions	4 x 12 x 0.3 cm
Item Weight	0.05 Kilograms (50 g)
Connectivity Technology	Infrared

Controller Type	Button Control
Maximum Range	10 Meters
Battery Type	Alkaline (AAA)
Special Features	Universal compatibility

8. Compatible Models

This remote control is compatible with a wide range of air conditioning units, including but not limited to the following models:

- YKR-L/101E, YKR-L/102E, YKR-L/201E, YKR-L102E, YKR-L101E, YKR-L201E
- CL93568
- LSGNW50, ASW-09-JA(V2), ASW-12-JA(V2), LSGT25-S, JSGNW35, LSGT35-S, JSGNW50, LSGT50-S, JSGNW70, LSGT70-S
- RZGNC50, RZGNC70, RZGNC100, RZGNC120, RZGNC140
- MUPR-09-H8A, MUPR-12-H8A, MUPR-18-H8A, MUPR-24-H8A, MUPR-09-H9A, MUPR-12-H9A, MUPR-18-H9A, MUPR-24-H9A, MUPR-09-H5A, MUPR-12-H5A, MUPR-18-H5A, MUPR-24-H5A
- DSGNW25, DSGNW35, DSGNW50, DSGNW70
- LSGNW25, LSGNW35, JSGNW25
- RZGBK35, LSGNK25-XM, LSGNK35-XM, LSGNK50-XM
- ASW-18-QC, ASW-24-QC, AMW-09-FH, RZGBK50, RZGBK70, AMW-12-FH, AMW-18-FH
- YKR-L/103E
- LSGNC25-XM, LSGNC35-XM, LSGNC50-XM, LSGNW20
- ASW-18-JA(V2), ASW-24-JA(V2), ASW-09QC, ASW-12-QC
- RZGBK100, RZGBK120, RZGBK140
- TT34EXC1-1232IAWPC, TA71FFUL-2432IAW, PFUVI-12WFI, PFUVO-12

This remote is designed to cover the functions of your original remote for these models.

9. Warranty and Support

For specific warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. This product is designed for reliability and ease of use. Should you encounter any issues not covered in the troubleshooting section, please consult your product vendor for further assistance.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question