Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WS 610600

WS 49-Key Electronic Synthesizer Keyboard with Microphone, Model 610600 Instruction Manual

Comprehensive guide for setup, operation, and maintenance of your WS electronic keyboard.

1. Product Overview

The WS 49-Key Electronic Synthesizer Keyboard, Model 610600, is an ideal instrument for beginners and young musicians. It offers a wide range of features to explore musical creativity, including various sounds, rhythms, and recording capabilities. This manual provides essential information to help you get started and make the most of your new instrument.



Image 1: WS 49-Key Electronic Synthesizer Keyboard with included microphone.



Image 2: Product dimensions showing the keyboard and its packaging. The keyboard measures approximately 66 cm in length.

2. Setup

Follow these steps to set up your WS 49-Key Electronic Synthesizer Keyboard:

1. **Power Supply:** The keyboard can be powered by 6 AA batteries (not included) or via the included USB cable.
    - For battery operation, open the battery compartment on the underside of the keyboard and insert 6 AA batteries, ensuring correct polarity.
    - For USB power, connect the USB cable to the keyboard's power input and to a compatible USB power adapter (not included) or a USB port on a computer.
2. **Microphone Connection:** Connect the included microphone to the designated microphone input jack on the keyboard.

Your browser does not support the video tag.

Video 1: Demonstration of connecting a microphone to a similar electronic keyboard. This video illustrates the process of plugging in the microphone for use with the instrument.

3. Operating Instructions

Familiarize yourself with the various functions of your keyboard:

- **Power On/Off:** Use the power button to turn the keyboard on or off.
- **Sound Selection:** The keyboard features 100 different instrument sounds. Use the dedicated buttons or a dial (if present) to cycle through and select your desired sound. The digital screen will display the selected sound number.
- **Rhythm Selection:** Choose from 100 built-in rhythms to accompany your playing. Adjust the tempo as needed.
- **Demo Songs:** Explore 10 pre-recorded demo songs to hear the keyboard's capabilities and for learning inspiration.
- **Percussion:** Access 5 different percussion sounds to add rhythmic elements to your music.
- **Recording Function:** Use the record function to capture your performances and the playback function to listen to them.
- **Microphone Use:** Once connected, the microphone allows you to sing along while playing the keyboard.

Your browser does not support the video tag.

Video 2: Overview of an electronic keyboard's features, including sound effects and basic operation. This video provides a general understanding of how to interact with the instrument's various functions.

Your browser does not support the video tag.

Video 3: Demonstration of a 49-key electronic keyboard, showcasing its power-on sequence, key sounds, and various control buttons. This video helps illustrate the user interface and basic functionality.

4. Maintenance

To ensure the longevity and optimal performance of your keyboard, follow these maintenance guidelines:

- **Cleaning:** Wipe the keyboard surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as they may damage the finish.
- **Storage:** When not in use, store the keyboard in a dry, cool place away from direct sunlight and extreme temperatures.
- **Battery Care:** If using batteries, remove them if the keyboard will not be used for an extended period to prevent leakage.

5. Troubleshooting

If you encounter any issues with your keyboard, refer to the following common troubleshooting tips:

- **No Power:**
  - Check if the power button is in the "ON" position.
  - If using batteries, ensure they are correctly inserted and not depleted. Replace with fresh batteries if necessary.
  - If using the USB cable, ensure it is securely connected to both the keyboard and a working power source.
- **No Sound:**
  - Verify that the volume is turned up.
  - Ensure no headphones are plugged in if you expect sound from the built-in speakers.
  - Check if a sound or rhythm is selected.
- **Microphone Not Working:**
  - Ensure the microphone is securely plugged into the correct input jack.
  - Check if the microphone has an on/off switch and that it is in the "ON" position.

6. Specifications

Feature	Detail
Brand	WS
Model Number	610600SK
Number of Keys	49
Dimensions (L x W x H)	66 x 21 x 7 cm

Weight	1.4 Kilograms
Material	Plastic
Power Source	6 AA Batteries (not included) or USB Cable (included)
Educational Value	Music learning for beginners
Recommended Age	6 - 13 years
Sounds	100
Rhythms	100
Demo Songs	10
Percussion Sounds	5
Features	Recording function, Digital screen, Microphone included

7. Warranty and Support

For warranty information and customer support, please refer to the product packaging or contact WS customer service directly. Keep your purchase receipt as proof of purchase.

© 2023 WS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BG3Q2KGL

More documents and user manuals: **https://manuals.plus/**