## Cirbic TWD002

# Cirbic TWD002 Talking Digital Watch Instruction Manual

Model: TWD002

## Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your Cirbic TWD002 Talking Digital Watch. Designed for ease of use, this watch features a large digital display and clear English voice announcements, making it ideal for individuals who are blind, visually impaired, or elderly.

## Product Overview

The Cirbic TWD002 Talking Digital Watch is equipped with four control buttons, typically located at the 2, 4, 8, and 10 o'clock positions. For the purpose of these instructions, we will refer to them as follows:

- **TIME Button (S1):** Located at the 2 o'clock position.
- **DATE Button (S2):** Located at the 4 o'clock position.
- **SET Button (S3):** Located at the 8 o'clock position.
- **RX/ALM Button (S4):** Located at the 10 o'clock position.






*Image: Front view of the Cirbic TWD002 Talking Digital Watch, displaying the time and day of the week. The watch has a silver-tone case and an expandable metal band.*






*Image: Back view of the Cirbic TWD002 Talking Digital Watch, showing the stainless steel case back with brand and manufacturing details.*




*Image: The Cirbic TWD002 Talking Digital Watch displayed next to a standard pencil, illustrating its compact size.*

## Setup and Activation

1. **Unboxing:** Carefully remove the watch from its packaging.
2. **Wearing the Watch:** The watch features a stretch band for easy placement on your wrist.
3. **Activating from 'SHIP' Mode:** If the screen displays "SHIP", hold down the **TIME Button (S1)** and **SET Button (S3)** simultaneously for approximately 5 seconds to activate the watch.
4. **Automatic Time Setting:** The watch is designed to automatically set its time at 3 AM every night.

Your browser does not support the video tag.

*Video: A quick guide demonstrating how to activate the watch from 'SHIP' mode and basic button functions.*

## Operating Instructions

### 1. Announcing Time and Date

- **To Hear the Time:** Press the **TIME Button (S1)** (2 o'clock position). The watch will announce the current time in a clear, loud North American accent.
- **To Hear the Date:** Press the **DATE Button (S2)** (4 o'clock position). The watch will announce the current date.

## 2. Setting Daily Alarm Time

1. Hold the **SET Button (S3)** (8 o'clock position) for 3 seconds until you hear "Set Alarm".
2. Press the **RX/ALM Button (S4)** (10 o'clock position) once.
3. Press the **TIME Button (S1)** repeatedly to adjust the alarm hour.
4. Press the **DATE Button (S2)** repeatedly to adjust the alarm minutes.
5. Press the **SET Button (S3)** to confirm the alarm time. The watch will announce the set alarm time.

## 3. Alarm ON/OFF

1. Hold the **SET Button (S3)** (8 o'clock position) for 3 seconds until you hear "Set Alarm".
2. Press the **SET Button (S3)** one more time. The watch will announce "Alarm ON" or "Alarm OFF".
3. Press the **RX/ALM Button (S4)** (10 o'clock position) once to toggle the alarm status (ON/OFF).
4. Press the **SET Button (S3)** to confirm the setting.

## 4. Hourly Chime ON/OFF

1. Hold the **SET Button (S3)** (8 o'clock position) for 3 seconds until you hear "Set Alarm".
2. Press the **SET Button (S3)** two more times. The watch will announce "Chime ON" or "Chime OFF".
3. Press the **RX/ALM Button (S4)** (10 o'clock position) once to toggle the chime status (ON/OFF).
4. Press the **SET Button (S3)** to confirm the setting.

## 5. Setting Time Zone

The watch supports 4 time zones: Pacific (-8), Mountain (-7), Central (-6), Eastern (-5).

1. Hold the **SET Button (S3)** (8 o'clock position) for 3 seconds until you hear "Set Alarm".
2. Press the **SET Button (S3)** three more times. The watch will announce "Time Zone Setting".
3. Press the **TIME Button (S1)** repeatedly to cycle through the available time zones.
4. Press the **SET Button (S3)** to confirm your selection.

## 6. Manual Time Setting

1. Hold the **SET Button (S3)** (8 o'clock position) for 3 seconds until you hear "Set Alarm".
2. Press the **SET Button (S3)** four more times. The watch will announce "Time Setting".
3. Press the **TIME Button (S1)** repeatedly to adjust the hour.
4. Press the **DATE Button (S2)** repeatedly to adjust the minutes.
5. Press the **SET Button (S3)** to confirm the time.

Your browser does not support the video tag.

*Video: Detailed instructions on how to set various functions of the 2117M Talking Watch, including alarm, chime, and time zone.*

## 7. Adjusting Volume

To adjust the volume, press the **TIME Button (S1)** or **DATE Button (S2)** while the time is being announced.

## Maintenance and Care

- Keep the watch clean by wiping it with a soft, dry cloth.
- Avoid exposing the watch to extreme temperatures or direct sunlight for prolonged periods.
- While durable, avoid dropping the watch or subjecting it to strong impacts.
- The watch is not specified as waterproof; avoid submerging it in water.

## Troubleshooting

- **No Sound/Voice:** Ensure the volume is not set to minimum. Check if the watch is in 'SHIP' mode and activate it if necessary.
- **Incorrect Time:** Verify the time zone setting. Allow the watch to automatically update at 3 AM, or manually set the time as per instructions.
- **Buttons Unresponsive:** Check for any debris or obstruction around the buttons. If the issue persists, contact customer support.

## Specifications

- **Model Number:** TWD002
- **Brand:** Cirbic
- **Department:** Unisex
- **Display:** Large Digital Screen
- **Voice:** Clear and loud North American accent female voice
- **Time Zones:** Pacific, Mountain, Central, Eastern (Does not work in Hawaii or Alaska time zones)
- **Automatic Time Update:** Yes, at 3 AM daily
- **Band Type:** Stretch band for easy wear
- **Dimensions:** 14.4 x 6.5 x 4.39 cm
- **Weight:** 91 g

## Warranty and Support

For any issues or inquiries, please contact Cirbic customer support. Your product is covered by Amazon.ca's 30-day right of return for many products. For exceptions and conditions, please refer to Amazon.ca's return policies.

- **Manufacturer:** Cirbic
- **Place of Business:** Cirbic Inc, Orleans, ON, K4A 3T2, Canada
- **Support Email:** support@cirbic.com

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question