Vistefly V15

Vistefly Cordless Vacuum Cleaner V15 Instruction Manual

Model: V15 | Brand: Vistefly

Introduction

The Vistefly Cordless Vacuum Cleaner V15 is designed for efficient and convenient cleaning of various surfaces. This powerful and lightweight stick vacuum features LED headlights, a touchscreen display, and a long runtime, making it suitable for everyday household cleaning, including pet hair on carpets and hard floors. This manual provides essential information for the safe and effective operation and maintenance of your Vistefly V15 vacuum cleaner.

Safety Information

Please read all safety warnings and instructions before using this appliance. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust cup and/or filters in place.
- Turn off all controls before unplugging.

- Use extra care when cleaning on stairs.
- Do not use to pick up large, hard, or sharp objects such as glass, nails, screws, or coins.

Package Contents

Upon opening the package, verify that all components are present and undamaged. The Vistefly V15 includes the following:

- Main Motor Unit with Dust Cup
- Extension Wand (Tube)
- Motorized Floor Brush with LED Headlights
- Crevice Tool
- 2-in-1 Dusting Brush
- Wall Mount Dock
- Power Adapter
- Removable Battery Pack
- Extra HEPA Filter
- Cleaning Tool
- Instruction Manual



Figure 1: Complete package contents of the Vistefly V15.

Setup

Follow these steps to assemble your Vistefly V15 vacuum cleaner:

1. **Attach the Battery:** Align the battery pack with the slot on the main motor unit and slide it in until it clicks securely into place.



Figure 2: Inserting the removable battery pack.

2. **Assemble the Main Unit:** Connect the extension wand to the main motor unit. Ensure it clicks firmly into place.



Figure 3: Assembling the main unit and extension wand.

3. **Attach the Floor Brush:** Connect the motorized floor brush to the other end of the extension wand. It should also click securely. For handheld use, attachments can be connected directly to the main unit.



Figure 4: Attaching the floor brush for multi-surface cleaning.

4. **Charging:** Before first use, fully charge the battery. Connect the power adapter to the wall mount dock, and place the vacuum on the dock. The touchscreen display will indicate charging status.



Figure 5: Touchscreen display showing charging status.

Operating Instructions

The Vistefly V15 is designed for ease of use. Here's how to operate it:

- **Power On/Off:** Press the power button on the main unit to turn the vacuum on or off.
- **Adjust Suction Power:** Use the "Gear Shift Button" on the touchscreen to cycle through different suction power levels (e.g., Eco, Standard, Max). The "Suction Power Indicator" on the display will show the current setting.



Figure 6: Suction power levels for different cleaning needs.

- **LED Headlights:** The motorized floor brush is equipped with LED headlights that illuminate the cleaning path, making dust and debris visible in dimly lit areas or under furniture.
- **Versatile Cleaning:**
    - For floors and carpets, use the main unit with the extension wand and motorized floor brush. The anti-tangle V-shaped brush is designed to prevent hair wrapping.
    - For upholstery, car interiors, or tight spaces, detach the extension wand and use the main unit with the crevice tool or 2-in-1 dusting brush.



Figure 7: Anti-tangle V-shaped brush for efficient cleaning.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

- **Emptying the Dust Cup:** The 1.3-liter dust cup can be emptied with a single click. Position the dust cup over a trash bin and press the release button to open the bottom flap.



Figure 8: One-click dust cup emptying.

- **Cleaning Filters:** The V15 features a 6-stage high-efficiency filtration system, including a HEPA filter, that traps 99.97% of 0.3-micron microscopic particles. Regularly clean the filters to maintain suction power.

    a. Twist and remove the dust cup from the main unit.
    b. Remove the filter components (pre-filter and HEPA filter).
    c. Tap off loose dust or rinse with cold water. Ensure filters are completely dry before reassembling.



Figure 9: 6-Stage High Efficiency Filtration System.

- **Brush Roll Cleaning:** Periodically check the brush roll for tangled hair or debris. Use the provided cleaning tool to cut and remove any wrapped hair.

Troubleshooting

Problem	Possible Cause	Solution
Vacuum not turning on	Battery not charged or not properly installed.	Ensure battery is fully charged and clicked into place.
Low suction power	Dust cup full, filters clogged, or brush roll tangled.	Empty dust cup, clean filters, and remove debris from brush roll.
Vacuum stops suddenly	Overheating due to blockage or prolonged use on high power.	Turn off, clear any blockages, and allow to cool for 30 minutes before restarting.

Problem	Possible Cause	Solution
LED headlights not working	Loose connection or internal issue.	Check connection of floor brush. If issue persists, contact customer support.

Specifications

- **Brand:** Vistefly
- **Model:** V15
- **Special Feature:** Bagless
- **Filter Type:** Cloth (HEPA filtration system)
- **Dust Cup Capacity:** 1.3 Liters
- **Maximum Suction:** 244.2 Millimeters (implied kPa from image, 33kPa)
- **Form Factor:** Handheld / Stick
- **Battery Type:** Lithium-Ion (7*2500 mAh)
- **Runtime:** Up to 60 Minutes
- **Amperage:** 17.24 Milliamps
- **Controller Type:** Push Button / Touchscreen
- **Portable:** Yes
- **Number of Power Levels:** 2
- **Finish Types:** Glossy/Matte
- **Item Weight:** 1.12 pounds
- **Package Dimensions:** 7.56 x 3.66 x 1.77 inches

Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Vistefly website. Keep your purchase receipt as proof of purchase for any warranty claims.
Vistefly Store: Visit the Vistefly Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question