Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY A2-2022092301A26

YING RAY Replacement Remote Control User Manual

For Blueridge AC Models: KIT-BPK18, KIT-BPK24, KIT-BPK36, BMKH18LM23UH, BM48M22C, BMKH18M-LM, BMKH18M-NDG3, BMKH18M23UH, BMKH18MCC, BMKH18MCCG

Brand: YING RAY | Model: A2-2022092301A26

1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your YING RAY replacement remote control. This remote is specifically designed to function with the listed Blueridge air conditioner models. Please read this manual thoroughly to ensure correct usage and to maximize the performance of your air conditioning unit.

2. Package Contents

Verify that all items are present in your package:

- 1 x YING RAY Replacement Remote Control
- 1 x Wall Mount Case



This image displays the YING RAY replacement remote control on the left and its white wall mount case on the right. The remote is silver and black, featuring a digital display at the top showing temperature, fan speed, and time. Below the display are various control buttons for functions like Mode, Fan, Swing, Sleep, Temp, iFeel, Clock, Light, and Timer. The wall mount case is a simple white plastic holder designed to store the remote.

3. Compatibility Information

This remote control is a direct replacement for specific Blueridge air conditioner models. It is**not a universal remote**

control. Please ensure your air conditioner model or original remote control model matches one of the following:

- Blueridge KIT-BPK18
- Blueridge KIT-BPK24
- Blueridge KIT-BPK36
- Blueridge BMKH18LM23UH
- Blueridge BM48M22C
- Blueridge BMKH18M-LM
- Blueridge BMKH18M-NDG3
- Blueridge BMKH18M23UH
- Blueridge BMKH18MCC
- Blueridge BMKH18MCCG

Using this remote with incompatible models may result in improper function or no function at all.

4. Setup

4.1 Battery Installation

1. Open the battery compartment cover on the back of the remote control.
2. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals are aligned correctly according to the markings inside the compartment.
3. Close the battery compartment cover securely.

Note: Remove batteries if the remote control will not be used for an extended period to prevent leakage.

4.2 Wall Mount Installation

1. Choose a convenient location on a wall, away from direct sunlight or heat sources.
2. Use a screw (not included) to secure the wall mount case to the desired position. Ensure it is firmly attached.
3. Place the remote control into the installed wall mount case for easy access and storage.

5. Operating Instructions

Point the remote control directly at the indoor unit of your air conditioner when operating.

5.1 Button Functions

Button	Function
Power (Red Button)	Turns the air conditioner unit ON or OFF.
MODE	Cycles through operating modes: Auto, Cool, Dry, Fan, Heat.
FAN	Adjusts the fan speed (e.g., Auto, Low, Medium, High).
▲ / ▼ (Up/Down Arrows)	Adjusts the temperature setting or timer values.
SWING	Controls the vertical louver swing function of the indoor unit.

Button	Function
TURBO	Activates rapid cooling or heating for quick temperature changes.
SLEEP	Activates Sleep Mode, which adjusts temperature and fan speed for comfortable sleep and energy saving.
TEMP	Switches the temperature display between Celsius (°C) and Fahrenheit (°F).
IFEEL	Activates the iFeel function, where the remote's built-in sensor measures the ambient temperature and sends it to the AC unit for more precise temperature control.
CLOCK	Used to set the current time on the remote's display.
LIGHT	Controls the display light on the indoor air conditioner unit (if applicable).
TIMER ON/OFF	Sets or cancels the automatic ON/OFF timer function.

5.2 Setting the Clock

1. Press the **CLOCK** button. The time display will flash.
2. Use the ▲ and ▼ buttons to adjust the hour and minute.
3. Press the **CLOCK** button again to confirm the time.

5.3 Setting the Timer

The timer function allows you to set the air conditioner to turn on or off automatically after a specified period.

1. Press the **TIMER ON/OFF** button. The timer display will flash.
2. Use the ▲ and ▼ buttons to set the desired ON or OFF time.
3. Press the **TIMER ON/OFF** button again to confirm.
4. To cancel the timer, press the **TIMER ON/OFF** button until the timer display disappears.

6. Maintenance

6.1 Battery Replacement

When the remote control display becomes dim or the remote does not respond, replace the batteries with new AAA batteries. Follow the battery installation steps in Section 4.1.

6.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the remote's surface or internal components.

7. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the air conditioner's indoor unit.
  - Confirm that the remote is compatible with your specific Blueridge AC model.

- **Display is dim or blank:**
  - Replace the batteries.
- **Temperature display is incorrect:**
  - Ensure the remote is not exposed to direct sunlight or heat sources, especially when using the iFeel function.

8. Specifications

Feature	Detail
Brand	YING RAY
Model Number	A2-2022092301A26
Compatible Devices	Blueridge Air Conditioners (specific models listed in Section 3)
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Battery Type	2 x AAA batteries (not included)
Item Weight	1.06 ounces
Package Dimensions	0.39 x 0.2 x 0.08 inches
Manufacturer	ZHUHAI YINGRAY TRADING CO., LTD.

9. Warranty and Support

This YING RAY replacement remote control comes with a**1-year warranty** from the date of purchase. For warranty claims or technical support, please contact your retailer or the manufacturer directly with your purchase details.

© 2023 YING RAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BG7ZCWRT

More documents and user manuals: **https://manuals.plus/**