Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MEUBLE COSY FUNKEL FABRIC BEIGE ROCK

MEUBLE COSY Rocking Chair Instruction Manual

Model: FUNKEL FABRIC BEIGE ROCK

Introduction

Thank you for choosing the MEUBLE COSY Rocking Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new rocking chair. Please read these instructions carefully before assembly and retain them for future reference.



Image: The MEUBLE COSY Rocking Chair, fully assembled, featuring a beige fabric upholstery and wooden rocker base, placed in a modern living room.

Safety Information

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the chair on a soft, clean surface to prevent scratches.
- Tighten all screws firmly, but do not overtighten. Periodically check and retighten fasteners.
- Keep children and pets away from the assembly area.
- Do not stand on the chair.
- Maximum weight capacity: 110 kg (242 lbs). Do not exceed this limit.

Package Contents

Before beginning assembly, verify that all components are included in your package:

- Rocking Chair Frame (metal and wood components)
- Upholstered Seat and Backrest
- Hardware Pack (screws, washers, Allen key)
- Assembly Instructions

Setup and Assembly

Assembly is required for this rocking chair. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, flat surface to prevent damage.
2. **Identify Parts:** Refer to the included diagram (if available) to identify each component. Pay close attention to labels on parts, especially for the rocker bases, to ensure correct orientation.
3. **Attach Rocker Bases:** Secure the wooden rocker bases to the metal frame using the provided screws and Allen key. Ensure the curved parts of the rockers are facing the correct direction for rocking motion.
4. **Assemble Seat and Backrest:** Connect the upholstered seat and backrest sections to the main frame. Align the pre-drilled holes and insert the screws, tightening them securely.
5. **Attach Armrests:** Secure the armrests to the seat and backrest frame.
6. **Final Tightening:** Once all components are loosely assembled, go back and tighten all screws firmly. Do not overtighten to avoid stripping the threads.
7. **Check Stability:** Gently rock the chair to ensure it is stable and all connections are secure.



Image: Close-up details of the rocking chair, showing the tufted backrest, padded armrest, comfortable seat, and the sturdy wooden rocker base.

Operating Instructions

The MEUBLE COSY Rocking Chair is designed for comfortable relaxation. To use your chair:

- Sit centrally on the seat, ensuring your weight is evenly distributed.
- Gently push off with your feet to initiate a rocking motion. Control the speed and range of motion with your feet.
- Avoid excessive or aggressive rocking, which could lead to instability or damage.
- Ensure there is sufficient clear space around the chair to prevent collisions with walls or other furniture during rocking.

Maintenance

Proper care will extend the life and appearance of your rocking chair:

- **Cleaning:** Wipe the fabric upholstery with a clean, damp cloth. For spills, blot immediately with a clean, dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Frame Care:** Wipe the wooden and metal components with a soft, dry cloth.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Retighten as necessary to maintain stability.
- **Placement:** Avoid placing the chair in direct sunlight or near heat sources, as this can cause fading or damage to the materials.

Troubleshooting

Problem	Possible Cause	Solution
Chair feels unstable or wobbly	Loose fasteners; uneven assembly	Check and tighten all screws and bolts. Ensure the chair is on a flat, level surface.
Squeaking noise during rocking	Friction between parts; loose connections	Tighten all fasteners. Apply a small amount of silicone lubricant to contact points if necessary.
Difficulty assembling a part	Incorrect orientation; misaligned holes	Review the assembly instructions carefully. Ensure parts are oriented correctly (e.g., rocker bases). Do not force parts together.

Specifications



Image: A technical diagram illustrating the key dimensions of the rocking chair, including height, width, depth, seat height, and backrest height.

Feature	Detail
Model Name	FUNKEL FABRIC BEIGE ROCK
Brand	MEUBLE COSY
Color	Beige
Overall Dimensions (D x W x H)	84 cm x 66 cm x 97 cm (33.1 in x 26 in x 38.2 in)
Product Weight	10.2 kg (22.5 lbs)
Maximum Weight Capacity	110 kg (242 lbs)
Frame Material	Wood, Metal

Feature	Detail
Upholstery Material	Fabric
Filling Material	Foam
Seat Height	43 cm (16.9 in)
Seat Depth	50 cm (19.7 in)
Backrest Height (internal)	65 cm (25.6 in)
Armrest Height	32 cm (12.6 in)
Assembly Required	Yes

Warranty and Support

For warranty information or customer support, please refer to the documentation provided with your purchase or contact MEUBLE COSY directly through their official website or customer service channels. Please have your model number (FUNKEL FABRIC BEIGE ROCK) and purchase details ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BG84W55R

More documents and user manuals: **https://manuals.plus/**