Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beurer 63261

Beurer FB 60 Foot Bath User Manual

Model: FB 60 (63261) | Brand: Beurer

Product Overview

The Beurer FB 60 foot bath is designed to provide a relaxing and therapeutic foot care experience. It features vibration and bubble massages, adjustable water heating, and integrated pedicure functions. This manual provides essential information for safe and effective use of your device.



Image: The Beurer FB 60 Foot Bath, showcasing its bubbling water and the included pedicure attachments.

Important Safety Instructions

Please read all safety warnings carefully before using the Beurer FB 60 foot bath to prevent injury or damage to the device.

- Do not use the massager near water sources (e.g., in a bathtub or shower) or with wet feet.
- Do not touch hot surfaces of the device during or immediately after use.
- Ensure the device is unplugged before cleaning or maintenance.
- Keep the device out of reach of children.
- Do not operate the device if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged.
- Only use the device for its intended purpose as described in this manual.
- Consult a doctor before use if you have any medical conditions, especially diabetes, circulatory problems, or open

wounds on your feet.

For further detailed safety instructions, refer to the manufacturer's full user manual.

Setup

1. Place the foot bath on a flat, stable, and non-slip surface. Ensure there is enough space around the device.
2. Fill the foot bath with water. You can use cold, warm, or hot water depending on your preference. Do not exceed the maximum fill line indicated inside the basin.
3. Plug the power cord into a suitable electrical outlet.



Image: A user enjoying the Beurer FB 60 Foot Bath, illustrating a typical setup for a home spa experience.

Operating Instructions

The Beurer FB 60 offers various functions for a personalized foot spa experience.

Basic Operation

1. After filling with water and plugging in, press the power button on the touch screen to turn on the device.
2. Select your desired settings using the touch screen controls.
3. Immerse your feet into the water.



Image: The intuitive touch screen interface of the Beurer FB 60, allowing easy control of settings.

Functions

- **Water Heating:** The powerful water heater can warm the water in 8 stages, from 34°C to 48°C. Use the temperature controls on the display to adjust. The double-walled housing helps maintain water temperature.
- **Bubble Massage:** Activate the bubble function for a soothing effervescent massage.
- **Vibration Massage:** Activate the vibration function for a stimulating massage.
- **Footbed Rollers and Nubs:** The integrated footbed features nubs and wide massage rollers. Move your feet back and forth over these elements for an intense and targeted massage.



Image: A detailed view of the foot bath's interior, highlighting the nubs and rollers designed for an intense foot massage.

Pedicure Attachments

The FB 60 includes three interchangeable pedicure attachments for comprehensive foot care:

- **Callus Remover:** For gently removing hardened skin.
- **Brush Attachment:** For stimulating circulation and smoothing skin.
- **Massage Attachment:** For additional massage and relaxation.

To use, simply attach the desired tool to the central post in the foot bath. The foot bath accommodates up to shoe size 51.



Image: The three included pedicure attachments: callus remover, brush, and massage tool.

Cleaning and Maintenance

Proper cleaning and maintenance ensure the longevity and hygiene of your foot bath.

1. After each use, unplug the device from the power outlet.
2. Empty the water from the basin.
3. Clean the basin and attachments with a damp cloth and mild detergent. Do not use abrasive cleaners or immerse the electrical unit in water.
4. Rinse thoroughly and dry all components before storage.
5. Store the foot bath in the provided storage and drying bag in a cool, dry place. Use the cable winder to neatly store the power cord.

Troubleshooting

If you encounter issues with your Beurer FB 60 foot bath, try the following steps:

- **Device does not turn on:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check if the power button on the touch screen has been pressed.
- **No bubbles/vibration:**
  - Verify that the respective function is activated on the touch screen.
  - Ensure the water level is within the recommended range.
- **Water not heating:**
  - Check the temperature setting on the display.
  - Allow sufficient time for the water to heat up, especially if starting with cold water.

If the problem persists after attempting these steps, please contact Beurer customer support or refer to the comprehensive troubleshooting section in the full user manual.

Product Specifications

Brand	Beurer
Model Number	63261 (FB 60)
Dimensions (L x W x H)	46.3 x 40.3 x 19 cm
Weight	1 kg (2.2 lbs)
Material	Rubber (for feet), Plastic (main body)
Power Source	Corded Electric
Water Heating Range	34°C to 48°C (8 stages)
Max. Shoe Size	51 (EU)
Special Features	Bubble Massage, Vibration Massage, Water Heating, Pedicure Attachments, Touch Screen, Non-slip feet, Cable winder



Image: Dimensions and key physical features of the Beurer FB 60 Foot Bath.

Warranty Information

Specific warranty details for the Beurer FB 60 foot bath are typically provided with the product packaging or on the manufacturer's official website. Please retain your proof of purchase for any warranty claims. Beurer products generally come with a manufacturer's warranty covering defects in materials and workmanship under normal use.

Customer Support

For technical assistance, spare parts, or further information regarding your Beurer FB 60 foot bath, please contact Beurer customer support. Contact details can usually be found on the official Beurer website or in the original product documentation.

You can visit the official Beurer store on Amazon for more products and information:Beurer Amazon Store

© 2024 Beurer. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BGFLCD8J

More documents and user manuals: **https://manuals.plus/**