Hatteker RFC-5618

Hatteker Beard Trimmer Kit User Manual

Model: RFC-5618

1. Introduction

Thank you for choosing the Hatteker 6-in-1 Multi-Functional Men's Grooming Kit. This versatile kit is designed to meet all your daily grooming needs, offering precision and convenience for hair cutting, beard trimming, shaving, and body grooming. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.

2. What's Included

Your Hatteker Grooming Kit includes the following components:



Image: All components of the Hatteker 6-in-1 Multi-Functional Men's Grooming Kit, including the main trimmer unit, various attachment heads, guide combs, cleaning brush, USB cable, and hair comb.

- Hair Clipper
- T-blade Trimmer
- Precision Trimmer
- Micro Shaver
- Nose Trimmer
- Body Trimmer
- 9 Guide Combs (4 for T-blade: 1mm, 3mm, 5mm, 7mm; 5 for Hair Clipper: 3mm, 6mm, 9mm, 12mm, 15mm)
- Cleaning Brush
- USB Cable
- Hair Comb

3. Setup

3.1 Charging the Device

Before first use, fully charge the grooming kit. A full charge takes approximately 1.5 hours and provides up to 180 minutes of running time.

1. Connect the USB charging cable to the charging port at the bottom of the trimmer.
2. Plug the other end of the USB cable into a compatible USB power source (e.g., computer, laptop, USB charger, power bank).
3. The digital display on the trimmer will indicate the charging progress.
4. Once fully charged, disconnect the cable.



Image: The Hatteker trimmer connected via USB cable to a power source, illustrating the quick charge capability and battery life.

Important Note:

- Use the original charging cable provided with the kit to ensure proper charging and prevent potential issues.
- Do not use the device while it is charging.

3.2 Attaching and Detaching Trimmer Heads

The grooming kit comes with multiple detachable heads for various functions.

1. To attach a head: Align the desired head with the main body of the trimmer and gently push until it clicks into place.
2. To detach a head: Hold the main body firmly and pull the head upwards away from the body.



Image: An exploded view illustrating the six different interchangeable heads: T-blade Trimmer, Hair Clipper, Micro Shaver, Precision Trimmer, Nose Trimmer, and Body Trimmer.

3.3 Attaching Guide Combs

Guide combs are used to achieve desired hair lengths for trimming and cutting.

1. Select the appropriate guide comb for your desired length. The T-blade trimmer uses 1mm, 3mm, 5mm, 7mm combs. The hair clipper uses 3mm, 6mm, 9mm, 12mm, 15mm combs.
2. Align the comb with the teeth of the trimmer head.
3. Push the comb firmly onto the head until it snaps securely into place.
4. To remove, gently pull the comb away from the trimmer head.



Image: A visual guide displaying the various guide comb sizes available for both the Hair Clipper and the T-blade Trimmer, indicating their respective lengths.

4. Operating Instructions

Ensure the device is fully charged before use. Press the power button to turn the trimmer on or off.

4.1 General Trimming Tips

- For best results, use on clean, dry hair.
- Always move the trimmer against the direction of hair growth.
- Use slow, controlled movements.
- Regularly clean the blades during use to prevent hair buildup.

4.2 Using Different Trimmer Heads



Image: Demonstrations of the various detachable attachments in use, including hair clipping, beard trimming, micro shaving, body trimming, hair carving, and nose hair removal.

- **T-blade Trimmer:** Ideal for hair cutting, trimming, carving hair shapes, and achieving bald head styles. Its zero-gapped design is excellent for precise trimming, beards, sideburns, and detailed artwork.
- **Hair Clipper:** Use with the larger guide combs (3mm, 6mm, 9mm, 12mm, 15mm) for general hair cutting and styling.
- **Precision Trimmer:** For fine lines, contours, and detailed styling around the beard, mustache, and hairline.
- **Micro Shaver:** Provides a close shave for small areas, suitable for finishing touches on cheeks or necklines.
- **Nose Trimmer:** Gently insert the trimmer into the nostril or ear canal to remove unwanted hair.
- **Body Trimmer:** Designed for grooming body hair.

The powerful and durable motor ensures an efficient and smooth cutting experience, while the ergonomic design provides a comfortable grip for extended use.

5. Maintenance

5.1 Cleaning the Blades

Regular cleaning ensures optimal performance and extends the life of your grooming kit.

1. Turn off the trimmer and detach the blade head.
2. Use the provided cleaning brush to remove any loose hairs from the blades and the trimmer body.
3. The blades are washable. You can rinse them under running water for quick and thorough cleaning.
4. Allow the blades to air dry completely before reattaching them to the trimmer body or storing the device.



Image: A close-up view of the stainless steel blade being rinsed under running water, demonstrating its washable and detachable design for easy cleaning.

5.2 Storage

Store the grooming kit in a cool, dry place, away from direct sunlight and moisture. Keep all attachments and the charging cable together to prevent loss.

6. Troubleshooting

If you encounter any issues with your Hatteker Grooming Kit, please refer to the following common solutions:

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer fully (approx. 1.5 hours).
Trimmer does not charge.	Incorrect charging cable or faulty power source.	Ensure you are using the original USB charging cable. Try a different USB power adapter or port.
Blades are pulling hair or not cutting effectively.	Blades are clogged with hair or dull.	Clean the blades thoroughly. If blades are dull after extended use, consider replacement if available.
Attachment heads do not fit securely.	Incorrect alignment or debris.	Ensure the head is correctly aligned and push firmly until it clicks. Check for any debris obstructing the connection.

7. Specifications

- **Model Number:** RFC-5618
- **Power Source:** Cordless, USB Charging
- **Battery Type:** Lithium-Ion
- **Charging Time:** Approximately 1.5 hours
- **Running Time:** Up to 180 minutes
- **Product Dimensions:** 8.31 x 5.31 x 2.32 inches
- **Weight:** 1.1 Pounds
- **Included Components:** Hair Clipper, T-blade trimmer, Precision trimmer, Micro shaver, Nose trimmer, Body trimmer, 9 guide combs, Cleaning brush, USB cable, Hair comb
- **Manufacturer:** Hatteker
- **Country of Origin:** China

8. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Hatteker customer service directly. Keep your purchase receipt as proof of purchase.
Safety Information: Do not use near water. Keep out of reach of children under 3 years old.

© 2024 Hatteker. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I reset the Hatteker RFC-5618 grooming kit?

The provided manual for the Hatteker RFC-5618 grooming kit does not mention a specific reset function for the device. The troubleshooting section primarily addresses issues like the trimmer not turning on or charging, and...

Read full answer