Buture Pro VC40

BuTure VC40 Cordless Stick Vacuum Cleaner User Manual

Model: VC40 | Brand: BuTure Pro

Introduction

Thank you for choosing the BuTure VC40 Cordless Stick Vacuum Cleaner. This manual provides important information on the safe operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before use and keep it for future reference.

Important Safety Instructions

When using an electrical appliance, basic precautions should always be followed, including the following:

- Read all instructions before using the vacuum cleaner.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without dust bin and/or filters in place.
- Turn off all controls before unplugging.

- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Store the appliance indoors. Put it away after use to prevent accidents.
- Use only the charger supplied by the manufacturer to recharge.

Package Contents

Please check the package contents upon opening. If any parts are missing or damaged, contact customer support.



Image: Overview of the BuTure VC40 Cordless Stick Vacuum Cleaner and its included accessories. This includes the main motor unit, extension wand, floor brush, wall mount, crevice tool, 2-in-1 brush, and spare filters.

- Main Motor Unit with Dustbin
- Extension Wand
- Motorized Floor Brush
- Wall Mount
- Crevice Tool

- 2-in-1 Brush
- Power Adapter
- Spare Filters (2)
- User Manual

Setup

1. Assembly

1. **Attach the Extension Wand:** Insert the extension wand into the main motor unit until it clicks into place.
2. **Attach the Floor Brush:** Connect the motorized floor brush to the other end of the extension wand, ensuring it clicks securely.
3. **Attach Accessories:** For handheld use, attach the crevice tool or 2-in-1 brush directly to the main motor unit.

2. Charging the Battery

The battery may not be fully charged upon first use. It is recommended to fully charge the battery before initial operation.

- Connect the power adapter to the charging port on the main motor unit or directly to the removable battery.
- Plug the adapter into a wall outlet.
- The touchscreen display will indicate charging status. A full charge typically takes 4-5 hours.



Image: Illustration showing the removable battery feature and approximate runtimes: 50 minutes (Eco mode), 30 minutes (Standard mode), and 15 minutes (Max mode).

Operating Instructions

1. Power On/Off

- Press the power button on the handle to turn the vacuum cleaner on or off.

2. Adjusting Suction Power

The BuTure VC40 features a touchscreen display to easily switch between three suction modes:



Image: Visual representation of the three suction power modes: Eco (12KPa), Standard (25KPa), and Max (33KPa), demonstrating their use on different surfaces.

- **Eco Mode (12KPa):** For light cleaning and extended runtime.
- **Standard Mode (25KPa):** For daily cleaning of various surfaces.

- **Max Mode (33KPa):** For deep cleaning and stubborn dirt.
- Tap the mode selection button on the touchscreen to cycle through the modes.

3. Using the Motorized Floor Brush

The motorized floor brush is designed for effective cleaning on both hard floors and carpets. It features an anti-tangle roller brush and LED headlights.



Image: Close-up view of the motorized floor brush, highlighting its anti-tangle roller design and integrated LED headlights for illuminating

dark areas during cleaning.

- The LED headlights automatically illuminate when the vacuum is in operation, helping to spot dust in dark corners.
- The anti-tangle design helps prevent hair and pet fur from wrapping around the brush roll.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

1. Emptying the Dustbin (1.5L Capacity)

- Press the dustbin release button to detach the dustbin from the main unit.
- Hold the dustbin over a trash can and press the bottom release latch to open the dustbin flap and empty contents.
- Close the flap and reattach the dustbin to the main unit.

2. Cleaning the Filters

It is recommended to clean the filters regularly, especially if suction power decreases. The vacuum comes with two spare filters.

- Twist and pull out the filter assembly from the dustbin.
- Separate the HEPA filter and the metal mesh filter.
- Tap off loose dust. Rinse both filters under cold running water until the water runs clear.
- Allow filters to air dry completely for at least 24 hours before reassembling and placing back into the vacuum. Do not use a dryer or heat to dry.

3. Cleaning the Roller Brush

- Turn off and unplug the vacuum cleaner.
- Locate the brush roll release tab on the side of the floor brush.
- Remove the brush roll.
- Use scissors or a cleaning tool to cut and remove any tangled hair or debris from the brush roll.
- Reinsert the brush roll until it clicks into place.

Troubleshooting

If you encounter issues with your BuTure VC40, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is not charged.	Charge the battery fully.
	Battery not properly installed.	Ensure the battery is securely clicked into place.
Low suction power.	Dustbin is full.	Empty the dustbin.
	Filters are clogged.	Clean or replace the filters. Ensure they are completely dry before reinstallation.

Problem	Possible Cause	Solution
	Brush roll is tangled or blocked.	Remove and clean the brush roll. Check for blockages in the air path.
Brush roll not spinning.	Brush roll is jammed by debris.	Turn off the vacuum, remove the brush roll, and clear any obstructions.
	Floor brush not properly connected.	Ensure the floor brush is securely attached to the extension wand or main unit.
Vacuum stops suddenly during use.	Battery is depleted.	Recharge the battery.
	Overheating protection activated.	Turn off the vacuum and let it cool down for at least 30 minutes. Check for blockages in the air path or filters.

Specifications

Feature	Detail
Model Number	VC40
Brand	Buture Pro
Power	400 Watts
Suction Power	Up to 33 KPa
Dustbin Capacity	1.5 Liters
Battery Type	Lithium-ion (1 included)
Runtime	Up to 50 minutes (Eco mode)
Voltage	220 Volts (AC)
Product Dimensions (L x W x H)	43.9 x 33.1 x 19.7 cm
Item Weight	4.15 Kilograms
Filter Type	Cartridge
Color	Dark Blue

Warranty and Support

For warranty information and customer support, please refer to the warranty card included in your package or contact BuTure Pro customer service directly. Keep your purchase receipt as proof of purchase.
For further assistance, please visit the official BuTure Pro website or contact their support team.

© 2023 BuTure Pro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question