TCL TCL TAB 8

TCL TAB 8 Wi-Fi Android Tablet User Manual

Model: TCL TAB 8 | Brand: TCL

Introduction

This manual provides detailed instructions for the proper use and maintenance of your TCL TAB 8 Wi-Fi Android Tablet. Please read this manual thoroughly before operating your device to ensure optimal performance and longevity. The TCL TAB 8 is a portable 8-inch HD display tablet designed for everyday use, featuring Android 11, 3GB RAM, 32GB internal storage (expandable up to 512GB), and a 4080mAh battery.

What's in the Box

- TCL TAB 8 Wi-Fi Android Tablet
- 1X Type-C Cable
- User Manual (this document)

Product Overview



Figure 1: TCL TAB 8 Tablet with its protective cover, showcasing the 8-inch HD display.



Figure 2: Front and back view of the TCL TAB 8 Tablet, highlighting its sleek design and rear camera.



Figure 3: The TCL TAB 8 Tablet displaying its storage capacity, indicating 32GB internal storage expandable up to 512GB with a microSD card.

Specifications

Feature	Detail
Brand	TCL
Model Name	TCL Tab
Screen Size	8 Inches
Display Resolution	800 x 1280 Pixels
Processor	2 GHz (Qualcomm, 4 Cores)
Graphics Coprocessor	IMG GE8300

Operating System	Android 11
Memory Storage Capacity	32 GB (expandable up to 512 GB with microSD)
Battery Life (Average)	8 Hours (online video)
Item Weight	0.317 ounces (approx. 9 grams)
Product Dimensions	8 x 6 x 0.3 inches
Rear Webcam Resolution	5 MP
Wireless Type	802.11b, 802.11a, 820.11g
USB Ports	1 (Type-C)

Setup

1. Initial Charging

Before first use, fully charge your TCL TAB 8 tablet using the provided Type-C cable and a compatible power adapter (not included). The battery indicator on the screen will show charging progress.

2. Powering On/Off

- To power on: Press and hold the Power button until the TCL logo appears.
- To power off: Press and hold the Power button, then select "Power off" from the options.
- To restart: Press and hold the Power button, then select "Restart" from the options.

3. Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup process. This includes:

1. Selecting your language.
2. Connecting to a Wi-Fi network.
3. Signing in with your Google account or creating a new one.
4. Setting up screen lock (PIN, pattern, password).
5. Reviewing and accepting terms and conditions.

4. Inserting a MicroSD Card (Optional)

The tablet supports expandable storage up to 512GB via a microSD card (sold separately). Locate the microSD card slot on the side of the tablet. Gently insert the card into the slot until it clicks into place. Ensure the tablet is powered off before inserting or removing the card.

Operating Your Tablet

1. Navigation Basics

- **Home Screen:** Swipe left or right to access different home screens.
- **App Drawer:** Swipe up from the bottom of the screen to view all installed applications.
- **Notifications & Quick Settings:** Swipe down from the top of the screen to access notifications and quick settings toggles (Wi-Fi, Bluetooth, etc.).

- **Back, Home, Recent Apps:** Use the navigation buttons at the bottom of the screen for these functions.

2. Managing Applications

- **Downloading Apps:** Access the Google Play Store to download and install new applications.
- **Uninstalling Apps:** Long-press an app icon on the home screen or in the app drawer, then drag it to "Uninstall" or select the uninstall option. Alternatively, go to Settings > Apps & notifications > See all apps, select the app, and tap "Uninstall".
- **Switching Apps:** Tap the "Recent Apps" button (square icon) to view and switch between recently used applications.

3. Eye Protection Modes

The TCL TAB 8 features three eye protection modes to enhance viewing comfort:

- **Eye Comfort Mode:** Reduces blue light emission to prevent eye strain, especially in low light. Activate from Quick Settings or Display settings.
- **Reading Mode:** Adjusts the screen to a monochrome or sepia tone, simulating a paper-like reading experience. Ideal for e-books.
- **Dark Mode:** Changes the system UI and supported apps to a dark color scheme, reducing glare and saving battery on OLED screens (though this tablet is HD LCD, it still helps with comfort).

These modes can be configured and activated in the tablet's*Settings* menu under *Display*.

Maintenance

1. Battery Care

- Avoid extreme temperatures, as they can degrade battery life.
- Do not let the battery completely drain frequently. Charge it before it reaches 0%.
- Use only the provided Type-C cable and a certified power adapter.
- For long-term storage, charge the tablet to about 50% and power it off.

2. Cleaning Your Tablet

- Use a soft, lint-free cloth to clean the screen and body.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner designed for electronics.
- Avoid using harsh chemicals, abrasive materials, or excessive moisture.

3. Software Updates

Regularly check for and install software updates to ensure your tablet has the latest features, security patches, and performance improvements. Go to *Settings > System > System update*to check for updates.

Troubleshooting

Problem	Solution

Tablet is slow or unresponsive.	◦ Close unused apps running in the background. ◦ Clear app caches (Settings > Apps & notifications > [App Name] > Storage & cache > Clear cache). ◦ Restart the tablet. ◦ Ensure sufficient free storage space.
Cannot connect to Wi-Fi.	◦ Ensure Wi-Fi is enabled in Quick Settings. ◦ Restart your Wi-Fi router. ◦ Forget the network and reconnect (Settings > Network & internet > Wi-Fi).
Apps are crashing or not downloading.	◦ Clear cache and data for the Google Play Store app (Settings > Apps & notifications > Google Play Store > Storage & cache). ◦ Ensure you have a stable internet connection. ◦ Check available storage space.
SIM card slot issue (if applicable).	*Note: This model is a Wi-Fi only tablet and does not support SIM cards. If you are attempting to insert a SIM card, please verify your tablet model.*

Warranty and Support

For warranty information and technical support, please refer to the official TCL website or contact their customer service. Keep your proof of purchase for warranty claims.
For further assistance, you may visit the product page on Amazon or the Amazon Renewed Store if your product was purchased as renewed.

© 2025 TCL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question