Freaks and Geeks EG-C2075B

Freaks and Geeks Harry Potter Wireless PS4 Controller

Model: EG-C2075B

Introduction

Thank you for purchasing the Freaks and Geeks Harry Potter Wireless PS4 Controller. This officially licensed controller is designed to enhance your gaming experience on PlayStation 4 with its wireless connectivity, dual vibration, and unique Harry Potter design. This manual provides essential information on setup, operation, maintenance, and troubleshooting to ensure optimal performance.



Image: The retail packaging of the Freaks and Geeks Harry Potter Wireless PS4 Controller, showcasing the controller and its features.

Setup

Charging the Controller

Before initial use, fully charge the controller. The controller features a 600 mA high-capacity, rechargeable Lithium Polymer battery, providing approximately 6 to 8 hours of gameplay on a full charge.

- Connect the included micro USB cable to the charging port on the controller.
- Connect the other end of the micro USB cable to a USB port on your PlayStation 4 console or a compatible USB wall adapter.
- The controller's indicator light will show charging status and turn off or change color when fully charged.

Connecting to PlayStation 4 (Bluetooth Pairing)

The controller connects wirelessly to your PlayStation 4 console via Bluetooth. It can be used as the main controller to start the console.

- Ensure your PlayStation 4 console is powered on.

- With the controller powered off, press and hold the**PS button** and **SHARE button** simultaneously until the light bar begins to flash rapidly. This indicates the controller is in pairing mode.
- On your PS4, navigate to**Settings > Devices > Bluetooth Devices**
- Select the Freaks and Geeks controller from the list of available devices.
- Once paired, the light bar will stop flashing and glow a solid color, indicating a successful connection.



Image: Front view of the Freaks and Geeks Harry Potter Wireless PS4 Controller, showing the buttons and touchpad.

Operating Instructions

Basic Controls and Features

The controller offers a familiar layout with enhanced features for an immersive gaming experience.

- **Dual Vibration Motor:** Provides tactile feedback during gameplay for enhanced immersion.
- **Clickable Central Touchpad:** Functions as an input device for various in-game actions and navigation.
- **Integrated Speaker:** Delivers audio effects directly from the controller for specific game events.
- **Luminous Buttons:** Certain buttons feature illumination for improved visibility and aesthetic appeal.

Headset Connection

Connect your headset or headphones directly to the controller for in-game audio and communication.

- Plug your 3.5 mm jack headset into the dedicated port located at the bottom of the controller.
- Adjust audio settings on your PS4 console if necessary (**Settings > Devices > Audio Devices**).



Image: Top view of the Freaks and Geeks Harry Potter Wireless PS4 Controller, highlighting the touchpad and main buttons.

Maintenance

Proper care and maintenance will extend the life of your controller.

- **Cleaning:** Use a soft, dry cloth to clean the controller. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Do not attempt to replace the internal battery. Avoid fully discharging the battery frequently to prolong its lifespan.
- **Handling:** Avoid dropping the controller or exposing it to excessive force, which can damage internal components.

Troubleshooting

If you encounter issues with your controller, refer to the following common solutions:

- **Controller Not Connecting:**
  - Ensure the controller is charged.
  - Re-attempt the Bluetooth pairing process (see 'Connecting to PlayStation 4').

- Try connecting the controller via USB cable to see if it registers.
- Reset the controller by inserting a small pin into the reset hole on the back of the controller for a few seconds.

- **Buttons or Joysticks Unresponsive:**
  - Ensure the controller is fully charged and connected.
  - Clean around the buttons and joysticks to remove any debris.
  - Test the controller in a different game or application to rule out software issues.

- **Charging Issues:**
  - Verify the micro USB cable is securely connected to both the controller and the power source.
  - Try a different micro USB cable or USB port.
  - Ensure the power source (PS4 console or wall adapter) is functioning correctly.

- **Audio Problems with Headset:**
  - Ensure the headset is fully plugged into the 3.5 mm jack.
  - Check audio settings on your PS4 console (**Settings > Devices > Audio Devices**) to ensure output is set to 'Headphones Connected to Controller'.
  - Test the headset with another device to confirm it is working.

Specifications

Model Number	EG-C2075B
Connectivity	Wireless (Bluetooth)
Compatibility	PlayStation 4
Battery Type	600 mA Lithium Polymer (Rechargeable)
Battery Life	6 to 8 hours (approximate)
Charging Port	Micro USB
Audio Port	3.5 mm Headset Jack
Dimensions (L x W x H)	17 x 19 x 8 cm
Weight	330 grams
Special Features	Dual Vibration, Clickable Touchpad, Integrated Speaker, Luminous Buttons

Warranty and Support

This Freaks and Geeks Harry Potter Wireless PS4 Controller comes with a **3-year warranty** from the date of purchase, covering manufacturing defects under normal use.
For technical support, warranty claims, or further assistance, please contact the retailer where you purchased the product or visit the official Freaks and Geeks support website. Please have your proof of purchase and the product model number (EG-C2075B) available when seeking support.