Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YIRISO YH-7269

YIRISO Body Hair Trimmer Instruction Manual

Model: YH-7269

Introduction

Thank you for choosing the YIRISO Body Hair Trimmer, Model YH-7269. This manual provides essential information for the safe and effective use, maintenance, and care of your new trimmer. Please read these instructions thoroughly before first use and retain them for future reference.

Safety Information

WARNING: To reduce the risk of injury, electric shock, fire, or damage to the product, always observe the following safety precautions:

- Keep away from water sources. Do not immerse the charging base in water.
- Do not use while charging.
- Avoid contact with eyes and broken skin.
- Not suitable for use on infants or children. Keep out of reach of children.
- Always unplug the device and allow it to cool before cleaning.
- Do not use on dry or irritated skin.
- Ensure the trimmer is fully assembled before use.

Product Overview

The YIRISO YH-7269 Body Hair Trimmer is designed for comprehensive body grooming. It features interchangeable heads and a quick-adjust comb for versatile use.



Figure 1: The YIRISO YH-7269 trimmer includes the main unit, two interchangeable trimmer heads, a quick-adjust dial comb, charging cable, and cleaning brush.



Figure 2: The trimmer comes with two distinct heads: one for general body grooming and another specifically designed for sensitive areas.

Key Features:

- **SkinSafe Technology:** Ceramic blades designed to minimize nicks and cuts.
- **IPX7 Waterproof:** Suitable for wet or dry use and easy cleaning.
- **Rechargeable:** Cordless operation for convenience.
- **Low Noise Operation:** Engineered for quiet performance.
- **Quick-Adjust Dial Comb:** 15 length settings from 3mm to 17mm.



Figure 3: The SkinSafe technology features ceramic blades designed to minimize nicks and cuts, protecting sensitive skin during grooming.

Setup

1. Initial Charging

Before first use, fully charge the trimmer. This typically takes several hours. The battery indicator lights will show the charging status.

1. Connect the charging cable to the trimmer's charging port.
2. Plug the USB end of the cable into a suitable USB power adapter (not included) or a powered USB port.
3. The indicator lights (HIGH, MID, LOW) will illuminate to show the charge level. When fully charged, all lights may remain solid or turn off, depending on the model.



Figure 4: Before first use, fully charge the trimmer. Connect the charging cable to the trimmer and a power source. The indicator lights will show charging status.

2. Attaching/Detaching Trimmer Heads

The trimmer comes with two interchangeable heads. To change heads:

- To detach: Hold the trimmer body firmly and gently pull the attached head upwards until it detaches.
- To attach: Align the desired head with the trimmer body and push down firmly until it clicks into place.

3. Attaching the Quick-Adjust Dial Comb

The comb attachment is used with the general body grooming head for varying hair lengths.

- Ensure the general body grooming head is attached to the trimmer.
- Slide the comb attachment over the trimmer head until it securely locks into place.
- Rotate the dial on the comb to select your desired trimming length (3mm to 17mm).



Figure 5: The quick-adjust dial comb attachment provides 15 length settings, ranging from 3mm to 17mm, for precise trimming.

Operating Instructions

1. Powering On/Off

Press the power button once to turn the trimmer on. Press it again to turn it off.

2. Trimming Techniques

- **For General Body Hair:** Attach the general body grooming head. For longer hair, use the quick-adjust comb attachment to select your desired length. Move the trimmer against the direction of hair growth for best results.
- **For Sensitive Areas:** Attach the specialized sensitive area trimmer head. This head is designed for closer trimming with enhanced skin protection. Use gentle, slow strokes.
- **Wet or Dry Use:** The YH-7269 is IPX7 waterproof, allowing for comfortable use in the shower or with shaving cream/gel. Ensure the charging port cover is securely closed when using in wet conditions.



Figure 6: The YIRISO YH-7269 trimmer is IPX7 waterproof, allowing for safe wet or dry use and easy cleaning under running water.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your trimmer.

1. **After Each Use:** Turn off the trimmer and detach the trimmer head.
2. **Rinsing:** Rinse the detached trimmer head and the blades under running water to remove hair clippings. You can also rinse the main body of the trimmer, ensuring the charging port cover is sealed.
3. **Drying:** Shake off excess water and allow all parts to air dry completely before reattaching the head or storing the trimmer.
4. **Cleaning Brush:** Use the provided cleaning brush to remove stubborn hair from the blades or inside the trimmer head.
5. **Storage:** Store the trimmer in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

- **Trimmer does not turn on:**

- Ensure the trimmer is fully charged. Connect it to the charger and check the indicator lights.
- Verify the power button is pressed firmly.

- **Poor trimming performance or hair pulling:**
  - Clean the trimmer head and blades thoroughly to remove any accumulated hair or debris.
  - Ensure the trimmer head is correctly attached and secured.
  - The battery might be low. Charge the trimmer fully.
  - Trim against the direction of hair growth.
- **Trimmer stops during use:**
  - The battery may be depleted. Recharge the trimmer.
  - Check for any hair blockages in the blades and clean if necessary.

Specifications

Brand	YIRISO
Model Number	YH-7269
Power Source	Rechargeable Battery (Corded Electric for charging)
Material	Stainless Steel (Blades)
Special Features	Rechargeable, Waterproof (IPX7)
Product Dimensions	4 x 3.9 x 16.2 cm; 340 g
Blade Material	Stainless Steel
Target Audience	Men

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official YIRISO website. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BHH1K28T

More documents and user manuals: **https://manuals.plus/**