Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Arzum AR2062-B

Arzum Airtasty Air Fryer Instruction Manual

Model: AR2062-B

Brand: Arzum

1. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully before using the appliance.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The appliance features a safety system that temporarily stops the fryer if the basket is removed during operation.
- Do not place the appliance against a wall or against other appliances. Leave at least 10 cm free space on the back and sides and 10 cm free space above the appliance.
- Do not place anything on top of the appliance.
- Use only on a stable, heat-resistant surface.

2. Product Overview

The Arzum Airtasty Air Fryer is designed for healthy cooking with minimal oil. Familiarize yourself with its components and controls for optimal use.

Components:

- Main Unit
- Removable Frying Basket
- Basket Handle

- Control Panel (Temperature Dial, Timer Dial)

Control Panel:

The control panel features two main dials for setting cooking parameters:

- **Temperature Dial:** Adjusts the cooking temperature from 80°C to 200°C.
- **Timer Dial:** Sets the cooking time. The appliance will automatically shut off when the timer reaches zero, and an alarm will sound.
- **Power Indicator Light:** Illuminates when the appliance is powered on.
- **Heat Indicator Light:** Illuminates when the heating element is active and turns off when the set temperature is reached.



Figure 2.1: Front view of the Arzum Airtasty Air Fryer, showcasing its sleek black design with copper accents and control dials.



Figure 2.2: The Arzum Airtasty Air Fryer positioned in a kitchen environment, highlighting the clear temperature and timer controls.

3. Setup and First Use

Unpacking:

1. Carefully remove the air fryer and all packaging materials from the box.
2. Remove any stickers or labels from the appliance.

Before First Use:

1. Clean the frying basket and pan thoroughly with hot water, some dishwashing liquid, and a non-abrasive sponge.
2. Wipe the inside and outside of the appliance with a moist cloth.
3. Ensure all parts are completely dry before use.

Placement:

- Place the air fryer on a stable, level, and heat-resistant surface.
- Ensure there is adequate ventilation around the appliance (at least 10 cm clearance on all sides and top).
- Do not place the appliance near flammable materials or heat sources.

4. Operating Instructions

Basic Operation:

1. Plug the main plug into a grounded wall outlet.
2. Carefully pull the frying basket out of the air fryer.
3. Place the ingredients into the frying basket. Do not exceed the 'MAX' fill line.



Figure 4.1: The air fryer basket containing a batch of french fries, ready for cooking.

4. Slide the frying basket back into the air fryer. Ensure it clicks securely into place.



Figure 4.2: The empty air fryer basket and pan, demonstrating the removable components for easy loading and cleaning.

5. Turn the temperature control dial to the desired temperature (80°C to 200°C).
6. Turn the timer dial to the desired cooking time. The appliance will start heating immediately. The power and heat indicator lights will illuminate.
7. During the cooking process, you can pull out the basket to shake or turn ingredients. The safety system will temporarily stop the fryer. Return the basket to resume cooking.
8. When the timer reaches zero, an alarm will sound, and the appliance will automatically shut off.
9. Carefully pull out the basket and empty the cooked food. Use tongs for smaller items.

Preheating:

For best results, especially with certain foods, preheating the air fryer is recommended. Set the temperature and timer for 3-5 minutes without food in the basket.

Cooking Programs:

The Arzum Airtasty Air Fryer comes with 8 pre-set cooking programs for common dishes. Refer to the recipe book (if

included) or experiment with these settings:

- Fries
- Chicken
- Fish
- Meat
- Shrimp
- Baking
- Vegetables
- Pizza

To use a program, simply select it on the control panel (if applicable, or follow the recommended temperature/time for each program).

5. Cleaning and Maintenance

Regular cleaning ensures the longevity and optimal performance of your air fryer.

Before Cleaning:

- Always unplug the appliance from the power outlet and allow it to cool down completely before cleaning.

Cleaning the Basket and Pan:

- The frying basket and pan have a non-stick coating. Do not use metal kitchen utensils or abrasive cleaning materials to clean them, as this may damage the coating.
- Clean the basket and pan with hot water, dishwashing liquid, and a non-abrasive sponge.
- For stubborn residue, soak the basket and pan in hot water with some dishwashing liquid for approximately 10 minutes.
- The basket and pan are generally dishwasher safe, but hand washing is recommended to prolong the life of the non-stick coating.

Cleaning the Interior:

- Wipe the inside of the appliance with a hot water and non-abrasive sponge.
- Clean the heating element with a cleaning brush to remove any food residue.

Cleaning the Exterior:

- Wipe the outside of the appliance with a moist cloth. Do not use harsh or abrasive cleaners.

Storage:

- Ensure the appliance is clean and dry before storing.
- Store the air fryer in a cool, dry place.

6. Troubleshooting

If you encounter issues with your Arzum Airtasty Air Fryer, consult the table below for common problems and solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in.	Ensure the power plug is securely inserted into a grounded wall outlet.
	Timer is not set.	Turn the timer dial to the desired cooking time.
Food is not cooked evenly.	Too much food in the basket.	Reduce the amount of food in the basket. Cook in smaller batches.
	Food not shaken/turned.	Shake or turn ingredients halfway through the cooking process.
White smoke coming from the appliance.	Greasy residue from previous use.	Clean the basket and pan thoroughly after each use.
	Cooking fatty ingredients.	This is normal for fatty foods. Ensure proper ventilation.

7. Specifications

Detailed technical specifications for the Arzum Airtasty Air Fryer Model AR2062-B.

Feature	Specification
Brand	Arzum
Model Number	AR2062-B
Color	Black / Silver
Product Dimensions (L x W x H)	33.5 x 33.5 x 38.5 cm
Capacity	4 Liters
Power / Electrical Power	1350 Watts
Voltage	220 Volts (AC)
Material	Aluminum Plastic
Automatic Shut-off	Yes
Special Features	Temperature control
Item Weight	5.3 Kilograms

Feature	Specification
Recommended Uses	Baking



Figure 7.1: Diagram illustrating the dimensions of the Arzum Airtasty Air Fryer.

8. Warranty and Support

Your Arzum Airtasty Air Fryer is backed by a comprehensive warranty to ensure your peace of mind.

Warranty Information:

This product comes with a**4-year warranty**. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects and malfunctions under normal use conditions.



Figure 8.1: The Arzum Airtasty Air Fryer displaying a '4 Year Warranty' sticker, indicating extended product coverage.

Customer Support:

For any questions, technical assistance, or warranty claims, please contact Arzum customer support through their official website or the contact information provided with your purchase documentation.

Always refer to the model number (AR2062-B) when contacting support to ensure efficient service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BHJ26NFS

More documents and user manuals: **https://manuals.plus/**