Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nautica NAPTCF201

Nautica Men's Tin Can Bay Watch NAPTCF201 User Manual

Model: NAPTCF201

Introduction

This manual provides instructions for the proper use, setup, and maintenance of your Nautica Men's Tin Can Bay Watch, model NAPTCF201. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.

Key Features

- 43mm Blue Stainless Steel Case with Mineral Crystal
- Analog Display with Quartz Movement
- Luminous Hands and Date Function
- Blue Silicone Strap
- Water Resistance up to 100 meters (330 feet)
- Glow-in-the-dark features

Setup

Setting the Time

1. Pull the crown (the knob on the side of the watch) out to the **second click position**.
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the desired time.
3. Push the crown back into its normal position to start the watch.

Setting the Date

1. Pull the crown out to the **first click position**.
2. Turn the crown clockwise or counter-clockwise to set the date.

3. Push the crown back into its normal position.

Note: *Avoid setting the date between 9:00 PM and 3:00 AM, as this may interfere with the automatic date change mechanism. If the date needs to be set during this period, first set the time outside this range, adjust the date, then reset the time.*

Operating Your Watch

Your Nautica Tin Can Bay watch is powered by a precise quartz movement, ensuring accurate timekeeping. The watch features luminous hands and markers for visibility in low-light conditions.

Water Resistance

This watch is water resistant up to 100 meters (330 feet). This makes it suitable for swimming and snorkeling, but it is **not** recommended for scuba diving. Ensure the crown is fully pushed in before any contact with water.





Front view of the Nautica Men's Tin Can Bay Watch, showcasing the blue dial, luminous hands, and blue silicone strap.

Maintenance

Cleaning

To clean your watch, wipe it gently with a soft, dry cloth. For water-resistant models, a damp cloth can be used, followed by drying with a soft, dry cloth. Avoid using chemical cleaners, as they may damage the watch's finish.

Battery Replacement

The watch is powered by a battery. When the watch stops or the second hand moves erratically (e.g., skipping seconds), it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance.

Strap Care

The silicone strap is durable but can be cleaned with mild soap and water. Rinse thoroughly and dry completely before wearing. Avoid prolonged exposure to direct sunlight or extreme temperatures to prevent material degradation.



Back view of the Nautica Men's Tin Can Bay Watch, displaying the stainless steel case back with model number NAPTCF201 and water resistance rating.

Troubleshooting

Problem	Possible Cause	Solution
Watch stops or runs intermittently	Low battery	Replace battery by a professional watch technician.
Date does not change	Date set during restricted hours (9 PM - 3 AM)	Reset the date outside of the restricted hours.

Problem	Possible Cause	Solution
Condensation inside the watch	Exposure to extreme temperature changes or compromised water resistance	Seek professional inspection immediately to prevent damage.
Time is inaccurate	Magnetic interference or internal movement issue	Keep watch away from strong magnetic fields. If problem persists, consult a technician.

Specifications

Model Number	NAPTCF201
Movement	Quartz
Display	Analog
Case Material	Stainless Steel
Case Diameter	44 mm
Case Thickness	11.1 mm
Crystal	Mineral Glass
Strap Material	Silicone
Strap Width	22 mm
Water Resistance	100 Meters (330 Feet)
Features	Date function, Luminous hands, Glow In The Dark
Product Dimensions	12 x 12 x 12 cm
Product Weight	100 g

Warranty Information

Your Nautica Tin Can Bay Watch NAPTCF201 comes with a**1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use.

The warranty does not cover:

- Battery life
- Normal wear and tear (e.g., scratches on case or crystal, alteration of strap/bracelet)
- Damage resulting from improper handling, lack of care, accidents, or unauthorized repairs
- Water damage if the crown was not properly secured

For warranty service, please retain your proof of purchase and contact Nautica customer support.

Customer Support

If you have any questions or require assistance with your Nautica watch, please visit the official Nautica website or contact their customer service department.

For more information, you may visit theNautica Brand Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BHKCZPZT

More documents and user manuals: **https://manuals.plus/**