RYOBI RTR18-0

RYOBI RTR18-0 18V Cordless Trim Router Instruction Manual

Model: RTR18-0
Brand: RYOBI

Introduction

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your RYOBI RTR18-0 18V Cordless Trim Router. Please read this manual thoroughly before using the tool.

Important Safety Information

Always wear eye protection and hearing protection when operating power tools. Ensure your work area is well-lit and clear of obstructions.

- Keep children and bystanders away while operating a power tool.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.
- Avoid accidental starting. Ensure the switch is in the off-position before connecting to battery pack, picking up or carrying the tool.
- Use the correct tool for your application.

Package Contents

The RYOBI RTR18-0 18V Cordless Trim Router package typically includes:

- RYOBI RTR18-0 18V Cordless Trim Router (Bare Tool)
- 6mm Collet

- 6.35mm (1/4") Collet
- 6.35mm Straight Cutter
- Parallel Guide
- Instruction Manual (this document)

Note: Battery and charger are not included and must be purchased separately.

Product Overview

The RYOBI RTR18-0 18V Cordless Trim Router is designed for precision woodworking tasks such as trimming laminate and veneer edges, and adding decorative edge profiles. It is part of the RYOBI ONE+ system, allowing compatibility with any ONE+ 18V battery.






Image: Front view of the RYOBI RTR18-0 18V Cordless Trim Router, showcasing its compact design and clear base.

Key features include micro depth adjustment for accurate cutting, a transparent base for stability and visibility, and an integrated LED light to illuminate the work area.

Setup

1. Attaching the Battery

Ensure the router's power switch is in the OFF position. Align the battery pack with the tool's battery port and slide it in until it clicks securely into place.



Image: Side view of the RYOBI RTR18-0 Cordless Trim Router with an 18V battery attached, ready for use.

2. Installing a Router Bit

1. Disconnect the battery before changing bits.
2. Loosen the collet nut using the provided wrench.
3. Insert the desired 6mm or 6.35mm (1/4") router bit into the collet, ensuring it is fully seated but not bottomed out.
4. Tighten the collet nut firmly with the wrench.

3. Adjusting Depth

The micro depth adjustment allows for precise control over cutting depth.

1. Loosen the depth adjustment lever.
2. Rotate the depth adjustment knob to raise or lower the router bit to the desired depth. Refer to the markings on the tool for guidance.
3. Tighten the depth adjustment lever to secure the setting.



Image: Close-up of the RYOBI RTR18-0 showing the depth adjustment mechanism and scale.

Operating the Router

1. Powering On/Off

To turn the router ON, slide the power switch to the 'I' (ON) position. To turn OFF, slide the switch to the 'O' (OFF) position.

2. Routing Techniques

Always ensure the workpiece is securely clamped. Hold the router firmly with both hands. For best results, make multiple shallow passes rather than one deep cut.



Image: A person using the RYOBI RTR18-0 Cordless Trim Router on a piece of wood, demonstrating proper handling.

3. Using the Parallel Guide

The parallel guide helps maintain a consistent distance from the edge of the workpiece. Attach the guide to the router base and adjust its position as needed.




Image: The RYOBI RTR18-0 Cordless Trim Router with the parallel guide accessory attached, illustrating its use for straight cuts.

Maintenance

Cleaning

Regularly clean the router and its ventilation openings with a soft brush or compressed air. Do not use solvents or abrasive cleaners.

Bit Care

Keep router bits sharp and clean for optimal performance. Replace dull or damaged bits immediately.

Storage

Store the router in a dry, secure location out of reach of children. Remove the battery pack when storing the tool for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Router does not start	Battery not charged or improperly inserted	Charge battery; ensure battery is fully seated
Poor cut quality	Dull bit; incorrect depth setting; too fast feed rate	Replace/sharpen bit; adjust depth; reduce feed rate
Excessive vibration	Loose bit; damaged bit; worn bearings	Tighten bit; replace bit; contact service center

Specifications

Feature	Detail
Model	RTR18-0
Voltage	18 Volts
No-load Speed	20,000 - 30,000 RPM
Collet Capacity	6mm & 6.35mm (1/4")
Item Weight	1.52 Kilograms (3.34 pounds)
Product Dimensions	8.82 x 4.09 x 6.18 inches
Power Source	Battery Powered
Material	Plastic

Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the official RYOBI website or contact their customer service.
You can find more information and register your product at:www.ryobitools.com




Image: An extensive display of various RYOBI ONE+ tools, illustrating the breadth of the compatible system.

© 2025 RYOBI. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question