Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY MR22GA

User Manual for Allimity MR22GA Voice Replaced Remote Control

Model: MR22GA | Brand: ALLIMITY

Introduction

This manual provides comprehensive instructions for the Allimity MR22GA Voice Replaced Remote Control. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your remote control. This remote is designed as a direct replacement for specific LG TV models, offering seamless functionality without complex programming.

Product Overview





Figure 1: Front view of the Allimity MR22GA remote control, showing all buttons including number pad, navigation, volume, channel, and dedicated streaming service buttons.



Figure 2: Angled view of the remote control, highlighting its ergonomic design and button layout.

The Allimity MR22GA remote control is designed to replicate the functionality of your original LG TV remote. It features a standard button layout for easy navigation, channel selection, volume control, and direct access to popular streaming services. The remote also includes a dedicated microphone button for voice control functionality.

Key Features:

- **Voice Control:** Integrated microphone for voice commands (requires pairing).
- **No Programming Required:** Functions immediately upon battery insertion for basic controls.
- **Dedicated Buttons:** Quick access to Netflix, Prime Video, Disney+, and L Channels.
- **Ergonomic Design:** Comfortable to hold and easy to use.

Setup

1. Battery Installation



Figure 3: Rear view of the remote control with the battery cover

removed, showing the battery compartment.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two (2) new 1.5V AAA Alkaline batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery cover by sliding it upwards until it clicks into place.

The remote control is designed to work immediately for basic functions once batteries are installed. No additional programming is required for standard TV control.

2. Pairing for Voice Function (Optional)



Figure 4: The remote control with the microphone button prominently displayed, indicating voice control capability.

To utilize the voice control feature, the remote must be paired with your LG TV. The pairing process typically involves the following steps, though specific instructions may vary slightly depending on your LG TV model:

1. Ensure your LG TV is powered on.
2. Point the remote control towards the TV.
3. Press and hold the **HOME** button and the **BACK** button simultaneously for approximately 5-10 seconds until a pairing message appears on your TV screen.

4. Follow any on-screen prompts to complete the pairing process.

Once successfully paired, the voice function will be active, allowing you to use voice commands for TV control.

Operating Instructions

The Allimity MR22GA remote control provides intuitive access to your LG TV's functions. Below are general operating guidelines:

- **Power Button ( ):** Turns the TV on or off.
- **Number Pad (0-9):** Directly enter channel numbers.
- **Volume Up/Down:** Adjusts the TV volume.
- **Channel Up/Down:** Changes TV channels.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates menus and confirms selections.
- **Back Button:** Returns to the previous screen or menu.
- **Home Button:** Accesses the TV's home screen or smart features.
- **Microphone Button:** Activates voice control (after pairing). Press and speak your command.
- **Dedicated Streaming Buttons (Netflix, Prime Video, Disney+, L Channels):** Provides direct access to these applications.

Compatible LG TV Models

This Allimity MR22GA remote control is compatible with a wide range of LG TV models. A partial list of compatible models includes:

55UQ7070ZUE
65UQ7590PUB
65UQ7570PUJ
65UQ7570PUA28LM400B-PU
OLED42C2PUA
75QNED85AQA
50UQ9000PUD
55NANO75UQA
32LQ630BPUA
43NANO75UQA
43UN7000PUB

Note: This list is not exhaustive. If your LG TV model is not listed, please refer to your TV's user manual or contact customer support to confirm compatibility.

Maintenance

Battery Replacement

When the remote control's performance degrades or it stops responding, it is likely time to replace the batteries. Follow the battery installation steps outlined in the "Setup" section.

- Always use new 1.5V AAA Alkaline batteries.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

Troubleshooting

Problem	Possible Cause	Solution
Remote control not responding.	Batteries are dead or incorrectly inserted.	Replace batteries with new ones, ensuring correct polarity.
Voice function not working.	Remote is not paired with the TV.	Perform the voice function pairing process as described in the "Setup" section.
Remote works intermittently.	Low battery power or obstruction between remote and TV.	Replace batteries. Ensure no objects are blocking the signal path to the TV's IR receiver.
Some buttons not working.	Specific button malfunction or TV setting issue.	Check if other buttons work. If only specific buttons fail, the remote may be faulty. Ensure TV settings are not interfering with button functions.

Specifications

Feature	Detail
Model Number	MR22GA
Brand	ALLIMITY
Power Supply	2 x 1.5V AAA Alkaline Batteries (Not Included)
Product Dimensions	7 x 1.5 x 1 inches
Item Weight	2 ounces
Color	Black
Special Feature	No Programming Required (for basic functions)
Compatible Devices	LG Televisions (specific models listed in manual)

© 2024 ALLIMITY. All rights reserved.
For further assistance, please refer to your LG TV's user manual or contact the manufacturer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BHSP1G9B

More documents and user manuals: **https://manuals.plus/**