HomeSpot HS-JY100-NR

HomeSpot Noise Reduction Wireless Neckband Headphones

Model: HS-JY100-NR

Introduction

The HomeSpot Noise Reduction Wireless Neckband Headphones are designed to provide high-quality audio and effective hearing protection in noisy environments. Featuring advanced noise reduction capabilities, comfortable design, and long battery life, these headphones are ideal for work safety and extended listening.

Key Features

- **Effective Noise Protection:** 27dB NRR (Noise Reduction Rating) for significant noise reduction.
- **Advanced Bluetooth 5.1 Connectivity:** Low latency, faster pairing, enhanced audio transmission, and up to 66 feet range.
- **Lightweight Neckband Design:** Flexible and comfortable for all-day wear with a secure in-ear fit.
- **Clear Calls with CVC Noise Cancelling Mic:** Reduces background noise for improved call clarity.
- **High-Quality Audio:** Deep bass and crystal-clear treble with Qualcomm aptX HD high-resolution audio support.
- **Long Battery Life:** Up to 20 hours of playtime on a single charge.



The HomeSpot Noise Reduction Wireless Neckband Headphones, featuring a black neckband, blue wires, and orange ear tips.

Setup

1. **Charge the Headphones:** Before first use, fully charge the headphones using the provided USB-C cable. Connect the cable to the charging port on the neckband and a compatible USB power source. A full charge takes approximately 1-2 hours.

2. **Power On:** Press and hold the multi-function button on the neckband until the LED indicator light flashes, indicating the headphones are powered on and in pairing mode.
3. **Pair with Your Device:**
    - Enable Bluetooth on your smartphone, tablet, or other Bluetooth-enabled device.
    - Search for available Bluetooth devices.
    - Select "HS-JY100-NR" from the list of devices.
    - Once connected, the LED indicator will stop flashing and remain solid.



The headphones feature Bluetooth 5.1 for stable and fast signal transmission up to 66 feet.

Operating Instructions

The neckband features easy-to-use controls for managing your audio and calls.

- **Power On/Off:** Press and hold the multi-function button.
- **Play/Pause:** Short press the multi-function button.
- **Volume Up/Down:** Use the '+' and '-' buttons.
- **Next Track:** Long press the '+' button.
- **Previous Track:** Long press the '-' button.
- **Answer/End Call:** Short press the multi-function button during an incoming call.
- **Reject Call:** Long press the multi-function button during an incoming call.
- **Activate Voice Assistant:** Double-press the multi-function button.



Detailed view of the control buttons on the neckband for easy operation.

Your browser does not support the video tag.

Official product video demonstrating the features and usage of the HomeSpot Noise Reduction Wireless Neckband Headphones.

Maintenance

- **Cleaning:** Regularly wipe the ear tips and neckband with a soft, dry cloth. For deeper cleaning, remove the silicone ear tips and wash them with mild soap and water, then dry thoroughly before reattaching.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tangling the wires.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in use for extended periods.
- **Avoid Water Exposure:** The headphones are not water-resistant. Avoid exposure to rain, sweat, or other liquids to prevent damage.

Troubleshooting

Problem	Possible Cause	Solution
Headphones won't power on	Low battery	Charge the headphones fully.
Cannot pair with device	Bluetooth not enabled or headphones not in pairing mode	Ensure Bluetooth is on and headphones are flashing (pairing mode). Restart both devices.
Poor sound quality	Weak Bluetooth connection or improper ear tip fit	Move closer to your device. Adjust ear tips for a secure seal.
Microphone not working	Microphone blocked or software issue	Ensure microphone is clear. Restart headphones and device.

Specifications

- **Model Name:** HS-JY100-NR
- **Noise Control:** Sound Isolation (27dB NRR)
- **Connectivity Technology:** Wireless (Bluetooth 5.1)
- **Wireless Range:** Up to 66 Feet (20m)
- **Battery Life:** Up to 20 Hours Playtime
- **Charging Time:** 1-2 Hours
- **Material:** Silicone eartips, Plastic
- **Item Weight:** 3.17 Ounces
- **Water Resistance Level:** Not Water Resistant
- **Frequency Range:** 20 Hz to 20,000 Hz
- **Impedance:** 16 Ohm

Warranty and Support

HomeSpot products typically come with a manufacturer's warranty. Please refer to the warranty card included in your

product packaging for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact HomeSpot customer service through their official website or the contact information provided in your product documentation.

You can also visit the HomeSpot Store on Amazon for more information and support resources.