Bajaj 680101

Bajaj RCX 1.8L DLX Rice Cooker Instruction Manual

Introduction

This manual provides essential information for the safe and efficient operation of your Bajaj RCX 1.8L DLX Rice Cooker. Please read these instructions thoroughly before first use and retain them for future reference. This appliance is designed for automatic rice cooking, featuring a 1.8-liter capacity and 700 watts of power, ensuring perfectly cooked rice without overcooking or undercooking. It includes a durable stainless steel lid and a thermal fuse for enhanced safety.

Important Safety Instructions

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is for household use only.
- Ensure the inner cooking bowl is properly seated before operating.
- Do not block steam vents during operation.

Product Components

Your Bajaj RCX 1.8L DLX Rice Cooker package includes the following items:

- **Rice Cooker Unit:** The main appliance body with heating element and controls.
- **Cooking Bowl:** The removable inner pot for cooking rice.
- **Detachable Power Cord:** For connecting the cooker to a power source.
- **Measuring Cup:** For accurate measurement of rice and water.
- **Trivet:** A perforated plate used for steaming or to prevent sticking.
- **Spatula:** For stirring and serving rice.
- **Stainless Steel Lid:** Covers the cooking bowl during operation.
- **Warranty Card:** Contains warranty information.
- **Instruction Manual:** This document.

Component Visuals



The complete Bajaj RCX 1.8L DLX Rice Cooker with its stainless steel lid in place.



The rice cooker with the inner cooking bowl inserted, showing measurement markings.



Close-up view of the removable inner cooking bowl with capacity markings.



An exploded view showing the rice cooker unit, inner bowl, lid, trivet, measuring cup, and spatula.



The perforated trivet, used for steaming or as a base.



The transparent measuring cup with markings in cups and milliliters.



The serving spatula, designed for use with the inner cooking bowl.

Setup and First Use

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the inner cooking bowl, stainless steel lid, measuring cup, trivet, and spatula with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the rice cooker unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the rice cooker on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources. Ensure adequate ventilation around the unit.
4. **Power Connection:** Insert the detachable power cord into the appliance's power inlet, then plug the other end into a suitable electrical outlet.

Operating Instructions

Cooking Rice

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of rice. Rinse the rice thoroughly under cold water until the water runs clear.
2. **Add Water:** Place the rinsed rice into the inner cooking bowl. Add the appropriate amount of water. A common ratio is 1 cup of rice to 1.5-2 cups of water, but this may vary based on rice type and personal preference. The inner bowl has markings to guide water levels.
3. **Insert Bowl:** Place the inner cooking bowl into the main rice cooker unit, ensuring it sits correctly on the heating plate.
4. **Cover:** Place the stainless steel lid securely on the rice cooker.
5. **Start Cooking:** Plug in the power cord. Press the "COOK" switch or lever down. The "COOK" indicator light (red) will illuminate, indicating that cooking has started.
6. **Automatic Keep Warm:** Once the rice is cooked, the cooker will automatically switch to "KEEP WARM" mode. The "WARM" indicator light (orange) will illuminate. This feature prevents overcooking and keeps the rice warm until serving.
7. **Resting Period:** For best results, allow the rice to rest in the "KEEP WARM" mode for 10-15 minutes after cooking before serving. This allows the moisture to distribute evenly.
8. **Serve:** Use the provided spatula to fluff and serve the rice.
9. **Unplug:** After serving, unplug the rice cooker from the power outlet.

Product Features Overview

Your browser does not support the video tag.

This video demonstrates the key features of the Bajaj RCX 1.8L DLX Rice Cooker, including its capacity, automatic cooking function, and stainless steel lid. It highlights how the cooker prevents overcooking or undercooking and provides extra safety with its thermal fuse.

Maintenance and Cleaning

Proper cleaning and maintenance will ensure the longevity and optimal performance of your rice cooker.

- **Always unplug** the rice cooker from the power outlet and allow it to cool completely before cleaning.
- **Inner Cooking Bowl and Lid:** Wash the inner cooking bowl, stainless steel lid, trivet, measuring cup, and spatula with warm, soapy water. Use a soft sponge or cloth to avoid scratching the non-stick surface of the inner bowl. Rinse thoroughly and dry completely. These parts are generally not dishwasher safe unless specified otherwise (hand wash is recommended).
- **Exterior:** Wipe the exterior of the rice cooker unit with a soft, damp cloth. Do not use abrasive cleaners or scouring pads. Never immerse the main unit, power cord, or plug in water or any other liquid.
- **Heating Plate:** Periodically check the heating plate at the bottom of the main unit for any food debris. Wipe it clean with a damp cloth. Do not use sharp objects to scrape off residue, as this may damage the heating element.
- **Storage:** Store the clean and dry rice cooker in a cool, dry place. You can store the measuring cup, spatula, and trivet inside the cooking bowl for convenience.

Troubleshooting

If you encounter issues with your rice cooker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Rice cooker does not turn on.	No power supply; power cord not properly connected; thermal fuse tripped.	Check if the power cord is securely plugged into both the cooker and the wall outlet. Ensure the wall outlet is functional. If the thermal fuse has tripped due to overheating, allow the unit to cool down completely. If the problem persists, contact customer support.
Rice is undercooked or too hard.	Insufficient water; lid not properly sealed; cooking cycle interrupted.	Ensure the correct rice-to-water ratio is used. Make sure the lid is securely closed during cooking. Do not open the lid frequently during the cooking cycle. Allow rice to rest in "KEEP WARM" mode for 10-15 minutes after cooking.
Rice is overcooked or mushy.	Too much water; rice not rinsed properly.	Reduce the amount of water used for cooking. Rinse rice thoroughly before cooking to remove excess starch.
Rice sticks to the bottom of the bowl.	Not enough water; bowl not clean; prolonged "KEEP WARM" time.	Ensure adequate water. Clean the inner bowl thoroughly before each use. Avoid keeping rice in "KEEP WARM" mode for excessively long periods.
Steam leaks from the lid.	Lid not properly seated; lid gasket (if present) damaged or dirty.	Ensure the lid is placed correctly and securely on the cooking bowl. Clean the lid and check for any obstructions.

Specifications

Feature	Detail
Brand	Bajaj
Model Name	680101
Capacity	1.8 litres
Wattage	700 Watts
Voltage	240 Volts
Power Source	Corded Electric
Material Type	Stainless Steel (Lid)
Colour	White
Product Dimensions (D x W x H)	13.2D x 11.2W x 6.1H Centimeters
Item Weight	1600 Grams
Special Features	Automatic Cooking, Thermal Fuse for safety
Product Care Instructions	Hand Wash

Warranty and Support

Your Bajaj RCX 1.8L DLX Rice Cooker comes with the following warranty:

- **Product Warranty:** 2 years from the date of purchase.
- **Heating Coil Warranty:** 5 years from the date of purchase.

For warranty claims, technical assistance, or any product-related inquiries, please contact Bajaj customer care:

Email: customercare@bajajelectricals.com

Phone: 022-41280000

Manufacturer: M/S. PMB Enterprises, AT: Dabua Pali Road, Near Sakshi Dharam Kanta, Faridabad - 121001, Haryana, India

Importer/Packer: M/S. Bajaj Electricals Ltd, #45/47 Veer Nariman Road, Mumbai - 40001

© 2024 Bajaj Electricals Ltd. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question