MEUBLE COSY WHALEN 160

MEUBLE COSY WHALEN 160 Extensible Dining Table User Manual

Model: WHALEN 160

Introduction

Thank you for choosing the MEUBLE COSY WHALEN 160 Extensible Dining Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new dining table. Please read these instructions carefully before use and retain them for future reference.
This extensible dining table is designed for versatility, suitable for both kitchen and dining areas. Its clean design, featuring a black oak top and robust metal structure, complements various interior styles.

Safety Warnings

- **Always use both hands** when extending or retracting the table to ensure smooth operation and prevent injury.
- Do not exceed the recommended maximum weight of **100 kg (220 lbs)** on the tabletop.
- For enhanced stability, consider securing the table to a wall or floor, especially if children are present, to prevent accidental tipping.
- Keep fingers and other body parts clear of moving parts during assembly and when adjusting the table's extension mechanism.
- Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten as necessary.
- Avoid placing hot items directly on the table surface. Use coasters or protective mats.

Setup and Assembly

The MEUBLE COSY WHALEN 160 table is designed for straightforward assembly. It comes with numbered parts and easy-to-follow instructions. We recommend assembling the table with two people.

Required Tools (Not Included):

- Phillips head screwdriver
- Allen wrench (usually included with hardware)

Assembly Steps:

1. Unpack all components and verify against the parts list provided in the packaging. Place all parts on a soft, clean surface to

prevent scratches.

2. Attach the table legs to the main tabletop frame using the provided screws and Allen wrench. Ensure the tapered steel legs are oriented correctly.
3. Secure the extension mechanism components to the underside of the tabletop, following the numbered diagrams.
4. Carefully attach the extensible leaves to the main tabletop, ensuring they slide smoothly into place.
5. Tighten all fasteners. Do not overtighten.
6. Place the adjustable rubber pads on the bottom of each leg to protect your floor and ensure stability.



Figure 1: Table dimensions and extension mechanism overview.



Figure 2: Table in a partially extended configuration, ready for use.

Operating Instructions

Extending the Table:

1. Ensure there is sufficient space around the table for extension.
2. Gently pull the two halves of the tabletop apart from the center. Use both hands to ensure even movement.
3. Locate the extension leaf(s) stored within or separately.
4. Carefully place the extension leaf(s) into the gap created. Ensure they are properly aligned with the main tabletop.
5. Push the two halves of the tabletop back together until they are flush with the extension leaf(s) and securely locked.

Retracting the Table:

1. Reverse the extension process. Unlock the tabletop halves if necessary.
2. Gently pull the tabletop halves apart to create a gap.

3. Remove the extension leaf(s) and store them safely.
4. Push the two main tabletop halves back together until they meet and are securely locked.



Figure 3: Demonstrating the table extension process.



Figure 4: The table in its fully extended position.

Maintenance

Proper care will ensure the longevity and appearance of your MEUBLE COSY dining table.

- **Cleaning:** Wipe the table surface with a damp cloth and a mild, neutral detergent. Avoid abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish. Dry immediately with a clean, soft cloth.
- **Spills:** Clean up spills immediately to prevent staining or damage to the MDF surface.
- **Protection:** Use placemats, coasters, and trivets to protect the tabletop from heat, moisture, and scratches.
- **Legs:** Periodically check the tightness of all leg fasteners and re-tighten if necessary. Ensure the rubber pads on the feet are intact to protect your floor.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.



Figure 5: Close-up of the table surface texture.

Troubleshooting

If you encounter any issues with your dining table, please refer to the following common solutions:

Problem	Possible Cause	Solution
Table is wobbly	Uneven floor; loose leg fasteners	Adjust the leveling pads on the bottom of the legs. Check and tighten all leg screws.
Extension mechanism is stiff	Dust/debris in tracks; misalignment	Clean the extension tracks. Ensure the leaves are aligned correctly before pushing together. Apply a silicone-based lubricant if necessary (avoid oil-based).
Scratches on floor	Missing or worn leg pads	Ensure all legs have their protective rubber pads. Replace worn pads if needed.

Problem	Possible Cause	Solution
Tabletop discoloration	Prolonged sun exposure; harsh cleaners	Relocate the table away from direct sunlight. Use only mild, neutral detergents for cleaning.

Specifications

Feature	Detail
Brand	MEUBLE COSY
Model Number	WHALEN 160
Color	Black
Product Dimensions (Compact)	120 cm (L) x 80 cm (W) x 75 cm (H)
Product Dimensions (Extended)	160 cm (L) x 80 cm (W) x 75 cm (H)
Material	Engineered Wood (MDF), Metal
Features	Extensible
Item Weight	26.5 Kilograms
Maximum Weight Recommendation	100 Kilograms
Frame Material	Metal
Top Material Type	Engineered Wood
Recommended Uses	Kitchen, Dining
Shape	Rectangular

Warranty and Support

For warranty information or customer support, please refer to the retailer or your purchase documentation. Information regarding the availability of spare parts is not provided at this time.
If you have any questions or require assistance, please contact MEUBLE COSY customer service through the platform where you purchased this product.

© 2025 MEUBLE COSY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question