ZdalaMit NF600UD

ZdalaMit NF600UD Replacement Remote Control User Manual

For Sylvania LCD TV Models: LC155SL8, LC155SL8P, LC200SL8, LC200SL8A, LC200SL8B

Introduction

This manual provides instructions for the setup, operation, and maintenance of your ZdalaMit NF600UD replacement remote control. This remote is specifically designed to be compatible with various Sylvania LCD TV models, including LC155SL8, LC155SL8P, LC200SL8, LC200SL8A, and LC200SL8B. No programming is required for its use; simply install the batteries, and it will be ready to operate your compatible television.

Setup

Battery Installation

To begin using your remote control, you must first install the batteries.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) 1.5V AA Alkaline batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.





Image: Front view of the ZdalaMit NF600UD replacement remote control, showing all buttons and its ergonomic design. This image

illustrates the general appearance of the remote.

Operating Instructions

Once batteries are installed, the remote control is ready for immediate use with compatible Sylvania LCD TV models. No additional programming or pairing is required.

Basic Functions

- **POWER:** Turns the television on or off.
- **INPUT:** Selects the video input source (e.g., HDMI, AV).
- **MUTE:** Mutes or unmutes the television audio.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes the television channel.
- **Number Buttons (0-9, +100, ENT):** Directly select channels.
- **DISPLAY:** Shows on-screen information.
- **SCREEN MODE:** Adjusts screen display modes.
- **CH. RETURN:** Returns to the previously viewed channel.
- **SLEEP:** Sets a sleep timer for the television.
- **AUDIO:** Adjusts audio settings or modes.
- **SETUP:** Accesses the TV's main menu for settings adjustments.
- **Navigation (Up, Down, Left, Right, ENTER):** Navigates through on-screen menus and confirms selections.
- **RETURN:** Goes back to the previous menu or screen.



Image: Angled view of the ZdalaMit NF600UD replacement remote control, highlighting the button layout and ergonomic grip. This perspective provides a clearer view of the side profile.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store the remote in a cool, dry place away from direct sunlight.
- **Avoid Damage:** Do not drop the remote control, expose it to extreme temperatures, or immerse it in water.

Troubleshooting

- **Remote not responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new 1.5V AA Alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective range and line of sight of the TV.
- **Some buttons not working:**
  - This remote is a direct replacement and should work without programming. If specific buttons are not functioning, ensure your TV model is listed as compatible.
  - Clean the remote control surface, especially around the non-working buttons, to remove any debris that might be obstructing them.
- **TV not turning on/off:**
  - Verify that the TV itself is plugged into a power outlet and is receiving power.
  - Try using the power button directly on the TV to confirm it is operational.

Specifications

Model	NF600UD
Brand	ZdalaMit
Compatible TV Models	Sylvania LCD TV LC155SL8, LC155SL8P, LC200SL8, LC200SL8A, LC200SL8B
Power Supply	2 x 1.5V AA Alkaline Batteries (not included)
Product Dimensions	5 x 1.5 x 0.5 inches (approximately)
Item Weight	2 ounces (approximately)
Special Feature	Ergonomic design

Warranty and Support

This product is designed for reliable performance. For any questions or assistance regarding your ZdalaMit NF600UD replacement remote control, please refer to the seller's contact information provided at the point of

purchase. While specific warranty details are not included in this manual, standard consumer rights apply. Please retain your purchase receipt for any warranty claims.
For further support, you may also visit the ZdalaMit brand page or contact their customer service through the platform where the product was purchased.

© 2025 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question