Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Red by Kiss BD

RED by KISS 2000 Ceramic Detangler Hair Dryer BD User Manual

Model: BD

1. Important Safety Information

Please read all instructions before using this appliance. When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER:** Keep away from water. As with most electrical appliances, electrical parts are electrically live even when the switch is off.
- Always unplug this appliance immediately after using.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If an appliance falls into water, unplug it immediately. Do not reach into the water.
- **WARNING:** To reduce the risk of burns, electrocution, fire, or injury to persons.
- An appliance should never be left unattended when plugged in.
- Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended household use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- Do not direct hot air towards eyes or other heat-sensitive areas.

- Attachments may be hot during use. Allow them to cool before handling.
- Do not place appliance on any surface while it is operating.
- While using the appliance, keep your hair away from the air inlets.

2. Product Overview

The RED by KISS 2000 Ceramic Detangler Hair Dryer is designed for efficient hair drying and detangling. It features Tourmaline Ceramic Technology to reduce frizz and seal in moisture, promoting smoother, healthier-looking hair. This dryer is suitable for all hair types, including curly, straight, thin, or thick.



Image 1: RED by KISS 2000 Ceramic Detangler Hair Dryer with included attachments.

Key Features:

- **Tourmaline Ceramic Technology:** Emits negative ions for smoother, frizz-free hair and moisture retention.

- **Multiple Detangler Piks:** Includes one patented double-layered detangler pik, one single-layered detangler pik, and one air concentrator.
- **3 Temperature Settings:** Adjustable heat settings to suit various hair types and styling needs.
- **Hanger Loop:** For convenient storage.
- **Tangle-Free 360° Swivel Cord:** Designed for ease of use and maneuverability.



Image 2: Detailed view of the hair dryer's temperature settings, hanger loop, and swivel cord.

3. Setup

1. **Unpack:** Carefully remove the hair dryer and all accessories from the packaging.
2. **Inspect:** Check the appliance for any signs of damage. Do not use if damaged.
3. **Attach Desired Pik/Nozzle:** Select the appropriate detangler pik or air concentrator for your styling needs. Align the attachment with the nozzle of the hair dryer and push it firmly into place until it clicks securely. Ensure the attachment is cool before handling and attaching/detaching.



Image 3: The three bonus detangler piks included with the hair dryer.

4. Operating Instructions

1. **Plug In:** Ensure the hair dryer is switched to the 'OFF' position before plugging it into a standard electrical outlet.
2. **Select Temperature:** Use the temperature switch on the handle to select your desired heat setting: **COLD**, **LOW**, or **HIGH**.
3. **Select Speed:** The dryer also features two speed settings. Adjust the switch to control the airflow intensity.
4. **Drying and Styling:** Direct the airflow towards your hair. For detangling, use the detangler pik attachments by gently combing through sections of your hair while drying. For concentrated drying, use the air concentrator.
5. **Cool Shot:** Use the COLD setting to set your style with a burst of cool air.
6. **Turn Off:** After use, switch the hair dryer to the 'OFF' position and unplug it from the outlet. Allow the appliance to cool down before storing.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the RED by KISS 2000 Ceramic Detangler Hair Dryer and its features.

5. Maintenance

Proper maintenance ensures the longevity and optimal performance of your hair dryer.

- **Cleaning the Air Filter:** Regularly check and clean the rear air filter to prevent lint and hair buildup, which can restrict airflow and cause overheating. To clean, ensure the dryer is unplugged and cool. Gently twist or pull off the rear filter cover (refer to product design for specific removal method). Use a soft brush or vacuum cleaner to remove any accumulated debris. Replace the filter cover securely.
- **Cleaning the Exterior:** Wipe the exterior of the hair dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the hair dryer in a cool, dry place. Use the integrated hanger loop for convenient storage. Do not wrap the power cord tightly around the appliance, as this can damage the cord.
- **Cord Care:** Avoid twisting, bending, or straining the power cord, especially at the plug connection.

6. Troubleshooting

If you encounter issues with your RED by KISS 2000 Ceramic Detangler Hair Dryer, refer to the following common solutions:

Problem	Possible Cause	Solution
Dryer does not turn on.	No power supply; Faulty outlet; Appliance switch is off.	Ensure the dryer is securely plugged into a working electrical outlet. Check if the outlet is functional by plugging in another appliance. Verify the power switch on the dryer is in the 'ON' position.
Low airflow or overheating.	Blocked air intake filter; Internal overheating protection activated.	Unplug the dryer and allow it to cool down. Clean the rear air filter as described in the Maintenance section. Ensure air vents are not blocked during use.
Hair is still frizzy after drying.	Incorrect heat setting; Improper use of detangler pik; Product application.	Ensure you are using the appropriate heat setting for your hair type. Utilize the Tourmaline Ceramic Technology by drying hair in sections with the detangler pik to smooth cuticles. Consider using anti-frizz hair products.
Attachments do not stay on.	Attachment not properly secured; Wear and tear.	Ensure the attachment is firmly pushed onto the nozzle until it clicks. If the issue persists, the attachment or dryer nozzle may be worn.

If the problem persists after attempting these solutions, please contact customer support.

7. Specifications

Feature	Detail
Model Name	Ceramic Detangler Blow Dryer
Model Number	BD
Brand	Red by Kiss
Wattage	1500 watts

Feature	Detail
Power Source	Corded Electric
Temperature Settings	3 (Cold, Low, High)
Number of Speeds	2
Technology	Tourmaline Ceramic
Included Components	2 Detangler Piks, 1 Concentrator
Product Dimensions (D x W x H)	3.6" x 7" x 11"
Item Weight	1.7 Pounds (0.77 Kilograms)
Hair Type Compatibility	All hair types (curly, straight, thin, thick)
UPC	649674066358

8. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product packaging or visit the official Red by Kiss website. Keep your purchase receipt as proof of purchase for any warranty claims.

Manufacturer: KISS

Date First Available: November 13, 2019

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BKC7M6M9

More documents and user manuals: **https://manuals.plus/**