Proscenic P10 Pro

Proscenic P10 Pro Cordless Vacuum Cleaner User Manual

Model: P10 Pro | Brand: Proscenic

Introduction

Thank you for choosing the Proscenic P10 Pro Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new vacuum cleaner. Please read this manual thoroughly before first use and keep it for future reference.



Figure 1: Proscenic P10 Pro Cordless Vacuum Cleaner and included accessories.

Product Components

The Proscenic P10 Pro comes with several components designed for versatile cleaning. Familiarize yourself with each part:

- **Main Unit:** Contains the motor, dustbin, and control panel.

- **Extension Tube:** Connects the main unit to the floor brush for upright cleaning.
- **Motorized Floor Brush:** Equipped with a roller brush for effective cleaning on various surfaces.
- **Battery Pack:** Removable 8*2000mAh battery for cordless operation.
- **Crevice Nozzle:** For narrow gaps and corners.
- **Round Brush:** For dusting and delicate surfaces.
- **Mini Motorized Brush:** Ideal for pet hair and upholstery.
- **Wall Mount:** For convenient storage and charging.
- **Power Adapter:** For charging the battery.



Figure 2: Exploded view of the Proscenic P10 Pro components.

Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Battery Installation:** Insert the battery pack into the main unit until it clicks into place. Ensure it is securely seated.



Figure 3: Battery installation.

3. **Assembly:**
    - For upright cleaning, connect the extension tube to the main unit, then attach the motorized floor brush to the other end of the extension tube.
    - For handheld cleaning, attach desired accessories (crevice nozzle, round brush, mini motorized brush) directly to the main unit.
4. **Initial Charge:** Before first use, fully charge the battery. Connect the power adapter to the charging port on the main unit or the wall mount, then plug it into a power outlet. The LED screen will indicate charging status. A full charge takes approximately 2.5 hours.

Operating Instructions

Power On/Off and Mode Selection

The P10 Pro features an intuitive LED touch screen for control.

1. **Power On:** Press the power button on the handle to turn on the vacuum cleaner.
2. **Mode Selection:** Use the "MODE" button on the LED touch screen to cycle through the three adjustable suction modes:
    - **ECO Mode:** For light cleaning and extended runtime (up to 52 minutes). Suction power: 7.5±1.0 KPa.
    - **AUTO Mode:** Automatically adjusts suction power based on floor type (17-31 minutes runtime). Suction power: 11.5-18.5 KPa.
    - **MAX Mode:** For powerful cleaning of stubborn dirt (12±2 minutes runtime). Suction power: 30±1.0 KPa.



Figure 4: LED Touch Screen for power and mode control.

3. **Power Off:** Press the power button again to turn off the vacuum cleaner.

Cleaning Tips

- For optimal performance, select the appropriate suction mode for the surface being cleaned.
- The motorized floor brush is effective on both hardwood floors and carpets. It features anti-tangle technology to prevent hair from wrapping around the brush.



Figure 5: Anti-tangle technology on the roller brush.

- Utilize the various attachments for specialized cleaning tasks:
  - **Crevice Nozzle:** Reaches tight spaces like between couch cushions or car seats.
  - **Round Brush:** Ideal for delicate surfaces, curtains, and keyboards.
  - **Mini Motorized Brush:** Excellent for removing pet hair from upholstery and stairs.



Figure 6: Versatile attachments for different cleaning scenarios.

- The vacuum head is designed to be flexible, allowing for easy maneuverability under furniture and around obstacles.



Figure 7: Flexible vacuum head for easy cleaning.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your Proscenic P10 Pro.

Dustbin Emptying

- Empty the dustbin after each use or when the MAX fill line is reached.
- Press the dustbin release button to detach it from the main unit.
- Open the dustbin lid and empty contents into a trash bin.

Filter Cleaning and Replacement

The P10 Pro features a multi-stage filtration system including a metal filter, sponge filter, and HEPA filter. All filters are washable.

1. **Disassembly:** Twist and pull to remove the filter assembly from the dustbin. Separate the metal, sponge, and HEPA filters.



Figure 8: Filter assembly components.

2. **Washing:** Rinse all filter components under running water until clean. Do not use detergents.
3. **Drying:** Allow all filters to air dry completely for at least 24 hours before reassembling. Ensure they are completely dry to prevent mold or damage to the vacuum.
4. **Reassembly:** Reassemble the filters in reverse order and place them back into the dustbin.
5. **Frequency:** Clean filters regularly, ideally after every 5 uses, or more frequently if vacuuming fine dust. Replace HEPA filters every 3-6 months depending on usage.



Figure 9: Emptying the dustbin and washing filters.

Roller Brush Cleaning

- Periodically check the roller brush for tangled hair or debris.
- Remove the roller brush from the floor head (refer to the product diagram for release mechanism).
- Use scissors or a brush to remove any tangled hair or fibers.
- Reinsert the roller brush securely.

Troubleshooting

If you encounter issues with your Proscenic P10 Pro, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is not charged or not properly installed.	Ensure battery is fully charged and securely inserted.
Low suction power.	Dustbin is full; filters are clogged; roller brush is tangled; blockage in tube/nozzle.	Empty dustbin. Clean or replace filters. Remove tangled hair from roller brush. Check for and clear any blockages.

Problem	Possible Cause	Solution
Vacuum stops suddenly during operation.	Battery is depleted; motor overheating due to blockage.	Recharge battery. Check for and clear any blockages, then allow motor to cool down.
LED screen displays an error code.	Internal malfunction or specific issue.	Refer to the specific error code on the screen for detailed instructions, or contact customer support.

If the problem persists after attempting these solutions, please contact Proscenic customer service.

Specifications

Feature	Detail
Brand	Proscenic
Model	P10 Pro
Power/Wattage	400 watts
Voltage	20 Volts
Suction Power (Max)	30,000 Pa
Runtime (ECO Mode)	Up to 52 minutes
Noise Level	78 dB
Filter Type	Multi-stage (Metal, Sponge, HEPA)
Special Features	LED touchscreen, HEPA filtration, anti-tangle roller brush, powerful suction
Item Weight	4.54 kg
Surface Recommendation	Hard Floor, Carpet

Warranty and Support

Proscenic provides a **12-month warranty** from the date of purchase. This warranty covers all quality-related issues and offers a replacement or full refund.
For any questions, suggestions, or warranty claims, please contact our customer service team:

- **Phone Service:** +1(833) 313 1310 (Monday - Friday, 6am - 3pm ET)
- Please have your product model and purchase date ready when contacting support.

© 2024 Proscenic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question