Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Colorcool A3

Colorcool 32GB Mp3 Player Instruction Manual

Model: A3
Brand: Colorcool

Introduction

Thank you for purchasing the Colorcool 32GB Mp3 Player. This portable music player is designed to provide a high-quality audio experience with versatile features, including Bluetooth 5.3 connectivity, FM radio, voice recording, and expandable storage. This manual will guide you through the setup, operation, and maintenance of your new device.

What's in the Box

- Bluetooth Mp3 player
- Wire headset
- USB type-C cable
- User manual

Product Overview

The Colorcool A3 Mp3 Player is a compact and feature-rich device. Below are its main components and features:

Compact Design with Clip



The MP3 player features a durable clip on the back, allowing it to be securely attached to clothing or bags, ideal for sports and on-the-go use. Its compact size (1.57 x 0.67 x 2.36 inches) and light weight (1.13 ounces) make it highly portable.

Full-Touch Screen & USB-C Port



Equipped with a full-touch screen for easy navigation and a built-in USB Type-C charging port for faster charging and stable data transmission.

Bluetooth 5.3 Connectivity



Features the latest Bluetooth 5.3 for quick pairing with Bluetooth speakers and earbuds, offering low power consumption. (Note: Cannot pair with smartphones).

Expandable 32GB Memory



Comes with 32GB internal memory and supports Micro SD cards up to 128GB, providing ample space for your music library.

Setup

1. Charging the Device

Before first use, fully charge your MP3 player using the provided USB Type-C cable. Connect the cable to the device's USB-C port and the other end to a USB power adapter (not included) or a computer's USB port. The battery indicator on the screen will show charging status.

2. Powering On/Off

Press and hold the power button (located on the side, typically red) until the screen lights up to power on. To power off, press and hold the power button again until the device shuts down.

3. Inserting a Micro SD Card (Optional)

If you wish to expand storage, gently insert a Micro SD card (up to 128GB) into the TF Card Slot on the side of the device

until it clicks into place. Ensure the card is inserted in the correct orientation.



This image highlights the location of the USB C Charging Port, Headphone Jack, Power on/off, Volume buttons, Return button, Loudspeaker, TF Card Slot, and Clip.

Operating Instructions

1. Music Playback

From the main menu, tap on the "Music" icon. You can browse "All Songs", "Last Played", "Artists", "Albums", or create "Playlists". The player supports multiple playback modes including repeat 1, repeat all, and shuffle.
Supported audio formats: MP3/ WMA/ APE / FLAC / WAV/ /DRM / ACELP, etc.

Your browser does not support the video tag.

Official product video demonstrating the Colorcool A3 mp3 player with clip and Bluetooth for sports, highlighting its use in various activities like running, cycling, and skateboarding. It also shows the wireless Bluetooth connection feature.

2. Bluetooth Connection

From the main menu, tap on the "Bluetooth" icon. Turn on Bluetooth and search for available devices. Select your Bluetooth headphones or speaker from the list to pair. (Note: This device cannot pair with smartphones).

3. FM Radio

Tap the "FM Radio" icon. You can manually tune to a station or use the auto-scan feature to find available frequencies. Ensure wired headphones are plugged in as they act as the antenna.

4. Voice Recording

Select the "Recording" icon. You can record from the built-in microphone or via line-in. Tap to start and stop recording. Recordings are saved in the device's memory.

5. E-Book Reader

Tap the "E-Book" icon. The player supports TXT format only. You can load compatible e-books onto the device's memory or SD card and read them on the screen.

6. Pedometer

Access the "Pedometer" function to track your steps. This feature is useful for monitoring your activity during walks or runs.

7. Stopwatch

The "Stopwatch" function allows you to time activities. Tap to start, pause, and reset the timer.

8. Alarm Clock & Calendar

Set alarms via the "Alarm" icon. You can configure alarm time, cycle, and music. The "Calendar" icon displays the current date.

Maintenance

- Keep the device dry and away from moisture.
- Clean the screen and body with a soft, dry cloth. Avoid abrasive cleaners.
- Avoid extreme temperatures.
- Do not attempt to disassemble or repair the device yourself.

Troubleshooting

Problem	Solution
Device won't turn on.	Ensure the battery is charged. Connect to a power source and try again.
Cannot connect to Bluetooth device.	Ensure Bluetooth is enabled on both devices and they are within range. This MP3 player cannot pair with smartphones.
No sound from headphones.	Check headphone connection. Ensure volume is not muted or too low. If using Bluetooth, ensure it's properly paired.

Problem	Solution
Cannot transfer files.	Ensure the USB cable is securely connected. Try a different USB port or cable. Check if the device is recognized by your computer.
FM Radio not working.	Ensure wired headphones are plugged in as they serve as the antenna. Try auto-scanning for stations.

Specifications

- Product Dimensions: 1.57 x 0.67 x 2.36 inches
- Item Weight: 1.13 ounces
- Internal Memory: 32GB
- Expandable Memory: Up to 128GB (Micro SD card)
- Bluetooth Version: 5.3
- Screen Size: 1.8 Inches (Full-touch)
- Charging Port: USB Type-C
- Supported Audio Formats: MP3/ WMA/ APE / FLAC / WAV/ /DRM / ACELP, etc.
- Supported Video Formats: AVI/AMV
- Supported E-book Format: TXT only
- Special Features: Video Playback, Voice Recorder, Built-In Clip, Equalizer, FM Radio, Pedometer, Alarm Clock, Calendar, Stopwatch.

Warranty and Support

Colorcool products come with a standard manufacturer's warranty. For detailed warranty information or technical support, please refer to the contact information provided on the product packaging or visit the official Colorcool website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BLNTHWG3

More documents and user manuals: **https://manuals.plus/**