4Gamers C6-100

4Gamers C6-100 Gaming Headset User Manual

Model: C6-100

1. Product Overview

The 4Gamers C6-100 is an over-ear gaming headset designed for multi-platform compatibility, offering clear audio and communication for an immersive gaming experience. It features a flexible microphone, inline volume controls, and comfortable ear cushions for extended use.



Image 1.1: The 4Gamers C6-100 Gaming Headset, showcasing its black and green design with a flexible microphone.

2. Setup and Connectivity

The C6-100 headset connects to your gaming device via a standard 3.5mm audio jack. Ensure your device has a compatible port.

2.1 Compatible Devices

- **PlayStation:** PS4, PS4 Slim, PS4 Pro, PS5
- **Xbox:** Xbox One*, Xbox Series X/S
- **Nintendo:** Nintendo Switch, Switch OLED, Switch Lite
- **PC:** Desktop and Laptop computers**

- **Mobile & Tablet:** Devices with a 3.5mm jack connection

**Original Xbox One controllers may require a Stereo Headset Adapter (sold separately).*
***Older PC models may require a splitter cable (sold separately) for separate microphone and headphone jacks.*

2.2 Connection Steps

1. Locate the 3.5mm audio jack on your gaming console controller, PC, or mobile device.
2. Insert the 3.5mm connector from the headset cable firmly into the audio jack.
3. For optimal performance, ensure the connection is secure.



Image 2.1: Visual guide to headset compatibility with different gaming platforms.

3. Operating Instructions

3.1 Microphone Usage

The C6-100 features a flexible boom microphone. Position the microphone approximately 1-2 inches from your mouth for clear voice capture. The flexible design allows you to adjust its angle and distance for optimal

communication.

3.2 Audio Controls

The headset includes an inline remote control on the cable for convenient audio adjustments:

- **Volume Control:** Use the scroll wheel or slider on the inline remote to adjust the game and chat audio volume.
- **Mic Mute:** A dedicated switch or button on the inline remote allows you to quickly mute or unmute your microphone.



Image 3.1: Inline remote control for microphone mute and volume adjustment.

4. Comfort and Design Features

The C6-100 headset is engineered for comfort during extended gaming sessions.

- **Comfort Over-Ear Cushions:** Soft leatherette ear cups provide comfort and help isolate sound.
- **40mm Drivers:** Deliver clear and powerful audio.
- **Adjustable Headband:** The headband can be extended or retracted to fit various head sizes comfortably.
- **Padded Headband:** Additional cushioning on the headband reduces pressure during long use.
- **Tilt & Twist Ear Cups:** Ear cups can pivot and rotate for a personalized fit and easier storage.
- **Durable Braided Cable:** The cable features a braided outer layer for enhanced durability and tangle resistance.



Image 4.1: Detail of the comfortable over-ear cushions and 40mm audio drivers.



Image 4.2: Key design elements: tilt & twist ear cups, flexible microphone, and braided cable.



Image 4.3: The padded and adjustable headband for a customized fit.

5. Maintenance and Care

Proper care will extend the life and performance of your headset.

- **Cleaning:** Use a soft, dry cloth to wipe down the ear cups and headband. Avoid using harsh chemicals or abrasive materials.
- **Cable Care:** Avoid sharp bends or excessive pulling on the cable. Store the headset in a way that prevents the cable from tangling or being pinched.
- **Storage:** When not in use, store the headset in a clean, dry place away from extreme temperatures and direct sunlight.

6. Troubleshooting

If you encounter issues with your C6-100 headset, refer to the following common solutions:

- **No Sound:**
  - Ensure the 3.5mm jack is fully inserted into the device.
  - Check the inline volume control on the headset cable and increase the volume.
  - Verify your device's audio settings to ensure the headset is selected as the output device and volume is not muted.
  - Test the headset with another device to rule out a device-specific issue.
- **Microphone Not Working:**
  - Ensure the mic mute switch on the inline remote is in the 'unmuted' position.
  - Check your device's audio settings to ensure the headset microphone is selected as the input device.
  - For Xbox One, confirm if a Stereo Headset Adapter is required and properly connected.
  - For PC, ensure a splitter cable is used if your computer has separate microphone and headphone jacks.
  - Position the flexible microphone closer to your mouth.
- **Uncomfortable Fit:**
  - Adjust the headband length by sliding the ear cups up or down.
  - Utilize the tilt and twist feature of the ear cups to find a comfortable angle.

7. Technical Specifications

Feature	Specification
Model Name	C6-100GRN-4G
Connectivity Technology	Wired (3.5 mm Jack)
Compatible Devices	XBOX One, XBOX Series X/S, PS4, PS5, Nintendo Switch, PC, Mobile, Tablet
Ear Placement	Over Ear
Audio Driver Type	Dynamic Driver
Frequency Range	20 Hz - 20,000 Hz
Control Type	Volume Control, Mic Mute
Microphone	Flexible Boom Mic
Cable Feature	Braided, 1.5m length
Material	Leatherette, Foam, Plastic
Item Weight	0.3 Kilograms (10.6 ounces)

8. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official 4Gamers website. Keep your proof of purchase for any warranty claims.
If you require further assistance, please contact 4Gamers customer support.

© 2023 4Gamers. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question