Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 00B080400AR0

Ariete 804 Digital Cyclops Bladeless Fan User Manual

Model: 00B080400AR0

Introduction

Thank you for purchasing the Ariete 804 Digital Cyclops Bladeless Fan. This manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your new fan. Please read this manual thoroughly before using the appliance and keep it for future reference.

Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using this fan.
- Ensure the power supply voltage matches the rating label on the fan.
- Do not operate any fan with a damaged cord or plug. If the cord or plug is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- To protect against electrical shock, do not immerse the fan, plug, or cord in water or spray with liquids.
- Unplug the fan from the outlet when not in use, when moving the fan from one location to another, and before cleaning.
- Do not allow children to operate the fan without supervision.
- Do not insert fingers or foreign objects into any openings of the fan.
- Place the fan on a stable, flat surface to prevent it from tipping over.
- Do not use the fan in areas where flammable liquids or gases are stored.
- This appliance is intended for household use only.

Product Overview

The Ariete 804 Digital Cyclops Bladeless Fan features a sleek, modern design with advanced functionalities for optimal air circulation.




Ariete
4h
3h
2h
1h
LIGHT
TIMER
ON-OFF
SPEED
SWING
CICLOPE



Figure 1: Front view of the Ariete 804 Digital Cyclops Bladeless Fan. This image shows the fan's overall design, including the bladeless air outlet and the control panel at the base.


Ariete
4h
3h
2h
1h
LIGHT
TIMER
ON/OFF
SPEED
SWING
CICLOPE

Figure 2: Close-up of the fan's control panel and remote control. The control panel features touch-sensitive buttons for Light, Timer, On/Off, Speed, and Swing functions. The remote provides convenient control from a distance.

Components:

- **Bladeless Air Outlet:** The main opening through which air is expelled.
- **Control Panel:** Located on the front base, with touch buttons and LED indicators.
- **Base:** Provides stability for the fan.
- **Power Cord:** For connecting to an electrical outlet.
- **Remote Control:** For convenient operation from a distance.

Setup

1. **Unpack:** Carefully remove the fan and all accessories from the packaging. Retain the packaging for future storage or transport.
2. **Placement:** Place the fan on a firm, level surface. Ensure there is adequate space around the fan for proper air circulation and oscillation. Avoid placing it near curtains or other objects that could obstruct airflow.
3. **Power Connection:** Insert the power plug into a standard electrical outlet. Ensure the outlet voltage matches the fan's specifications.
4. **Remote Control Battery (if applicable):** If the remote control requires batteries, insert them according to the polarity markings inside the battery compartment.

Operating Instructions

The Ariete 804 fan can be operated using the touch control panel on the unit or the included remote control.



Figure 3: Demonstrates the convenience of using the remote control to operate the fan from a distance, ideal for adjusting settings without

moving.



Figure 4: Shows the fan with its LED light feature activated, providing ambient illumination. This feature can be controlled independently.

Control Panel / Remote Control Functions:

Button/Function	Description
ON/OFF (Power)	Press to turn the fan on or off. The fan will start at the last used speed setting.
SPEED	Press repeatedly to cycle through the 3 available speed settings: Low, Medium, High.
TIMER	Press to set the automatic shut-off timer. Each press adds 1 hour, up to a maximum of 10 hours. The corresponding LED indicator will light up.
SWING	Press to activate or deactivate the oscillation function, allowing the fan to rotate horizontally for wider air distribution.
LIGHT	Press to turn the integrated LED light on or off.
MODE (Implied from "3 ventilation modes" in product description)	Press to cycle through different ventilation modes (e.g., Normal, Natural, Sleep). Refer to the display for the active mode.

Maintenance and Cleaning

Regular cleaning will help maintain the efficiency and appearance of your fan.

1. **Before Cleaning:** Always unplug the fan from the power outlet before cleaning.
2. **Exterior Cleaning:** Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents, as they may damage the surface.

3. **Air Inlet/Outlet:** Use a soft brush or a vacuum cleaner with a brush attachment to gently remove dust from the air inlet and outlet openings. Do not attempt to disassemble the unit for internal cleaning.
4. **Storage:** When not in use for extended periods, store the fan in its original packaging or a clean, dry place.

Troubleshooting

Before contacting customer service, please check the following common issues:

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in; Power outlet not working; Power button not pressed.	Ensure the fan is securely plugged into a working outlet. Press the ON/OFF button.
Weak airflow.	Speed setting is too low; Air inlets/outlets are blocked.	Increase the speed setting. Check and clear any obstructions from the air inlets/outlets.
Fan is noisy.	Fan is not on a stable surface; Internal dust accumulation (rare for bladeless).	Place the fan on a flat, stable surface. Ensure no foreign objects are near the air inlets.
Remote control not working.	Batteries are dead or incorrectly inserted; Obstruction between remote and fan.	Replace batteries, ensuring correct polarity. Remove any obstructions and ensure you are within range.

Specifications

Feature	Detail
Brand	Ariete
Model	00B080400AR0 (Ariete 804)
Power (Wattage)	45W
Voltage	2.3E+2 Volt (230V)
Color	White
Dimensions (Product)	20.5P x 26.5L x 58H cm (approx. 8.1D x 10.4W x 22.8H inches)
Weight (Item)	4.11 kg (approx. 9.06 lbs)
Speed Settings	3 (Low, Medium, High)
Timer	Up to 10 hours
Special Features	Bladeless design, Digital display, LED light, Oscillation, Portable

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or visit the official Ariete website. Keep your purchase receipt as proof of purchase.
For further assistance, you may contact Ariete customer service through their official channels.
Website: www.ariete.net

© 2025 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BLVSQZBV

More documents and user manuals: **https://manuals.plus/**