Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CAPOXO D7

CAPOXO D7 Wireless Earbuds User Manual

Model: D7 | Brand: CAPOXO

Product Overview

The CAPOXO Wireless Earbuds (Model D7) are designed to provide a high-quality audio experience with extended battery life and convenient features. These earbuds are suitable for various uses, including listening to music, making calls, and engaging in sports activities.



Figure 1: CAPOXO D7 Wireless Earbuds and Charging Case. The case features a dual LED power display indicating the battery level of both the case and the individual earbuds.

Package Contents

Ensure all items are present upon unboxing:

- CAPOXO D7 Wireless Earbuds (Left and Right)
- Wireless Charging Case
- USB-C Charging Cable
- User Manual (this document)
- 3 Pairs of Rubber Ear Tips (Small, Medium, Large)



Figure 2: What's in the Box. The package includes the earbuds, charging case, USB-C cable, and various sizes of ear tips for a comfortable fit.

Setup and Pairing

Initial Setup

1. **Charge the Case:** Before first use, fully charge the charging case using the provided USB-C cable or a wireless charging pad (not included). The dual LED display will show the charging progress.
2. **Charge Earbuds:** Place the earbuds into the charging case. They will begin charging automatically.

Bluetooth Pairing

The earbuds feature auto-quick pairing for convenience.

1. **Activate Earbuds:** Open the charging case. The earbuds will automatically turn on and enter pairing mode.
2. **Enable Bluetooth:** On your device (smartphone, tablet, laptop), go to the Bluetooth settings.
3. **Select Device:** Look for "D7" in the list of available Bluetooth devices and select it to connect.
4. **Confirmation:** Once connected, you will hear an audio prompt, and the earbuds will be ready for use.
5. **Automatic Reconnection:** After the initial pairing, the earbuds will automatically connect to the last paired device when taken out of the charging case.



Figure 3: Charging Options. The earbuds and case support both USB-C wired charging and wireless charging for convenience.

Operating Instructions

Touch Controls

The CAPOXO D7 earbuds feature intuitive touch controls on each earbud. Avoid excessive pressure on the ear canal when operating.

Play/Pause: Double-tap L/R earbud.

Answer/End Call: Double-tap L/R earbud.

Next Track: Triple-tap R earbud.

Previous Track: Triple-tap L earbud.

Reject Call: Long-press L/R earbud for 2 seconds.

Volume -: Long-press L earbud.

Volume +: Long-press R earbud.

Activate Voice Assistant (Siri/Google Assistant): Triple-tap L/R earbud.



Figure 4: Smart Touch Control functions for the earbuds.

Audio Quality and Call Performance

Engineered with high-quality speakers, these earbuds deliver a wide sound range with dynamic highs and deep bass, providing a stereo surround sound experience. Built-in microphones ensure clear and loud voice transmission during phone calls, making them suitable for web meetings and online classes.



Figure 5: Internal structure illustrating the Hi-Fi Stereo Sound components.

Single and Dual Earbud Use

The earbuds support flexible usage, allowing you to use either a single earbud or both simultaneously. This is convenient for situations where you need to remain aware of your surroundings or extend battery life by alternating earbuds.



Figure 6: Versatile Usage. The earbuds are suitable for various daily activities.

Battery and Charging

The CAPOXO D7 earbuds offer extended playtime and flexible charging options.

- **Playtime:** A single full charge provides 6 hours of use. With the charging case, total playtime extends to 50 hours (at 50%-60% volume).
- **Charging Time:** Approximately 2 hours for a full charge.
- **Charging Methods:**
  - **USB-C Cable:** Connect the provided USB-C cable to the charging port on the case and a power source.
  - **Wireless Charging:** Simply place the charging case on a compatible wireless charging pad (not included).
- **LED Power Display:** The built-in dual LED display on the charging case allows you to monitor the remaining power of the case and the charging status of each earbud in real-time.



Figure 7: Superior Battery Life for extended listening.

Maintenance and Care

Water Resistance (IPX7)

The earbuds are IPX7 waterproof, meaning they can effectively prevent damage from sweat and raindrops. This makes them ideal for sports, workouts, running, and travel. **Note:** The charging case is not waterproof. Do not submerge the charging case in water.



Figure 8: IPX7 Waterproof rating for the earbuds.

Cleaning

Regularly clean the earbuds and charging contacts with a soft, dry cloth to ensure optimal performance and charging efficiency. Remove ear tips and clean them separately with mild soap and water if necessary, ensuring they are completely dry before reattaching.

Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

Troubleshooting

If you encounter issues with your CAPOXO D7 earbuds, try the following steps:

- **No Sound/Connection Issues:**

- Ensure earbuds are charged.
- Verify Bluetooth is enabled on your device.
- Forget "D7" from your device's Bluetooth list and re-pair.
- Place earbuds back in the case, close the lid, wait a few seconds, then open to reset.

- **One Earbud Not Working:**
  - Ensure both earbuds are charged.
  - Clean the charging contacts on the earbud and inside the case.
  - Try resetting the earbuds by placing them in the case and re-pairing.
- **Charging Issues:**
  - Check the USB-C cable and power adapter.
  - Ensure the wireless charging pad is compatible and properly aligned.
  - Clean the charging contacts on the earbuds and inside the case.
- **Poor Sound Quality:**
  - Ensure earbuds are properly seated in your ears. Try different sized ear tips.
  - Clean any debris from the earbud speakers.
  - Ensure your device is within the Bluetooth range (33 feet).

Specifications

Feature	Detail
Model Number	D7
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	33 Feet
Battery Life (Single Charge)	6 Hours
Total Playtime (with Charging Case)	50 Hours
Charging Time	2 Hours
Water Resistance Level	IPX7 (Earbuds only)
Control Method	Touch
Audio Driver Size	13 Millimeters
Item Weight	3.2 ounces
Product Dimensions	0.98 x 0.87 x 0.94 inches
Material	Plastic
Ear Placement	In Ear

Noise Control	Active Noise Cancellation

Warranty and Support

For detailed warranty information and customer support, please refer to the official CAPOXO website or contact their customer service directly. A digital version of the user manual is also available for download:
Download User Manual (PDF)

© 2023 CAPOXO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BLZ8HNDT

More documents and user manuals: **https://manuals.plus/**