Oster BLSTEPH-BTP-000

Oster Pro Series 2-in-1 Kitchen System

Model: BLSTEPH-BTP-000
Brand: Oster

Product Overview

The Oster® XL Professional 2-in-1 Kitchen System combines pulverizing, ice-crushing power and blending versatility with touch-activated controls, in a sleek, modern design. This blender and food processor features a powerful 1200-watt, high-performance motor that effortlessly blends tough ingredients. The highly advanced, capacitive touchscreen display includes 4 Auto Programs for Smoothie, Milkshake, Salsa, and Frozen Drinks, so you can whip up more of your favorite recipes in no time. Make more of your favorite frozen drinks, smoothies, and salsas with the extra-large, dishwasher-safe, BPA-free 9-cup Tritan™ jar. The 5-cup food processor attachment features an S-Blade and Slicing/Shredding Disc that turns this Oster blender into your go-to kitchen tool. Dual Direction Blade Technology™ automatically changes direction to prevent jamming and produce consistently perfect blends. Plus, the included tamper tool makes it easy to push tricky ingredients back toward the blades.

Key Features

- **Touch-Activated Controls:** Modern and intuitive touch LED display for easy operation.
- **High-Performance Motor:** Powerful 1200-watt motor for effortless blending and pulverizing.
- **XL 9-Cup Tritan Jar:** Large capacity, dishwasher-safe, and BPA-free for convenience and safety.
- **Versatile Blending:** Features 4 Auto Programs (Smoothie, Milkshake, Salsa, Frozen Drinks) and 4 manual speed settings.
- **Food Processor Attachment:** Includes a 5-cup food processor with S-Blade and Slicing/Shredding Disc for chopping and dicing.
- **Tamper Tool:** Assists in processing difficult ingredients by pushing them towards the blades.
- **Dual Direction Blade Technology:** Automatically changes blade direction to prevent jamming and ensure consistent results.

Components



The complete Oster Pro Series 2-in-1 Kitchen System, featuring the blender base, 9-cup Tritan jar, 5-cup food processor attachment, and tamper tool.



The powerful 1200-watt motor effortlessly crushes tough ingredients like ice and Oreos, as shown with the blender jar filled with ingredients.



The extra-large 9-cup Tritan jar is ideal for making large batches of smoothies, easily pouring a green smoothie into a bowl.



The 5-cup food processor attachment, equipped with a Slicing/Shredding Disc, efficiently processes ingredients like tomatoes and onions.



The included tamper tool helps to push difficult-to-process ingredients down towards the blades for thorough blending.



The intuitive touch-activated controls allow for easy selection of auto programs or manual speed settings.

Official Product Video

This video demonstrates the Oster Pro Series 2-in-1 Kitchen System, highlighting its features and the food processor attachment in action.

Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean Before First Use:** Wash the Tritan jar, food processor bowl, blades, discs, and tamper tool in warm, soapy water or place them in the dishwasher (top rack recommended). Wipe the motor base with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Assemble Blender:** Place the 9-cup Tritan jar onto the motor base, ensuring it is securely seated and locked into place.
4. **Assemble Food Processor:** Alternatively, place the 5-cup food processor bowl onto the motor base. Insert the

desired blade (S-Blade) or disc (Slicing/Shredding Disc) onto the center post. Secure the food processor lid.

5. **Power Connection:** Plug the power cord into a standard electrical outlet. The power button on the touch display will illuminate.

Operating Instructions

Blender Function

1. **Add Ingredients:** Place ingredients into the 9-cup Tritan jar. Do not exceed the MAX fill line.
2. **Secure Lid:** Place the blender lid firmly onto the jar. Ensure the lid is properly sealed.
3. **Select Program or Speed:**
   - **Auto Programs:** Touch the desired auto program icon (Smoothie, Milkshake, Frozen, Salsa) on the display. The blender will run through a pre-programmed cycle and stop automatically.
   - **Manual Speeds:** Touch PULSE for short bursts of power, or select LOW, MEDIUM, or HIGH for continuous blending. Touch the power button to stop manual blending.
4. **Using the Tamper Tool:** For thick mixtures or when ingredients get stuck, remove the filler cap from the lid and insert the tamper tool. Use it to push ingredients towards the blades while the blender is running. **Never use other utensils or your hands.**

Food Processor Function

1. **Assemble:** Ensure the food processor bowl is securely on the base with the S-Blade or Slicing/Shredding Disc installed. Secure the food processor lid.
2. **Add Ingredients:** For chopping, add ingredients directly into the bowl. For slicing/shredding, use the feeding chute on the lid to add ingredients while the processor is running.
3. **Select Speed:** Use the PULSE setting for chopping or the LOW/MEDIUM/HIGH settings for continuous processing, depending on the desired consistency.

Maintenance and Cleaning

- **Unplug:** Always unplug the appliance from the power outlet before cleaning.
- **Dishwasher Safe Parts:** The Tritan jar, food processor bowl, blades, discs, and tamper tool are dishwasher safe (top rack recommended).
- **Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
- **Touch Display:** The capacitive touchscreen display wipes clean easily.
- **Storage:** Store the appliance in a dry place.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; safety interlock not engaged.	Ensure power cord is securely plugged into a working outlet. Make sure the jar/bowl and lid are correctly assembled and locked onto the base.
Blades are not spinning or jamming.	Too many ingredients; ingredients are too large or hard; safety feature activated.	Reduce the amount of ingredients. Cut larger ingredients into smaller pieces. Use the tamper tool to push ingredients towards the blades. The Dual Direction Blade Technology should help prevent jamming, but if it persists, turn off and clear the obstruction.
Leaking from the bottom of the jar/bowl.	Jar/bowl not properly seated; blade assembly loose; gasket missing or damaged.	Ensure the jar/bowl is securely twisted and locked onto the motor base. Check that the blade assembly is tightly secured to the bottom of the jar/bowl. Verify the gasket is correctly in place and undamaged.
Motor smells or overheats.	Overloading; continuous operation for too long.	Do not overload the appliance. Allow the motor to cool down for at least 10-15 minutes before resuming use. Refer to the manual for maximum continuous operating times.

SPECIFICATIONS

Feature	Detail
Brand	Oster
Model Name	Pro Series 2-in-1 Kitchen System
Model Number	BLSTEPH-BTP-000
Power	1200 Watts
Product Dimensions	6.93"D x 6.93"W x 15.87"H
Item Weight	4.5 pounds
Color	Dark Blue
Blender Jar Capacity	9 Cups (Tritan, BPA-Free)
Food Processor Bowl Capacity	5 Cups
Blade Material	Stainless Steel
Controls	Touch-Activated LED Display
Auto Programs	Smoothie, Milkshake, Salsa, Frozen Drinks
Manual Speeds	Pulse, Low, Medium, High

Feature	Detail
Care Instructions	Dishwasher Safe (removable parts)

Warranty and Support

Specific warranty details for the Oster Pro Series 2-in-1 Kitchen System are not available in the provided product data. Please refer to the product packaging, the official Oster website, or contact Oster customer support for detailed warranty information and support options.
For further assistance, please consult the manufacturer's official resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question