Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BCXY CS-AY4020CL

BCXY Replacement Battery for Doro Domo Phones (Models DFC-0150, DFC-0190, 2424, 2415, 2414) - Model CS-AY4020CL Instruction Manual

This manual provides important instructions for the safe and effective use of your BCXY replacement battery.

1. Product Overview

The BCXY CS-AY4020CL is a high-quality replacement lithium-ion battery designed for specific Doro Domo phone models. It provides reliable power, ensuring your device operates efficiently. This battery is manufactured to meet original specifications, offering a capacity of 1200mAh and a voltage of 3.7V.



Image: The BCXY CS-AY4020CL replacement battery. The label indicates Model No.: CS-AY4020CL, Capacity: 1200mAh/4.44Wh, Type: Lithium-ion, Volts: 3.7VDC, Part No: RTR001F01. It also states 'WARRANTY VOID IF LABEL IS REMOVED' and 'Made In China'.

Compatible Models:

- Domo DFC-0150
- Domo DFC-0190
- Domo 2424
- Domo 2415
- Domo 2414

Compatible Battery Part Numbers:

- DBR-800D
- DBR-800A

2. Important Safety Instructions

WARNING: Failure to follow these safety instructions may result in fire, electric shock, injury, or damage to the battery or device.

- Do not disassemble, open, crush, bend, deform, puncture, or shred the battery.
- Do not modify or remanufacture the battery, attempt to insert foreign objects into the battery, or immerse or expose it to water or other liquids.
- Do not expose the battery to fire, explosion, or other hazards.
- Only use the battery for the system for which it is specified.
- Only use charging systems that have been qualified with the system per IEEE-Std-1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Do not short-circuit a battery or allow metallic conductive objects to contact battery terminals.
- Promptly dispose of used batteries in accordance with local regulations.
- Battery usage by children should be supervised.
- Avoid dropping the phone or battery. If the phone or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.

3. Battery Installation

Follow these steps to safely replace the battery in your compatible Doro Domo phone:

1. **Power Off Device:** Ensure your Doro Domo phone is completely powered off before beginning the installation process.
2. **Remove Back Cover:** Carefully remove the back cover of your phone. Refer to your phone's original manual if you are unsure how to do this.
3. **Remove Old Battery:** Gently lift and remove the old battery from its compartment. Avoid using excessive force or sharp objects.
4. **Insert New Battery:** Align the BCXY replacement battery with the battery compartment and gently press it into place, ensuring the contacts are properly aligned. The battery should fit snugly.
5. **Replace Back Cover:** Reattach the phone's back cover, ensuring it is securely fastened.
6. **Initial Charge:** It is recommended to fully charge the new battery before its first use.

4. Operating Your Battery

To maximize the performance and lifespan of your BCXY replacement battery, consider the following operational guidelines:

- **First Use:** For optimal performance, fully charge the battery before its initial use.
- **Charging:** Always use the original charger or a certified compatible charger for your Doro Domo phone. Avoid using damaged chargers or cables.
- **Avoid Deep Discharge:** Do not allow the battery to completely drain to 0% frequently. Recharge your device when

the battery level is low.

- **Temperature:** Operate your device within recommended temperature ranges. Extreme cold or heat can negatively impact battery performance and lifespan.
- **Regular Use:** Regular use and charging cycles help maintain battery health.

5. Care and Maintenance

Proper care and maintenance will help extend the life of your battery:

- **Storage:** If storing the battery for an extended period, store it in a cool, dry place at approximately 50% charge. Avoid storing it fully charged or completely depleted.
- **Cleaning:** Keep the battery contacts clean. If necessary, gently wipe them with a dry, lint-free cloth.
- **Avoid Physical Damage:** Protect the battery from drops, impacts, and punctures. Physical damage can lead to internal short circuits or leakage.
- **Extreme Temperatures:** Do not expose the battery to extreme temperatures (below 0°C or above 45°C) as this can degrade performance and safety.

6. Troubleshooting Common Issues

If you encounter issues with your BCXY replacement battery, refer to the following table for potential solutions:

Problem	Possible Solution
Battery not charging	Ensure the charger and cable are working correctly. Check if the battery is properly seated in the phone. Try cleaning the battery and phone contacts.
Short battery life	Ensure the battery has been fully charged. Reduce background apps and screen brightness. Check for excessive network usage. Avoid extreme temperatures.
Phone does not power on	Ensure the battery is correctly installed and has sufficient charge. Connect the phone to a charger for at least 15 minutes before attempting to power on.
Battery swelling or overheating	Immediately discontinue use and remove the battery if safe to do so. Contact customer support for assistance. Do not attempt to puncture or use a swollen battery.

7. Product Specifications

- **Model Number:** CS-AY4020CL
- **Capacity:** 1200mAh / 4.44Wh
- **Voltage:** 3.7V
- **Battery Cell Composition:** Lithium Ion
- **Dimensions:** 53.2 x 34.0 x 5.7mm (2.09 x 1.34 x 0.22 inches)
- **Weight:** 48 Grams (1.69 ounces)
- **Certifications:** ISO9001, RoHS, CE, UN38.3, MSDS
- **Manufacturer:** BCXY

8. Warranty Information

This BCXY replacement battery is designed for durability and performance. Please note that the**WARRANTY IS VOID IF THE LABEL IS REMOVED** from the battery. For specific warranty terms and conditions, please refer to the purchase documentation or contact BCXY customer support.

9. Customer Support

If you have any questions, concerns, or require assistance with your BCXY replacement battery, please contact the seller or BCXY customer support. Provide your product model number (CS-AY4020CL) and details of your inquiry for prompt service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BM9437N9

More documents and user manuals: **https://manuals.plus/**