FEELWORLD TP10

FEELWORLD TP10 Portable Folding Teleprompter User Manual

1. Introduction

The FEELWORLD TP10 is a portable and foldable 10-inch teleprompter designed to assist with video recording by displaying scrolling text for the presenter. It supports prompting from smartphones or tablets up to 11 inches and is compatible with both DSLR cameras and smartphones for shooting. Its compact design and versatile mounting options make it suitable for various production environments, including interviews, online education, and social media content creation.

2. Package Contents

Please verify that all items are present in the package:

- FEELWORLD TP10 Teleprompter Unit
- Bluetooth Remote Control
- Lens Adapter Rings (various sizes)
- Smartphone/Tablet Clamp
- Carry Bag
- Sun Hood

3. Product Features

- **Folding Design:** Allows for convenient storage and transport.
- **10-inch Beam Split Glass:** Provides clear display of prompted content with excellent light transmission.
- **Wide Compatibility:** Supports smartphones or tablets up to 11 inches for prompting.
- **Versatile Shooting:** Compatible with DSLR cameras and smartphones for horizontal and vertical video recording.
- **Wide Angle Lens Support:** Designed to accommodate wide-angle lenses for broader vision.
- **Bluetooth Remote Control:** Enables convenient control of prompting text.
- **Multiple Mounting Threads:** Features 1/4-inch standard mounting threads for attaching accessories like microphones or fill lights.

4. Setup Instructions

4.1 Unpacking and Assembly

Carefully remove all components from the carry bag. Unfold the teleprompter unit to its operational position. The folding glass design allows for quick setup.



Image: The folding glass design of the teleprompter, illustrating how it opens for use.

4.2 Mounting the Camera or Smartphone

For DSLR Cameras: Attach your DSLR camera to the rear mounting plate of the teleprompter. Select the appropriate lens adapter ring from the provided set and secure it to your camera lens. This ring will connect the camera to the teleprompter's main body, ensuring a light-tight seal.

For Smartphones (as camera): Use the provided smartphone clamp to secure your smartphone in the camera position at the rear of the teleprompter. Ensure the phone's camera lens is aligned with the opening.



Image: Teleprompter configured for smartphone shooting, demonstrating both horizontal and vertical orientations.

4.3 Mounting the Prompting Device (Smartphone or Tablet)

Place your smartphone or tablet (up to 11 inches) onto the adjustable tray at the base of the teleprompter. Ensure it is securely seated and positioned to reflect text clearly onto the beam splitter glass.



Image: The 10-inch beam split glass showing clear, readable text from a prompting device.

4.4 Attaching to a Tripod

Secure the teleprompter to a tripod using the 1/4-inch mounting thread located at its base. Ensure the connection is stable before proceeding.

4.5 Optional Accessories

The teleprompter features multiple 1/4-inch mounting threads for attaching additional equipment such as microphones, LED fill lights, or external monitors. These can be mounted to enhance your recording setup.



Image: Diagram showing various optional accessories and their attachment points on the teleprompter setup.

5. Operating Instructions

5.1 Powering On

Ensure your prompting smartphone/tablet and camera are adequately charged or connected to power.

5.2 App Installation

Download and install the official FEELWORLD teleprompter application on your prompting smartphone or tablet from its respective app store (iOS or Android).

5.3 Bluetooth Remote Control Pairing

1. Turn on the Bluetooth remote control.
2. On your prompting device, navigate to Bluetooth settings and search for available devices.
3. Select the remote control from the list to pair.

4. Open the FEELWORLD teleprompter app. The app should automatically detect the paired remote control.

5.4 Loading and Adjusting Script

Within the teleprompter app, load your desired script. Use the app's interface or the Bluetooth remote control to adjust text scrolling speed, font size, and background color for optimal readability.

5.5 Shooting Modes

The TP10 supports both horizontal and vertical shooting orientations for your camera or smartphone, allowing flexibility for various content formats.

6. Maintenance

6.1 Cleaning the Beam Splitter Glass

To clean the beam splitter glass, use a soft, lint-free microfiber cloth. For stubborn smudges, apply a small amount of lens cleaning solution to the cloth (not directly to the glass) and gently wipe. Avoid abrasive materials or harsh chemicals.

6.2 Cleaning the Teleprompter Body

Wipe the exterior of the teleprompter with a soft, dry cloth. If necessary, a slightly damp cloth can be used, followed by immediate drying.

6.3 Storage

When not in use, fold the teleprompter and store it in its provided carry bag to protect it from dust and physical damage. Store in a cool, dry place.

7. Troubleshooting

7.1 Remote Control Not Connecting to App

- Ensure the remote control is powered on and fully charged.
- Verify that Bluetooth is enabled on your prompting device.
- Confirm the remote is paired with your device in the Bluetooth settings.
- Close and reopen the FEELWORLD teleprompter app.
- Restart both the remote control and your prompting device.

7.2 Prompting Device (Tablet/Smartphone) Does Not Fit or Is Unstable

- Ensure your device's dimensions are within the supported range (up to 11 inches).
- Adjust the tray to securely hold the device.
- If the device is too heavy, ensure the teleprompter is mounted on a stable tripod and consider additional support if available.

7.3 Text Appears Unclear or Faint

- Increase the brightness of your prompting smartphone/tablet screen.
- Ensure the camera lens is properly aligned with the teleprompter's opening.
- Clean the beam splitter glass for any smudges or dust.
- Adjust the font size and contrast within the teleprompter app.

8. Specifications

Item Model Number	KT-TP10
Manufacturer	FEELWORLD
Package Dimensions	9.72 x 8.54 x 3.66 inches
Item Weight	3.08 pounds
First Available Date	November 21, 2022

9. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official FEELWORLD website. Contact their customer service for assistance with product issues or inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Is there an adapter ring to fit the DJI Osmo Action 5 Pro for the FEELWORLD TP10 teleprompter?

The FEELWORLD TP10 includes a set of standard lens adapter rings (typically ranging from 49mm to 77mm) designed for DSLR and mirrorless camera lenses. Because the DJI Osmo Action 5 Pro is an action...

Read full answer