Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mattel HNT62

Mattel Jurassic World Track 'n Attack Tyrannosaurus Rex Action Figure Instruction Manual

Model: HNT62

Introduction

Welcome to the world of Jurassic adventure! This Mattel Jurassic World Track 'n Attack Tyrannosaurus Rex action figure brings the excitement of dinosaurs to life with its realistic features and interactive play. Designed for fans aged 4 years and up, this figure includes double chomp head action, authentic sounds, and removable tracking gear. Enhance your play experience by connecting to the free Jurassic World Facts App for augmented reality adventures.

What's Included

- 1 Jurassic World Track 'n Attack Tyrannosaurus Rex figure
- 1 Removable tracking gear accessory
- 3 LR44 batteries (pre-installed)

Colors and decoration may vary.

Key Features

- **Double Chomp Action:** Experience realistic two-part head chomping action with accompanying sounds.
- **Authentic Design:** Features a desert terrain design and removable tracking gear for enhanced play.
- **Posable Figure:** The figure is posable, allowing for dynamic action scenes and display.
- **Augmented Reality (AR) Integration:** Scan the hidden Tracking Code with the free Jurassic World Facts App to unlock interactive AR experiences and games.
- **Interactive App Features:** Explore thermal and X-ray modes, and play games like Rescue 'n Release Mission and Track 'n Catch Challenge within the app.

Setup Guide

Follow these steps to set up your Tyrannosaurus Rex figure and unlock its full potential:

1. **Battery Installation:** The figure comes with 3 LR44 batteries pre-installed. If replacement is needed, locate the battery compartment on the underside of the figure, open it with a small screwdriver, replace the batteries, and secure the cover.
2. **Attach Tracking Gear:** The removable tracking gear can be placed over the dinosaur's head and neck for an authentic look.
3. **Download the App:** Download the free **Jurassic World Facts App** on a compatible smart device (Android or iOS).
4. **Locate Tracking Code:** Find the hidden Tracking Code on the dinosaur figure.
5. **Scan for AR Experience:** Open the Jurassic World Facts App and scan the Tracking Code to initiate augmented reality activities and games.



Image: Locate and scan the hidden Tracking Code on the dinosaur's back to activate AR features.



Image: The Jurassic World Facts App interface, showing augmented reality gameplay.

Operating Instructions

Activating Sounds and Chomping Action

To activate the Tyrannosaurus Rex's sounds and double chomp action, press the button located on its back. The head will move, and the mouth will open and close with realistic chomping sounds.

Your browser does not support the video tag.

Video: Official demonstration of the Tyrannosaurus Rex's chomping action and sounds.



Image: A hand demonstrating the double chomp action of the Tyrannosaurus Rex figure.

Posable Movement

The Tyrannosaurus Rex figure features posable limbs and tail, allowing you to create various dynamic poses for play or display. Gently adjust the legs, arms, and tail to position the dinosaur as desired.

Augmented Reality Play

Once the Tracking Code is scanned in the Jurassic World Facts App, you can engage in various augmented reality experiences. Follow the in-app instructions to interact with your digital dinosaur, explore different modes, and play exciting games.

Care and Maintenance

- **Cleaning:** Wipe the figure with a damp cloth to remove dust and dirt. Do not submerge in water.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight to prevent fading or damage.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage.

Troubleshooting

- **No Sound/Movement:** Ensure batteries are correctly installed and not depleted. Replace with fresh LR44 batteries if necessary.
- **App Not Scanning Code:** Ensure good lighting conditions and that the tracking code is clean and clearly visible. Update the Jurassic World Facts App to the latest version.
- **Figure Damage:** If any parts are broken or damaged, discontinue use. Contact Mattel customer support for assistance.

Product Specifications

Brand	Mattel
Model Number	HNT62
Product Dimensions	66.93 x 193.31 x 77.56 inches
Item Weight	1.1 pounds
Recommended Age	4 years and up
Batteries Required	3 LR44 (included)

Warranty and Support

Mattel stands behind the quality of its products. For warranty information, product support, or to inquire about replacement parts, please visit the official Mattel website or contact their customer service department. Keep your purchase receipt for warranty claims.

© 2023 Mattel. All Rights Reserved. Jurassic World and all related marks and logos are trademarks and copyrights of Universal Studios and Amblin Entertainment, Inc. Licensed by Universal Studios. All Rights Reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BN167RHK

More documents and user manuals: **https://manuals.plus/**